Configurar o cluster FTD no FP9300 (intrachassi)

Contents

Introduction **Prerequisites** Requirements **Componentes Utilizados** Informações de Apoio Configurar Diagrama de Rede Tarefa 1. Criar interfaces necessárias para o cluster FTD Tarefa 2. Criar cluster FTD Tarefa 3. Registrar cluster FTD no FMC Tarefa 4. Configurar subinterfaces de canal de porta no FMC Tarefa 5. Verificar a conectividade básica Captura de cluster da IU do Gestor de Chassi Tarefa 6. Excluir um dispositivo escravo do cluster Verificar Troubleshoot Informações Relacionadas

Introduction

Este documento descreve como configurar e verificar o recurso de cluster no dispositivo FPR9300.

Caution: As informações fornecidas neste documento abrangem a instalação/configuração inicial do cluster. Este documento não se aplica a uma substituição de unidade (procedimento de autorização de devolução de material - RMA)

Prerequisites

Requirements

Não existem requisitos específicos para este documento.

Componentes Utilizados

As informações neste documento são baseadas nestas versões de software e hardware:

• Dispositivo de segurança Cisco Firepower 9300 executando 1.1(4.95)

- Firepower Threat Defense (FTD) executando 6.0.1 (build 1213)
- FireSIGHT Management Center (FMC) executando 6.0.1.1 (build 1023)

Hora de conclusão do laboratório: 1 hora.

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. Se a rede estiver ativa, certifique-se de que você entenda o impacto potencial de qualquer comando.

Informações de Apoio

- No dispositivo FPR9300 com FTD, você pode configurar o Clustering intra-chassi em todas as versões suportadas.
- O agrupamento entre chassis foi apresentado na seção 6.2.
- O canal de porta 48 é criado como um link de controle de cluster. Para o agrupamento entre chassis, este link utiliza o painel traseiro Firepower 9300 para comunicações em cluster.
- Interfaces de dados individuais não são suportadas, com exceção de uma interface de gerenciamento.
- A interface de gerenciamento é atribuída a todas as unidades no cluster.

Configurar

Diagrama de Rede



Tarefa 1. Criar interfaces necessárias para o cluster FTD

Requisito de tarefa:

Crie um cluster, uma interface de gerenciamento e uma interface de dados do canal de porta.

Solução:

Etapa 1. Crie uma interface de Dados do canal da porta.

Para criar uma nova interface, você precisa fazer login no FPR9300 Chassis Manager e navegar

até a guia Interfaces.

Selecione Add Port Channel e crie uma nova Port Channel Interface com estes parâmetros:

ID do canal da porta	5
Тіро	Dados
Enable	Yes
ID do membro	Ethernet1/3, Ethernet 1/4

Selecione OK para salvar a configuração como mostrado na imagem.

Add Port Cha	nnel			?×
Port Channel ID:	5	🗹 Enable		
Туре:	Data	•		
Speed:	1gbps 👻			
Interfaces				
Ava	ilable Interface		Member ID	
	Search]	Ethernet1/3	
	Ethernet1/2		Ethernet1/4	
	Ethernet1/3			1
	Ethernet1/4			
	Ethernet1/5			
	Ethernet1/6			
	Ethernet1/7	Add Interface		
	Ethernet1/8			
	Ethernet2/1			
	Ethernet2/2			
	Ethernet2/3			
	Ethernet2/4			
	Ethernet3/1			
	Ethernet3/2			
			ОК	Cancel

Etapa 2. Crie uma interface de gerenciamento.

Na guia Interfaces, escolha a interface, clique em Edit e configure a interface Management Type.

Clique em OK para salvar a configuração como mostrado na imagem.

Edit Inte	rface - Ethernet1	/1 ?×
Name: Type:	Ethernet1/1	Enable
Speed:	1gbps	×
	ок	Cancel

Etapa 3. Crie uma Interface de Link de Controle de Cluster.

Clique no botão **Add Port Channel** e crie uma nova Port Channel Interface com esses parâmetros e conforme mostrado na imagem.

ID do canal da porta	48
Тіро	Cluster
Enable	Yes
ID do membro	-

Add Port Cha	annel				? ×
Port Channel ID:	48	C Enable			
Туре:	Cluster				
Speed:	1gbps 👻	1	1.0		
Interfaces		_			
Av	ailable Interface		Member ID		
	Search				
	Ethernet1/2				
	Ethernet1/5				
	Ethernet1/6				
	Ethernet1/7				
	Ethernet1/8	Add to be do as			
	Ethernet2/1	Add Interface			
	Ethernet2/2				
	Ethernet2/3				
	Ethernet2/4				
	Ethernet3/1				
	Ethernet3/2				
	Ethernet3/3				
	Ethernet3/4				
				ок	Cancel

Tarefa 2. Criar cluster FTD

Requisito de tarefa:

Crie uma unidade de cluster FTD.

Solução:

Etapa 1. Navegue até Dispositivos lógicos e clique no botão Adicionar dispositivo.

Crie o cluster FTD da seguinte maneira:

Nome de dispositivo	FTD_cluster
Modelo	Defesa contra ameaças do Cisco Firepower
Versão da imagem	6.0.1.1213
Modo do dispositivo	Cluster

Para adicionar o dispositivo, clique em **OK** conforme mostrado na imagem.

Add Device			?×
Device Name:	FTD_cluster		
Template:	Cisco Firepower Threat Defense	~	
Image Version:	6.0.1.1213	~	
Device Mode:	🔵 Standalone 💿 Cluster		
		_	
	ОК		Cancel

Etapa 2. Configure e implante o cluster FTD.

Depois de criar um dispositivo FTD, você é redirecionado para a janela Provisioningdevice_name.

Clique no ícone do dispositivo para iniciar a configuração conforme mostrado na imagem.

0	verview	Interfaces	Logical Devices	Security Mo	dules Platform Settings					System	Tools	Help	admin
d	rovisionin ustered	g - FTD_cluste Cisco Firepow	er Threat Defense	6.0.1.1213						Se	_	Canos	
D	ata Ports		-										
10	Ethernet1/2												
10	Ethernet1/S												
	Ethernet1/6						<u></u>		<u> </u>				
	Ethernet1/7												
	Ethernet1/8												
	Ethernet2/1												
	Ethernet2/2						FTD - 6.0.1	.1213					
	Ethernet2/3						Security Modu	ile 1,2,3					
	Ethernet2/4												
	Ethernet3/1												
	Ethernet3/2						· · · · · · · · · · · · · · · · · · ·						
	Ethernet3/4												
	Port-channel!												
			<u></u>										_
	Security	fodule Aj	plication	Version	Management IP	Gateway	Management Port	Status					
2	Security M	odule 1 PT	D	6.0.1.1213									
a	Security M	odule 2 FT	D	6.0.1.1213									
4	Security M	odule 3 PT	D	6.0.1.1213									

Configure a guia **Informações do Cluster** FTD com essas configurações e conforme mostrado na imagem.

Chave do cluster	cisco
Nome do grupo de cluster	FTD_cluster
Interface de gerenciamento	Ethernet1/1

Cisco Firepower Thre	eat Defense - Configuration 📧
Cluster Information Setti	ings Interface Information Agreement
Security Module(SM)	
Security Module-1,Security M	Iodule-2,Security Module-3
Interface Information	
Cluster Key:	
Cluster Group Name:	FTD_cluster
Management Interface:	Ethernet1/1
	OK Cancel

Configure a guia **Configurações** do FTD com essas configurações e conforme mostrado na imagem.

Chave de registro	cisco
Senha	Admin123
IP do Firepower Management	10 62 148 73
Center	10.02.140.75
Domínios de pesquisa	cisco.com
Modo de firewall	Roteado
Servidores DNS	173.38.200.100
Nome de host totalmente qualificado	ksec-fpr9k-1-1-3.cisco.com
Interface de evento	Nenhum

Cisco Firepower Three Cluster Information Settings	at Defense - Config	uration 🖭 🗵 Agreement
Pagistration Kau	2	_
Registration Rey:	•••••	
Password:		
Firepower Management Center IP:	10.62.148.73	
Search domains:	cisco.com	
Firewall Mode:	Routed	~
DNS Servers:	173.38.200.100	
Fully Qualified Hostname:	ksec-fpr9k-1-1-3.cisco.co	m
Eventing Interface:	None	~
	ОК	Cancel

Configure a guia Interface Information FTD com essas configurações e conforme mostrado na imagem.

Tipo de endereço Módulo de segurança 1	Somente IPv4
IP de gerenciamento	10.62.148.67
Máscara de rede	255.255.255.128
Gateway	10.62.148.1
Módulo de segurança 2	
IP de gerenciamento	10.62.148.68
Máscara de rede	255.255.255.128
Gateway	10.62.148.1
Módulo de segurança 3	
IP de gerenciamento	10.62.148.69
Máscara de rede	255.255.255.128
Gateway	10.62.148.1

Cisco Firepower Threat Defense - Configuration			
Cluster Information Settings	Interface Information Agreement		
Address Type:	IPv4 only		
Security Module 1			
Management IP:	10.62.148.67		
Network Mask:	255.255.255.128		
Gateway:	10.62.148.1		
Security Module 2			
Management IP:	10.62.148.68		
Network Mask:	255.255.255.128		
Gateway:	10.62.148.1		
Security Module 3			
Management IP:	10.62.148.69		
Network Mask:	255.255.255.128		
Gateway:	10.62.148.1		
	OK Cancel		

Aceite o Contrato na guia Contrato e clique em OK conforme mostrado na imagem.

Cisco Firepower Threat Defense - Configuration 2 S Cluster Information Settings Interface Information Agreement
End User License Agreement
IMPORTANT: PLEASE READ THIS END USER LICENSE AGREEMENT CAREFULLY. IT IS VERY IMPORTANT THAT YOU CHECK THAT YOU ARE PURCHASING CISCO SOFTWARE OR EQUIPMENT FROM AN APPROVED SOURCE AND THAT YOU, OR THE ENTITY YOU REPRESENT (COLLECTIVELY, THE "CUSTOMER") HAVE BEEN REGISTERED AS THE END USER FOR THE PURPOSES OF THIS CISCO END USER LICENSE AGREEMENT. IF YOU ARE NOT REGISTERED AS THE END USER YOU HAVE NO LICENSE TO USE THE SOFTWARE AND THE LIMITED WARRANTY IN THIS END USER LICENSE AGREEMENT DOES NOT APPLY. ASSUMING YOU HAVE PURCHASED FROM AN APPROVED SOURCE, DOWNLOADING, INSTALLING OR USING CISCO OR CISCO-SUPPLIED SOFTWARE CONSTITUTES ACCEPTANCE OF THIS AGREEMENT.
CISCO SYSTEMS, INC. OR ITS SUBSIDIARY LICENSING THE SOFTWARE INSTEAD OF CISCO SYSTEMS, INC. ("CISCO") IS WILLING TO LICENSE THIS SOFTWARE TO YOU ONLY UPON THE CONDITION THAT YOU PURCHASED THE SOFTWARE
I understand and accept the agreement
OK Cancel

Etapa 3. Atribuir interfaces de dados ao FTD.

Expanda a área de Portas de Dados e clique em cada interface que deseja atribuir ao FTD. Após a conclusão, selecione **Salvar** para criar um cluster FTD como mostrado na imagem.

c	verview Interfaces	Logical Device	Security Modules Pla	tform Settings				System Tools	Help admin
P	rovisioning - FTD_clu Clustered Cisco Firep	uster power Threat Defens	se 6.0.1.1213					Save	Cancel
D	lata Ports								1
	Ethernet1/7								
I,	Ethernet1/8								
IJ	Ethernet2/1								
II,	Ethernet2/2								
Į,	Ethernet2/3	_		Port- channel5					
II.	Ethernet2/4	_1				6			
ŀ	Ethernet3/1					FTD - 6.0	0.1.1213		
ŀ	Ethernet3/2	-1		But.		Security M	odule 1,2,3		
ŀ	Ethernet3/3	-1		channel48					
ŀ	EthernetJy4								
	Port-channels								
2									
	Security Module	Application	Version	Management IP	Gateway	Management Port	Status		
	Security Module 1	FTD	6.0.1.1213	10.62.148.67	10.62.148.1	Ethernet1/1			
	Cluster Interfaces:	Port-channel48							
	Security Module 2	FTD	6.0.1.1213	10.62.148.68	10.62.148.1	Ethernet1/1			
	Cluster Interfaces:	Port-channel48							
۲	Security Module 3	FTD	6.0.1.1213	10.62.148.69	10.62.148.1	Ethernet1/1			
	Cluster Interfaces:	Port-channel48							

Aguarde alguns minutos para que o cluster seja implantado, após os quais a eleição da unidade

Verificação:

• Na GUI do FPR9300, como mostrado na imagem.



• Da CLI FPR9300

FPR9K-1-A# FPR9K-1-A# scope ss FPR9K-1-A /ssa # sh	a ow app-inst	ance			
Application Name	Slot ID	Admin State	Operational State	Running Version	n Startup
Version Cluster Ope	r State				
ftd	1	Enabled	Online	6.0.1.1213	6.0.1.1213
In Cluster					
ftd	2	Enabled	Online	6.0.1.1213	6.0.1.1213
In Cluster					
ftd	3	Enabled	Online	6.0.1.1213	6.0.1.1213
In Cluster					

Da CLI do LINA (ASA)

firepower# show cluster info

Cluster FTD_cluster: On Interface mode: spanned This is "unit-1-1" in state MASTER ID : 0 Version : 9.6(1)Serial No.: FLM19216KK6 CCL IP : 127.2.1.1 CCL MAC : 0015.c500.016f Last join : 21:51:03 CEST Aug 8 2016 Last leave: N/A Other members in the cluster: Unit "unit-1-3" in state SLAVE ID : 1 Version : 9.6(1)Serial No.: FLM19206H7T CCL IP : 127.2.1.3 CCL MAC : 0015.c500.018f Last join : 21:51:05 CEST Aug 8 2016

Last leave: N/A Unit "unit-1-2" in state SLAVE ID : 2 Version : 9.6(1) Serial No.: FLM19206H71 CCL IP : 127.2.1.2 CCL MAC : 0015.c500.019f Last join : 21:51:30 CEST Aug 8 2016 Last leave: N/A firepower# cluster exec show cluster interface-mode cluster interface-mode spanned cluster interface-mode spanned cluster interface-mode spanned firepower# firepower# cluster exec show cluster history _____ To State From State Reason 21:49:25 CEST Aug 8 2016 DISABLED DISABLED Disabled at startup 21:50:18 CEST Aug 8 2016 Enabled from CLI DISABLED ELECTION 21:51:03 CEST Aug 8 2016 ELECTION MASTER_POST_CONFIG Enabled from CLI 21:51:03 CEST Aug 8 2016 MASTER_POST_CONFIG MASTER Master post config done and waiting for ntfy _____ _____ To State From State Reason _____ 21:49:44 CEST Aug 8 2016 DISABLED DISABLED Disabled at startup 21:50:37 CEST Aug 8 2016 DISABLED ELECTION Enabled from CLI 21:50:37 CEST Aug 8 2016 ELECTION ONCALL Received cluster control message 21:50:41 CEST Aug 8 2016 Received cluster control message ONCALL ELECTION 21:50:41 CEST Aug 8 2016 ELECTION ONCALL Received cluster control message 21:50:46 CEST Aug 8 2016 ONCALL ELECTION Received cluster control message

21:50:46 CEST Aug 8 2016 ELECTION ONCALL Received cluster control message 21:50:51 CEST Aug 8 2016 Received cluster control message ONCALL ELECTION 21:50:51 CEST Aug 8 2016 ELECTION Received cluster control message ONCALL 21:50:56 CEST Aug 8 2016 ONCALL ELECTION Received cluster control message 21:50:56 CEST Aug 8 2016 ELECTION Received cluster control message ONCALL 21:51:01 CEST Aug 8 2016 ONCALL ELECTION Received cluster control message 21:51:01 CEST Aug 8 2016 ELECTION ONCALL Received cluster control message 21:51:04 CEST Aug 8 2016 ONCALL SLAVE_COLD Received cluster control message 21:51:04 CEST Aug 8 2016 SLAVE_COLD SLAVE_APP_SYNC Client progression done 21:51:05 CEST Aug 8 2016 SLAVE_CONFIG Slave application configuration sync done SLAVE_APP_SYNC 21:51:17 CEST Aug 8 2016 SLAVE_CONFIG SLAVE_BULK_SYNC Configuration replication finished 21:51:29 CEST Aug 8 2016 SLAVE_BULK_SYNC SLAVE Configuration replication finished _____ _____ From State To State Reason _____ 21:49:24 CEST Aug 8 2016 Disabled at startup DISABLED DISABLED 21:50:16 CEST Aug 8 2016 DISABLED ELECTION Enabled from CLI 21:50:17 CEST Aug 8 2016 ELECTION ONCALL Received cluster control message 21:50:21 CEST Aug 8 2016 ONCALL ELECTION Received cluster control message 21:50:21 CEST Aug 8 2016 Received cluster control message ELECTION ONCALL 21:50:26 CEST Aug 8 2016 ONCALL Received cluster control message ELECTION 21:50:26 CEST Aug 8 2016 ELECTION ONCALL Received cluster control message

21:50:31 CEST Aug 8 2016 Received cluster control message ONCALL ELECTION 21:50:31 CEST Aug 8 2016 ELECTION ONCALL Received cluster control message 21:50:36 CEST Aug 8 2016 Received cluster control message ONCALL ELECTION 21:50:36 CEST Aug 8 2016 ELECTION ONCALL Received cluster control message 21:50:41 CEST Aug 8 2016 ONCALL ELECTION Received cluster control message 21:50:41 CEST Aug 8 2016 ELECTION Received cluster control message ONCALL 21:50:46 CEST Aug 8 2016 ONCALL ELECTION Received cluster control message 21:50:46 CEST Aug 8 2016 ELECTION Received cluster control message ONCALL 21:50:51 CEST Aug 8 2016 Received cluster control message ONCALL ELECTION 21:50:51 CEST Aug 8 2016 ELECTION ONCALL Received cluster control message 21:50:56 CEST Aug 8 2016 Received cluster control message ONCALL ELECTION 21:50:56 CEST Aug 8 2016 ELECTION ONCALL Received cluster control message 21:51:01 CEST Aug 8 2016 ONCALL ELECTION Received cluster control message 21:51:01 CEST Aug 8 2016 ELECTION ONCALL Received cluster control message 21:51:06 CEST Aug 8 2016 ONCALL ELECTION Received cluster control message 21:51:06 CEST Aug 8 2016 ELECTION ONCALL Received cluster control message 21:51:12 CEST Aug 8 2016 ONCALL ELECTION Received cluster control message 21:51:12 CEST Aug 8 2016 ELECTION ONCALL Received cluster control message 21:51:17 CEST Aug 8 2016 ONCALL Received cluster control message ELECTION 21:51:17 CEST Aug 8 2016 ELECTION ONCALL Received cluster control message 21:51:22 CEST Aug 8 2016 ONCALL ELECTION Received cluster control message

21:51:22 CEST Aug 8 2016

```
ELECTION
                 ONCALL
                                   Received cluster control message
21:51:27 CEST Aug 8 2016
                ELECTION
                            Received cluster control message
ONCALL
21:51:27 CEST Aug 8 2016
                           Received cluster control message
ELECTION
                 ONCALL
21:51:30 CEST Aug 8 2016
ONCALL
                SLAVE_COLD Received cluster control message
21:51:30 CEST Aug 8 2016
                SLAVE_APP_SYNC
SLAVE_COLD
                                  Client progression done
21:51:31 CEST Aug 8 2016
SLAVE_APP_SYNC SLAVE_CONFIG Slave application configuration sync done
21:51:43 CEST Aug 8 2016
SLAVE_CONFIG
                SLAVE_BULK_SYNC Configuration replication finished
21:51:55 CEST Aug 8 2016
SLAVE_BULK_SYNC SLAVE
                                     Configuration replication finished
```

firepower#

Tarefa 3. Registrar cluster FTD no FMC

Requisito de tarefa:

Adicione os dispositivos lógicos ao FMC e agrupe-os em um cluster.

Solução:

Etapa 1. Adicione dispositivos lógicos ao FMC. A partir da versão 6.3 do FMC, você deve registrar apenas um dispositivo FTD (recomendado para ser o mestre). O resto dos DTFs são descobertos automaticamente pelo CVP.

Efetue login no FMC e navegue até a guia **Devices > Device Management** e clique em **Add Device**.

Adicione o primeiro dispositivo lógico com as configurações mencionadas na imagem.

Clique em Registrar para iniciar o registro.

Add Device		?)	×
Host:	10.62.148.67		
Display Name:	FTD1		
Registration Key:	cisco		
Group:	None	~	
Access Control Policy:	FTD9300	~	
Smart Licensing Malware:			
URL Filtering:			
 Advanced On version 5.4 devi specified from licensing 	ces or earlier, the licensing options will need to page.	be	
	Register Cano	el	

A verificação é como mostrado na imagem.

Cisco Firepower 9000 Series SM-36 Threat Defense Cluster			/ 8
FTD1(primary) 10.62.148.67 - Cisco Firepower 9000 Series SM-36 Threat Defense - v6.0.1 - routed	Cisco Firepower 9000 Series SM-36 Thre Base, Threat, Malware, URL Filtering	FTD9300	
PTD2 10.62.148.68 - Cisco Firepower 9000 Series SM-36 Threat Defense - v6.0.1 - routed	Cisco Firepower 9000 Series SM-36 Thre Base, Threat, Malware, URL Filtering	FTD9300	i
FTD3 10.62.148.69 - Cisco Firepower 9000 Series SM-36 Threat Defense - v6.0.1 - routed	Cisco Firepower 9000 Series SM-36 Thre Base, Threat, Malware, URL Filtering	FTD9300	8

Tarefa 4. Configurar subinterfaces de canal de porta no FMC

Requisito de tarefa:

Configure subinterfaces para a interface Dados do canal de porta.

Solução:

Etapa 1. Na GUI do FMC, selecione o botão FTD_cluster Edit.

Navegue até a guia Interfaces (Interfaces) e clique em Add Interfaces > Sub Interface (Adicionar interfaces), conforme mostrado na imagem.

Overview Analysis Policies Devices Objects AMP		Deploy 🌒 System Help 🔻 olga 🕶
Device Management NAT VPN Platform Settings		
FTD_cluster		Seve Seve
Cisco Firepower 9000 Series SM-36 Threat Defense		
Cluster Devices Routing NAT Interfaces Inline Sets	DHCP	
2		Add Interfaces •
Interface Logical Name	Type Security Zone Mac Address(Active/Standby)	IP Address Sub Interface
📆 Port-channel5	EtherChannel	1
Port-channel48	EtherChannel	۹.
Ethernet1/1 diagnostic	Physical	1

Configure a primeira subinterface com esses detalhes. Selecione **OK** para aplicar as alterações e conforme mostrado nas imagens.

Nome	Interna
guia Geral	
Interface	Canal de porta 5
ID da subinterface	201
ID da VLAN	201
guia IPv4	
Tipo de IP	Usar IP estático
IP Address	192.168.75.10/24

Add Sub Interface			? ×
Name: Inside	Enabled	Management Only	
Security Zone:	~	-	
Description:			
General IPv4 IPv6	Advanced		
MTU:	1500	(64 - 9000)	
Interface *:	Port-channel5	🗹 Enabled	
Sub-Interface ID *:	201	(1 - 4294967295)	
VLAN ID:	201	(1 - 4094)	
			OK Cancel

Add Sub Interfac	e ? ×	
Name: Insid	de Catalog Management Only	
Security Zone:	~	
Description:		
General IPv4 I	Pv6 Advanced	
IP Type:	Use Static IP	
IP Address:	eg. 1.1.1.1/255.255.255.228 or 1.1.1.1/25	
	OK Cancel	

Configure a segunda subinterface com esses detalhes.

Nome	Externa
guia Geral	
Interface	Canal de porta 5
ID da subinterface	210
ID da VLAN	210
guia IPv4	
Tipo de IP	Usar IP estático
IP Address	192.168.76.10/24

Clique em **OK** para criar a subinterface. Clique em **Salvar** e em **Implantar** alterações no FTD_cluster, como mostrado na imagem.

Verificação:

Overview Analysis Policies Devices Objects AMP		Deploy 🍳 System Help 🔻 olga 🔻					
Device Management NAT VPN Platform Settings							
FTD cluster							
Cisco Firepower 9000 Series SM-36 Threat Defense							
Cluster Devices Routing NAT Interfaces Inline Sets	DHCP						
3		Add Interfaces •					
Interface Logical Name	Type Security Zone Mac Address(Active/Standby)	IP Address					
Port-channel5	EtherChannel	/					
Port-channel48	EtherChannel	۹,					
Ethernet1/1 diagnostic	Physical	1					
Port-channel5.201 Inside	SubInterface	192.168.75.10/24(Static)					
Port-channel5.210 Outside	SubInterface	192.168.76.10/24(Static)					

Tarefa 5. Verificar a conectividade básica

Requisito de tarefa:

Crie uma captura e verifique a conectividade entre duas VMs.

Solução:

Etapa 1. Criar capturas em todas as unidades de cluster.

Navegue até LINA (ASA) CLI da unidade Master e crie capturas para as interfaces interna e externa.

```
firepower#
firepower# cluster exec capture capi interface inside match icmp any any
firepower#
firepower# cluster exec capture capo interface outside match icmp any any
firepower#
Verificação:
firepower# cluster exec show capture
capture capi type raw-data interface Inside [Capturing - 0 bytes]
match icmp any any
capture capo type raw-data interface Outside [Capturing - 0 bytes]
match icmp any any
```

capture capi type raw-data interface Inside [Capturing - 0 bytes]

match icmp any any capture capo type raw-data interface Outside [Capturing - 0 bytes] match icmp any any

Etapa 2. Execute o teste de ping da VM1 para a VM2.

Faça o teste com 4 pacotes. Verifique a saída da captura após o teste:

firepower# cluster exec show capture capture capi type raw-data interface Inside [Capturing - 0 bytes] match icmp any any capture capo type raw-data interface Outside [Capturing - 0 bytes] match icmp any any capture capi type raw-data interface Inside [Capturing - 752 bytes] match icmp any any capture capo type raw-data interface Outside [Capturing - 752 bytes] match icmp any any capture capi type raw-data interface Inside [Capturing - 0 bytes] match icmp any any capture capo type raw-data interface Outside [Capturing - 0 bytes] match icmp any any

firepower#

Execute o comando para verificar a saída da captura na unidade específica:

firepower# cluster exec unit unit-1-3 show capture capi

8 packets captured

1: 12:58:36.162253 802.1Q vlan#201 P0 192.168.75.100 > 192.168.76.100: icmp: echo request 2: 12:58:36.162955 802.10 vlan#201 P0 192.168.76.100 > 192.168.75.100: icmp: echo reply 3: 12:58:37.173834 802.10 vlan#201 P0 192.168.75.100 > 192.168.76.100: icmp: echo request 802.1Q vlan#201 P0 192.168.76.100 > 192.168.75.100: icmp: echo reply 802.1Q vlan#201 P0 192.168.75.100 > 192.168.76.100: icmp: echo 4: 12:58:37.174368 5: 12:58:38.187642 request 802.10 vlan#201 P0 192.168.76.100 > 192.168.75.100: icmp: echo reply 6: 12:58:38.188115 7: 12:58:39.201832 802.1Q vlan#201 P0 192.168.75.100 > 192.168.76.100: icmp: echo request 8: 12:58:39.202321 802.1Q vlan#201 P0 192.168.76.100 > 192.168.75.100: icmp: echo reply 8 packets shown

firepower# cluster exec unit unit-1-3 show capture capo

8 packets captured

1: 12:58:36.162543	802.1Q vlan#210	ΡO	192.168.75.100	>	192.168.76.100:	icmp:	echo	
request								
2: 12:58:36.162894	802.1Q vlan#210	PO	192.168.76.100	>	192.168.75.100:	icmp:	echo	reply
3: 12:58:37.174002	802.1Q vlan#210	PO	192.168.75.100	>	192.168.76.100:	icmp:	echo	
request								
4: 12:58:37.174307	802.1Q vlan#210	PO	192.168.76.100	>	192.168.75.100:	icmp:	echo	reply
5: 12:58:38.187764	802.1Q vlan#210	PO	192.168.75.100	>	192.168.76.100:	icmp:	echo	
request								
6: 12:58:38.188085	802.1Q vlan#210	PO	192.168.76.100	>	192.168.75.100:	icmp:	echo	reply
7: 12:58:39.201954	802.1Q vlan#210	PO	192.168.75.100	>	192.168.76.100:	icmp:	echo	
request								
8: 12:58:39.202290	802.1Q vlan#210	PO	192.168.76.100	>	192.168.75.100:	icmp:	echo	reply
8 packets shown								
firepower#								
And a second day and a family								

Após concluir esta tarefa, exclua as capturas com o próximo comando:

Crie novas capturas com estes:

Verifique a saída show conn:

 TCP Outside
 192.168.76.100:49175 Inside
 192.168.75.100:21, idle 0:00:34, bytes 0, flags y

 TCP cluster
 127.2.1.1:10851 NP Identity Ifc
 127.2.1.3:48493, idle 0:00:52, bytes 224, flags UI

 TCP cluster
 127.2.1.1:64070 NP Identity Ifc
 127.2.1.3:10847, idle 0:00:11, bytes 806, flags UO

TCP cluster 127.2.1.1:10851 NP Identity Ifc 127.2.1.2:64136, idle 0:00:53, bytes 224, flags UI

Mostrar saída da captura:

Captura de cluster da IU do Gestor de Chassi

Na imagem a seguir, você pode ver um cluster de 3 unidades no FPR9300 com 2 canais de porta (8 e 48). Os dispositivos lógicos são ASAs, mas no caso do FTD será o mesmo conceito.O importante a ser lembrado é que, embora existam **3 unidades de cluster**, do ponto de vista da captura há apenas **um dispositivo lógico**:

0	verview	Interfaces	Logical Devices	Security Mod	dules Platform Setti	ings		Syst	tem Tools Help admin
Lo	gical De	vice List						c	Refresh 🕢 Add Device
	ASA	(Clustered	Status:ok					F. 2 E •
I	Secur	ity Module	Application	Version	Management IP	Gateway	Management Port	Status	
G	Securi	ty Module 1	ASA	9.6.2.7	0.0.0.0	0.0.0.0	Ethernet1/1	🕜 online	🕶 💱
	Por	ts: ata Interfaces: luster Interfaces:	Port-channel8 Port-channel48	A	Attributes: Cluster Operational Status Management IP VIRTUAL Cluster Role Management URL Management IP	s: in-cluster : 10.111.8.206 : master : https://10.111.8.206/ : 10.111.8.193			
G	Securi	ty Module 2	ASA	9.6.2.7	0.0.0.0	0.0.0.0	Ethernet1/1	🕜 online	🕶 🏂
	Por D C	ts: ata Interfaces: luster Interfaces:	Port-channel8 Port-channel48	A	tttributes: Cluster Operational Status Management IP VIRTUAL Cluster Role Management URL Management IP	s: in-cluster : 10.111.8.206 : slave : https://10.111.8.206/ : 10.111.8.189			
G	Securi	ty Module 3	ASA	9.6.2.7	0.0.0.0	0.0.0.0	Ethernet1/1	🕜 online	🕶 💱
	Por	ts: ata Interfaces: luster Interfaces:	Port-channel8 Port-channel48	A	Attributes: Cluster Operational Status Management IP VIRTUAL Cluster Role Management URL Management IP	s: in-cluster : 10.111.8.206 : slave : https://10.111.8.206/ : 10.111.8.190			

Tarefa 6. Excluir um dispositivo escravo do cluster

Requisito de tarefa:

Efetue login no FMC e exclua a unidade Slave do cluster.

Solução:

Etapa 1. Faça login no FMC e navegue até **Device > Device Management (Dispositivo > Gerenciamento de dispositivos)**.

Clique no ícone de lixo ao lado da unidade de escravos, como mostrado na imagem.

ETD_cluster Cisco Firepower 9000 Series SM-36 Threat Defense Cluster			28
FTD1(primary) 10.62.148.67 - Cisco Firepower 9000 Series SM-36 Threat Defense - v6.0.1 - routed	Cisco Firepower 9000 Series SM-36 Thre Base, Threat, Malware, URL Filtering	FTD9300	~
FTD2 10.62.148.68 - Cisco Firepower 9000 Series SM-36 Threat Defense - v6.0.1 - routed	Cisco Firepower 9000 Series SM-36 Thre Base, Threat, Malware, URL Filtering	FTD9300	8
PTD3 10.62.148.69 - Cisco Firepower 9000 Series SM-36 Threat Defense - v6.0.1 - routed	Cisco Firepower 9000 Series SM-36 Thre Base, Threat, Malware, URL Filtering	FTD9300	8

A janela de confirmação é exibida. Selecione **Sim** para confirmar como mostrado na imagem.



Verificação:

Do FMC, como mostrado na imagem.

- 6	FTD_cluster Cisco Firepower 9000 Series SM-36 Threat Defense Cluster	0	9
	FD1(primary) 10.62.148.67 - Cisco Tirepower 9000 Series SM-36 Threat Defense - v6.0.1 - routed Cisco Firepower 9000 Series SM-36 Threat, Malware, URL Filtering FTD9300		
	FTD3 10.62.148.69 - Cisco Firepower 9000 Series SM-36 Threat Defense - v6.0.1 - routed Cisco Firepower 9000 Series SM-36 Threat, Malware, URL Filtering FTD9300	8	

• Da CLI do FXOS.

FPR9K-1-A# scope ssa								
FPR9K-1-A /ssa # show app-instance								
Application Name	Slot ID	Admin State	Operational State	Running Versior	ı Startup			
Version Cluster Ope	er State							
ftd	1	Enabled	Online	6.0.1.1213	6.0.1.1213			
In Cluster								
ftd	2	Enabled	Online	6.0.1.1213	6.0.1.1213			
In Cluster								
ftd	3	Enabled	Online	6.0.1.1213	6.0.1.1213			
In Cluster								

• Na CLI do LINA (ASA).

```
firepower# show cluster info
Cluster FTD_cluster: On
   Interface mode: spanned
   This is "unit-1-1" in state MASTER
                : 0
       ID
       Version : 9.6(1)
       Serial No.: FLM19216KK6
       CCL IP : 127.2.1.1
       CCL MAC : 0015.c500.016f
       Last join : 21:51:03 CEST Aug 8 2016
       Last leave: N/A
Other members in the cluster:
   Unit "unit-1-3" in state SLAVE
       ID
                 : 1
       Version : 9.6(1)
       Serial No.: FLM19206H7T
       CCL IP
                : 127.2.1.3
       CCL MAC : 0015.c500.018f
       Last join : 21:51:05 CEST Aug 8 2016
       Last leave: N/A
   Unit "unit-1-2" in state SLAVE
       ID
                : 2
       Version : 9.6(1)
       Serial No.: FLM19206H71
       CCL IP : 127.2.1.2
       CCL MAC : 0015.c500.019f
```

```
Last join : 21:51:30 CEST Aug 8 2016
Last leave: N/A
firepower#
```

Note: O dispositivo não foi registrado no FMC, mas ainda é um membro do cluster no FPR9300.

Verificar

Use esta seção para confirmar se a sua configuração funciona corretamente.

A verificação é concluída e abordada em tarefas individuais.

Troubleshoot

Atualmente, não existem informações disponíveis específicas sobre Troubleshooting para esta configuração.

Informações Relacionadas

• Todas as versões do guia de configuração do Cisco Firepower Management Center podem ser encontradas aqui:

https://www.cisco.com/c/en/us/td/docs/security/firepower/roadmap/firepower-roadmap.html#id_47280.

 Todas as versões dos guias de configuração do FXOS Chassis Manager e CLI podem ser encontradas aqui:

https://www.cisco.com/c/en/us/td/docs/security/firepower/fxos/roadmap/fxos-roadmap.html#pgfld-121950.

 O Cisco Global Technical Assistance Center (TAC) recomenda enfaticamente este guia visual para um conhecimento prático profundo sobre as tecnologias de segurança de próxima geração do Cisco Firepower, incluindo as mencionadas neste artigo:

http://www.ciscopress.com/title/9781587144806.

 Para todas as Notas técnicas de configuração e solução de problemas referentes às tecnologias Firepower.

https://www.cisco.com/c/en/us/support/security/defense-center/tsd-products-support-serieshome.html.

<u>Suporte Técnico e Documentação - Cisco Systems</u>