Prime基础设施与ACS 4.2 TACACS集成配置示例

目录

<u>简介</u> <u>先决条件</u> <u>要求</u> 使用的组件 配置 配置 <u>在PI中将ACS添加为TACACS服务器</u> <u>PI中的AAA模式设置</u> <u>从PI检索用户角色属性</u> 配置ACS 4.2 验证 故障排除

简介

本文档介绍终端访问控制器访问控制系统(TACACS+)的配置示例

对Cisco Prime基础设施(PI)应用的身份验证和授权。

先决条件

要求

Cisco 建议您了解以下主题:

- •在访问控制服务器(ACS)中将PI定义为客户端
- 在ACS和PI上定义IP地址和相同的共享密钥

使用的组件

本文档中的信息基于以下软件和硬件版本:

• ACS版本4.2

• Prime基础设施版本3.0

本文档中的信息都是基于特定实验室环境中的设备编写的。本文档中使用的所有设备最初均采用原 始(默认)配置。如果您使用的是真实网络,请确保您已经了解所有命令的潜在影响。

配置

配置

在PI中将ACS添加为TACACS服务器

要将ACS添加为TACACS服务器,请完成以下步骤:

步骤1.导航至 管理 > 用户 > 用户、角色和AAA 在PI中

步骤2.从左侧栏菜单中,选择TACACS+ Servers,在Add TACACS+ servers 下单击Go,然后显示 页面,如图所示:

Administration / Users / U	Jsers, Roles & AAA 🔺				
AAA Mode Settings	Add TACACS+ Server				
Active Sessions	O [★] IP Address				
Change Password	○* DNS Name				
Local Password Policy	* Port	49			
RADIUS Servers	Shared Secret Format	ASCII	•		
SSO Server Settings	* Shared Secret				?
SSO Servers	* Confirm Shared Secret				
TACACS+ Servers	* Retransmit Timeout	5	(secs)		
User Groups	* Retries	1			
Users	Authentication Type	PAP	•		
	Local Interface IP	10.106.	68.130	•	
	Save Cancel				

步骤3.添加ACS服务器的IP地址。

步骤4.输入在ACS服务器中配置的TACACS+共享密钥。

步骤5.在"确认共享密钥"文本框中重新输入共享密钥。

步骤6.将其余字段保留为默认设置。

步骤7.单击"提**交"**。

PI中的AAA模式设置

要选择身份验证、授权和记帐(AAA)模式,请完成以下步骤:

步骤1.导航至Administration > AAA。

步骤2.从左侧**栏菜单**中选择AAA模式,您可以看到该页面,如图所示:

E	e vilvelle Prime Infrastructure					
ſ	Administration / Users / U	Jsers, Roles & AAA 🔺				
	AAA Mode Settings	AAA Mode Settings				
	Active Sessions	AAA Mode 🔇				
	Change Password	Enable fallback to Local	ONLY on no server respons			
	Local Password Policy					
	RADIUS Servers	Save				
	SSO Server Settings					
	SSO Servers					
	TACACS+ Servers					
	User Groups					
	Users					

步骤3.选择TACACS+。

步骤4.如果希望管理员在ACS**服务器无法访问时使**用本地数据库,请选中启用回退到本地方框。这 是建议的设置。

从PI检索用户角色属性

步骤1.导航至Administration > AAA > User Groups。此示例显示管理员身份验证。在列表中**查找** Admin Group Name,然后单击右**侧的T**ask List选项,如图所示:

😑 "luulu" Prime Infrastructure			Q ▼ Application Search	root - ROOT-DOMA	AIN 🎝
Administration / Users / U	Users, Roles & AAA 🔺			(00
AAA Mode Settings	User Groups				
Active Sessions	Group Name	Members	Audit Trail	View Task	
Change Password	Admin	virtual	6	Task List	
Local Password Policy	Config Managers		8	Task List	
RADIUS Servers	Lobby Ambassador			Task List	
SSO Server Settings	Monitor Lite			Task List	
	NBI Credential			Task List	
SSO Servers	NBI Read			Task List	
TACACS+ Servers	NBI Write		8	Task List	
User Groups	North Bound API			Task List	
Users	Root	root	8	Task List	
	Super Users			Task List	
	System Monitoring	virtual		Task List	

单击"任务**列表"**选项后,将出现窗口,如图所示:

Task List	
Please copy and paste the appropriate protocol data below into the custom/ve	ndor-specific attribute field in your AAA server.
TACACS+ Custom Attributes	RADIUS Custom Attributes
	If the size of the RADIUS attributes on your AAA server is more than 4096 bytes, Please copy ONLY role
	retrieve the associated TASKS
role0=Admin	NCS:role0=Admin
task0=View Alerts and Events	NCS:task0=View Alerts and Events
task1=Run Job	NCS:task1=Run Job
task2=Device Reports	NCS:task2=Device Reports
task3=Alarm Stat Panel Access	NCS:task3=Alarm Stat Panel Access
task4=RADIUS Servers	NCS:task4=RADIUS Servers
task5=Raw NetFlow Reports	NCS:task5=Raw NetFlow Reports
task6=Credential Profile Delete Access	NCS:task6=Credential Profile Delete Access
task7=Compliance Audit Fix Access	NCS:task7=Compliance Audit Fix Access
task8=Network Summary Reports	NCS:task8=Network Summary Reports
task9=Discovery View Privilege	NCS:task9=Discovery View Privilege
task10=Configure ACS View Servers	NCS:task10=Configure ACS View Servers
task11=Run Reports List	NCS:task11=Run Reports List
task12=View CAS Notifications Only	NCS:task12=View CAS Notifications Only
task13=Administration Menu Access	NCS:task13=Administration Menu Access
task14=Monitor Clients	NCS:task14=Monitor Clients
task15=Configure Guest Users	NCS:task15=Configure Guest Users
task16=Monitor Media Streams	NCS:task16=Monitor Media Streams
task17=Configure Lightweight Access Point	NCS:task17=Configure Lightweight Access Point
Templates	Templates
task18=Monitor Chokepoints	NCS:task18=Monitor Chokepoints
task19=Maps Read Write	NCS:task19=Maps Read Write
task20=Administrative privileges under Manage and	NCS:task20=Administrative privileges under Manage

步骤2.复制这些属性并将其保存在记事本文件中。

步骤3.您可能需要在ACS服务器中添加自定义虚拟域属性。自定义虚拟域属性位于同一任务列表页 面的底部。

O Virtual Domain custom attributes are mandatory. To add custom attributes related to Virtual Domains, please click here.

步骤4.单击**此处**选项可获取"虚拟域"属性页,您可以看到该页,如图所示:

TACACS+ Custom Attributes	RADIUS Custom Attributes			
virtual-domain0=ROOT-DOMAIN virtual-domain1=test1	NCS:virtual-domain0=ROOT-DOMAIN NCS:virtual-domain1=test1	NCS:virtual-domain0=ROOT-DOMAIN NCS:virtual-domain1=test1		
		10		

配置ACS 4.2

步骤1.登录ACS Admin GUI, 然后导航至Interface Configuration > TACACS+页面。

步骤2.为prime创建新服务。此示例显示了使用名称NCS配置的服务名称,如图所示:

New	Services		
		Service	Protocol
		ciscowlc	common
		Wireless-WCS	НТТР
		NCS	НТТР

步骤3.将步骤2中创建的记事本中的所有属性添加到用户或组配置。确保添加虚拟域属性。

NCS HTTP



步骤4.单击"确**定"。**

验证

使用您创建的新用户名登录到Prime,并确认您具有管理角色。

故障排除

本部分提供了可用于对配置进行故障排除的信息。

从/opt/CSCOlumos/logs目录中提供的prime root CLI查**看usermgmt.log**。检查是否存在任何错误消息。

2016-05-12 15:24:18,517 [http-bio-443-exec-10] DEBUG usermgmt - [[TacacsLoginModule] Primary server=172.18.70.243:49] 2016-05-12 15:24:18,517 [http-bio-443-exec-10] DEBUG usermgmt - Thread Id : [835], Entering Method : [login], Class : [com.cisco.xmp.jaas.tacacs.TacacsLoginClient]. 2016-05-12 15:24:18,517 [http-bio-443-exec-10] DEBUG usermgmt - Thread Id : [835], Entering Method : [login], Class : [com.cisco.xmp.jaas.tacacs.SecondaryTacacsLoginClient]. 2016-05-12 15:24:18,518 [http-bio-443-exec-10] INFO usermgmt - [Tacacs:connectTacacs()] : [prepare to ping TACACS+ server (> 0):/172.18.70.243 (-1)]. 2016-05-12 15:24:18,619 [http-bio-443-exec-10] INFO usermgmt - [Tacacs:connectTacacs()] : [Tacacs: Num of ACS is 3]. 2016-05-12 15:24:18,619 [http-bio-443-exec-10] INFO usermgmt - [Tacacs:connectTacacs()] : [Tacacs:activeACSIndex is 0]. 2016-05-12 15:24:18,619 [http-bio-443-exec-10] INFO usermgmt - [Tacacs:connectTacacs()] : [Tacacs: Unable to connect to Server 2: /172.18.70.243 Reason: Connection refused]. 2016-05-12 15:24:18,619 [http-bio-443-exec-10] DEBUG usermgmt - [[Thu May 12 15:24:18 EST 2016] [TacacsLoginModule] exception in client.login(primaryServer, primaryPort, seconda..: com.cisco.xmp.jaas.XmpAuthenticationServerException: Server Not Reachable: Connection refused] 此示例显示错误消息的示例,可能是由于各种原因(如防火墙或任何中间设备拒绝连接等)。