基于下一代加密(NGE)的CUCM和CUC之间安全 SIP集成配置示例

目录

简介 先决条件 要求 网络图 证书要求 协商的基于RSA密钥的密码 基于EC密钥的密码协商 配置— Cisco Unity Connection(CUC) 1.添加新端口组 2.添加TFTP服务器参考 3.添加语音信箱端口 4.上传第三方CA的CUCM根和中间证书 配置— Cisco Unified CM(CUCM) 1.创建SIP中继安全配置文件 2.创建安全SIP中继 3.配置TLS和SRTP密码 4.上传CUC Tomcat证书(基于RSA和EC) 5.创建路由模式 6.创建语音邮件引导、语音邮件配置文件并将其分配给DN 配置 — 由第三方CA对基于EC密钥的证书进行签名(可选) 验证 安全SIP中继验证 安全RTP呼叫验证 相关信息

简介

本文档介绍使用下一代加密的Cisco Unified Communication Manager(CUCM)和Cisco Unity Connection(CUC)服务器之间安全SIP连接的配置和验证。

下一代SIP安全接口限制SIP接口使用基于TLS 1.2、SHA-2和AES256协议的套件B密码。它允许根据RSA或ECDSA密码的优先级顺序进行各种密码组合。在Unity Connection与Cisco Unified CM之间的通信过程中,密码和第三方证书在两端都经过验证。以下是下一代加密支持的配置。

如果您计划使用由第三方证书颁发机构签名的证书,则从配置部分末尾的证书签名开始(配置 — 由 第三方CA签名基于EC密钥的证书)

先决条件

要求

本文档中的信息基于以下软件和硬件版本:

CUCM 11.0版及更高版本(混合模式) CUC版本11.0及更高版本

本文档中的信息都是基于特定实验室环境中的设备编写的。本文档中使用的所有设备最初均采用原 始(默认)配置。如果您使用的是真实网络,请确保您已经了解所有命令的潜在影响。

网络图

此图简要说明了在启用下一代加密支持后帮助在CUCM和CUC之间建立安全连接的过程:





在Cisco Unity Connection上启用下一代加密支持后,这些是证书交换要求。

• 协商的基于RSA密钥的	密码		
使用的CUCM证书	使用的CUC证书	上传到CUCM的证书	要上传
CallManager.pem(自签名)	Tomcat.pem(自签名)	要上传到CUCM > CallManger-trust的	无.
	一 () , , , , , , , , , , , , , , , , , ,	CUC根和中间CA证 ^{书*1} 要上传到CUCM>	СИСМ
CallManager.pem(CA签名)	Iomcat.pem(CA签名)	CallManager-trust	CallMa
CallManager.pem(CA签名)	Tomcat.pem(自签名)	要上传到CUCM > CallManger-trust的	要上传
	_ · · · · · · · · · · · · · · · · · · ·	iomcat.pem 要上传到CUCM>CallManager-trust的	和中间
CallManager.pem(自签名)	Tomcat.pem(CA签名)	CUC根和中间CA证书	尢.

^{*1} CUC根和中间CA证书是指签署Unity connection Tomcat证书(Tomcat.pem)的CA证书。

^{*2} CUCM根和中间CA证书是指签署CUCM CallManager证书(Callmanager.pem)的CA证书。

•基于EC密钥的密码协商			
使用的CUCM证书	使用的CUC证书	上传到CUCM的证书	要上传到CUC的证书
CallManager- ECDSA.pem(自签名)	Tomcat-ECDSA .pem(自签名)	要上传到CUCM > CallManger-trust的 Tomcat-ECDSA.pem	无.
CallManager- ECDSA.pem(CA签名)	Tomcat- ECDSA.pem(CA签名)	CUC根和中间CA证 ^书 ^{*1} 要上传到CUCM> CallManager-trust	CUCM根和中间 CA证 ^{书*2} 要上传到 CUC > CallManager- trust。
CallManager- ECDSA.pem(CA签名)	Tomcat-ECDSA .pem(自签名)	要上传到CUCM > CallManger-trust的 Tomcat- ECDSA.pem。 要上传到CUCM >	要上传到CUC> CallManager-trust的 CUCM根和中间 CA证书。
CallManager-ECDSA .pem(自签名)	Tomcat- ECDSA.pem(CA签名)	g_⊥1g 到CUCM CallManager-trust的 CUC根和中间CA证 书	无.

^{*1 CUC}根和中间CA证书是指签署基于Unity连接EC的Tomcat证书(Tomcat-ECDSA.pem)的CA证书。

*2 CUCM根和中间CA证书是指签署CUCM CallManager证书(CallManager-ECDSA.pem)的CA证书。

1. **注意:**在CUC的11.0.1版本中,Tomcat-ECDSA.pem证书称为CallManager-ECDSA.pem。从 CUC 11.5.x,证书已重命名为Tomcat-ECDSA.pem。

配置— Cisco Unity Connection(CUC)

1.添加新端口组

导航至Cisco Unity Connection Administration页面> Telephony integration > Port group,然后点击 Add New。确保选中启用下一代加密复选框。

New Port Group		
Phone System Pho	neSystem 🔻	
Create From 💿	Port Group Type SIP	
0	Port Group PhoneSystem-1 V	
Port Group Descr	iption	
Display Name*	PhoneSystem-2	
Authenticate with SIP Server Authentication Username		
Authentication Password		
Contact Line Name		
SIP Security Profile 5061/TLS V		
 Enable Next Generation Encryption Secure RTP 		
Primary Server Settings		
IPv4 Address or Host Name 10.48.47.109		
IPv6 Address or Host Name		
Port	5061	

1. **注**意:一旦启用Enable Next Generation Encryption复选框,Unity Connection的Cisco Tomcat证书将在SSL握手期间使用。

> ·在协商基于ECDSA的密码时,SSL握手中使用基于EC密钥的tomcat-ECDSA证书。 ·如果协商基于RSA的密码,则在SSL握手中使用基于RSA密钥的tomcat证书。

2.添加TFTP服务器参考

在Port Group Basics页面,导航至Edit > Servers,然后添加CUCM集群的TFTP服务器的FQDN。 TFTP服务器的FQDN/主机名必须与CallManager证书的公用名(CN)匹配。服务器的IP地址将无法工 作,并且会导致无法下载ITL文件。因此,DNS名称必须可通过配置的DNS服务器解析。

SIP Servers			
Delete Selected Add			
Order	IPv4 Addre	ess or Host Name	
0	10.48.47.109		
Delete Selected Add			
TFTP Servers			
Delete Selected Add			
Order		IPv4 Address or Host Name	
0	CUCMv11		
Delete Selected Add			

导航至Cisco Unity Connection Serviceability > Tools > Service Management,在每个节点上重新 启动Connection Conversation Manager。这是配置生效的必需条件。

 注意:Unity Connection使用安全6972端口上的https协议从CUCM的TFTP下载ITL文件 (ITLfile.tlv)(URL:https://<CUCM-TFTP-FQDN>:6972/ITLFile.tlv)。CUCM必须处于混合模式 ,因为CUC正在从ITL文件中查找"CCM+TFTP"功能证书。

导航回Telephony integration > Port group > Port Group Basics配置页面并重置新添加的端口组。

Port Group			
Display Name*	PhoneSystem-1		±.
Integration Method	SIP		
Reset Status	Reset Required	Reset	
Session Initiation	Protocol (SIP) Settings		
Register with SI	P Server		
Authenticate wit	h SIP Server		

1. **注意:**每次重置端口组时,CUC服务器将通过连接到CUCM服务器更新其本地存储的ITL文件 。

3.添加语音信箱端口

导航回Telephony integration > Port,然后点击Add new,将端口添加到新创建的端口组。

New Phone System Port		
Enabled		
Number of Ports	10	
Phone System	PhoneSystem V	
Port Group	PhoneSystem-1 V	
Server	cucv11 V	
Port Behavior		
🗹 Answer Calls		
Perform Message Notification		
Send MWI Requests (may also be disabled by the port group)		
Allow TRAP C	onnections	

4.上传第三方CA的CUCM根和中间证书

如果是第三方证书,则必须在Unity Connection的CallManager信任上上传第三方证书颁发机构的根 证书和中间证书。仅当第3方CA为Call Manager证书签名时,才需要此设置。导航至Cisco Unified OS Administration > Security > Certificate Management,然后点击Upload Certificate,执行此操作 。

Upload Certificate/Certificate	chain
Certificate Purpose*	CallManager-trust 🗸
Description(friendly name)	
Upload File	Choose File CA_root4096_key.crt
Upload Close	

配置— Cisco Unified CM(CUCM)

1.创建SIP中继安全配置文件

导航至CUCM管理>System >安全> SIP中继安全配置文件并添加新配置文件。X.509主题名称必须 与CUC服务器的FQDN匹配。

-SIP Trunk Security Profile Information		
Name*	cuc-secure-profile-EDCS	
Description		
Device Security Mode	Encrypted 🔻	
Incoming Transport Type*	TLS	
Outgoing Transport Type	TLS	
Enable Digest Authentication		
Nonce Validity Time (mins)*	600	
X.509 Subject Name	CUCv11	
Incoming Port*	5061	
Enable Application level authorization		
Accept presence subscription		
Accept out-of-dialog refer**		
Accept unsolicited notification		
Accept replaces header		
Transmit security status		
Allow charging header		

1. **注**意:CLI命令"show cert own tomcat/tomcat.pem"可在Unity Connection上显示基于RSA密钥的tomcat证书。CN必须与CUCM上配置的X.509主题名称匹配。CN等于Unity服务器的FQDN/主机名。基于EC密钥的证书在其使用者备用名称(SAN)字段中包含FQDN/主机名。

2.创建安全SIP中继

导航至Device > Trunk > Click and Add new,然后创建标准SIP中继,该中继将用于与Unity Connection的安全集成。

SRTP Allowed - When this flag is checked, Encrypte	d TLS needs to be configured in the network to provide e	end to end security. Failure to do so will expose keys and other informat	ion.
Consider Traffic on This Trunk Secure*	When using both sRTP and TLS	¥	
Route Class Signaling Enabled*	Default	T	
Use Trusted Relay Point*	Default	T	
PSTN Access			
Run On All Active Unified CM Nodes			

-Inbound Calls	
Significant Digits*	All
Connected Line ID Presentation*	Default 🔹
Connected Name Presentation*	Default 🔹
Calling Search Space	< None > T
AAR Calling Search Space	< None > T
Prefix DN	
Redirecting Diversion Header	Delivery - Inbound

Outbound Calls	-
----------------	---

Called Party Transformation CSS	< None >	
🗹 Use Device Pool Called Party Transform	mation CSS	
Calling Party Transformation CSS	< None >	
🗹 Use Device Pool Calling Party Transfor	rmation CSS	
Calling Party Selection*	Originator 🔹	
Calling Line ID Presentation*	Default 🔹	
Calling Name Presentation *	Default 🔹	
Calling and Connected Party Info Format	* Deliver DN only in connected party	
Redirecting Diversion Header Delivery	/ - Outbound	
Redirecting Party Transformation CSS	< None >	
✓ Use Device Pool Redirecting Party Trans	nsformation CSS	

- Destination				
Destination Address is an SRV				
Destination Ad	dress	Destination Address IPv6	Destination Port	
1* 10.48.47.123			5061	
MTP Preferred Originating Codec*	711ulaw	Ŧ		
BLF Presence Group*	Standard Presence group	T		
SIP Trunk Security Profile*	cuc-secure-profile-EDCS	T		
Rerouting Calling Search Space	< None >	T		
Out-Of-Dialog Refer Calling Search Space	< None >	T		
SUBSCRIBE Calling Search Space	< None >	T		
SIP Profile*	Standard SIP Profile	View Details		
DTMF Signaling Method*	No Preference	▼		

3.配置TLS和SRTP密码

1. **注意:** Unity Connection和Cisco Unified Communications Manager之间的协商取决于TLS密码配置,具有以下条件: 当Unity Connection用作服务器时,TLS密码协商基于Cisco Unified CM选择的首选项。在协商基于ECDSA的密码时,SSL握手中使用基于EC密钥的tomcat-ECDSA证书。在协商基于RSA的密码时,SSL握手中使用基于RSA密钥的tomcat证书。当Unity Connection用作客户端时,TLS密码协商基于Unity Connection选择的首选项。

导航至Cisco Unified CM > Systems > Enterprise Parameters,然后从下拉列表中选择适当的密码 选项TLS和SRTP密码。

r Security Parameters		
Cluster Security Mode_*	1	
LBM Security Mode_*	Insecure	/
CAPF Phone Port *	3804	
CAPF Operation Expires in (days) *	10	
TFTP File Signature Algorithm *	SHA-1	1
Enable Caching *	True	/
Authentication Method for API Browser Access.*	Basic	/
TLS Ciphers_*	All Ciphers RSA Preferred	
SRTP Ciphers *	All Supported Ciphers	·
HTTPS Ciphers *	RSA Ciphers Only	/

导航至Cisco Unified Serviceability页面、Tools > Control Center-Feature Services并在CM Services下选择Cisco Call Manager,重新启动每个节点上的Cisco Call Manager服务

导航至Cisco Unity Connection Administration页面> System Settings > General Configurations,然 后从下拉列表中选择适当的密码选项TLS和SRTP密码。

Edit General Configuration	
Time Zone	(GMT+01:00) Europe/Warsaw
System Default Language	English(United States) 🔻
System Default TTS Language	English(United States) 🔻
Recording Format	G.711 mu-law 🔻
Maximum Greeting Length	90
Target Decibel Level for Recordings and Messages	-26
Default Partition	cucv11 Partition 🔻
Default Search Scope	cucv11 Search Space 🔻
When a recipient cannot be found	Send a non-delivery receipt 🔻
IP Addressing Mode	IPv4 V
TLS Ciphers	All Ciphers RSA Preferred
SRTP Ciphers	All supported AES-256, AES-128 ciphers
HTTPS Ciphers	RSA Ciphers Only

导航至Cisco Unity Connection Serviceability > Tools > Service Management,在每个节点上重新 启动Connection Conversation Manager。

优先级顺序的TLS密码选项

TLS密码选项	按优先级顺序的TLS密码
	 TLS_ECDHE_RSA_WITH_AES_256_GC
	M_SHA384
人取强— ALS-230 SHA-304.1.0A日返	 TLS_ECDHE_ECDSA_WITH_AES_256_GCM_SHA
	384
	 TLS_ECDHE_ECDSA_WITH_AES_256_GCM_SHA
仅最强 — AES-256 SHA-384:首选ECDSA	384
	 TLS_ECDHE_RSA_WITH_AES_256_GCM_SHA384
	 TLS_ECDHE_RSA_WITH_AES_256_GCM_SHA384
	 TLS_ECDHE_ECDSA_WITH_AES_256_GCM_SHA
	384
仅中型AE3-230 AE3-120.R3A自近	• TLS_ECDHE_RSA_WITH_AES_128_GCM_SHA256
	• TLS_ECDHE_ECDSA_WITH_AES_128_GCM_SHA
	256

- 384 • TLS ECDHE RSA WITH AES 256 GCM SHA384 仅中型AES-256 AES-128:首选ECDSA TLS_ECDHE_ECDSA_WITH_AES_128_GCM_SHA 256 • TLS ECDHE RSA WITH AES 128 GCM SHA256 TLS_ECDHE_RSA_WITH_AES_256_GCM_SHA384 TLS_ECDHE_ECDSA_WITH_AES_256_GCM_SHA 384 所有密码RSA首选(默认) TLS_ECDHE_RSA_WITH_AES_128_GCM_SHA256 TLS_ECDHE_ECDSA_WITH_AES_128_GCM_SHA 256 TLS_RSA_WITH_AES_128_CBC_SHA
 - TLS_ECDHE_ECDSA_WITH_AES_256_GCM_SHA 384

TLS_ECDHE_ECDSA_WITH_AES_256_GCM_SHA

- TLS ECDHE RSA WITH AES 256 GCM SHA384
- TLS_ECDHE_ECDSA_WITH_AES_128_GCM_SHA 256
- TLS ECDHE RSA WITH AES 128 GCM SHA256
- TLS_RSA_WITH_AES_128_CBC_SHA

按优先级顺序的SRTP密码选项

SRTP密码选项

所有支持的AES-256、AES-128密码

- 按优先级顺序排列的SRTP
 - AEAD_AES_256_GCM
 - AEAD_AES_128_GCM
 - AES CM 128 HMAC SHA1 32
 - AEAD AES 256 GCM
 - AEAD_AES_128_GCM
 - AEAD_AES_256_GCM

4.上传CUC Tomcat证书(基于RSA和EC)

导航到OS Administration > Security > Certificate Management,并将两个CUC Tomcat证书(基于 RSA和EC)上传到CallManager信任存储中。

·Upload Certificate/Certificate chain			
Certificate Purpose*	CallManager-trust ~		
Description(friendly name)			
Upload File	Choose File tomcat-ECDSA.pem		

Upload	Close
--------	-------

AEAD AES-256、AES-28基于GCM的密码

仅AEAD AES256基于GCM的密码

首选所有密码ECDSA

- Upload Certificate/Certificate chain		
Certificate Purpose*	CallManager-trust 🗸	
Description(friendly name)		
Upload File	Choose File tomcat.pem	

Upload	Close

1. **注**意:如果仅协商ECDSA密码,则不必上载两个Unity Tomcat证书。在这种情况下,基于 EC的Tomcat证书已足够。

如果有第三方证书,您必须上传第三方证书颁发机构的根证书和中间证书。仅当第三方CA为您的 Unity Tomcat证书签名时,才需要此设置。

Upload Certificate/Certificate chain				
Certificate Purpose*	CallManager-trust 🗸			
Description(friendly name)				
Upload File	Choose File CA_root4096_key.crt			
Upload Close				

在所有节点上重新启动Cisco Call Manager进程以应用更改。

5.创建路由模式

通过导航至Call Routing > Route/Hunt > Route Pattern,配置指向已配置中继的路由模式。输入为路由模式号码的分机可用作语音邮件引导。

ſ	-Pattern Definition		
	Route Pattern*	2000	±.
	Route Partition	< None > V	
	Description		
	Numbering Plan	Not Selected V	
	Route Filter	< None > V	
	MLPP Precedence*	Default	
	Apply Call Blocking Percentage		
	Resource Priority Namespace Network Domain	< None > V	
	Route Class*	Default	
	Gateway/Route List*	CUCv11	
	Route Option	Route this pattern	
		Block this pattern No Error	
1			

6.创建语音邮件引导、语音邮件配置文件并将其分配给DN

通过转至Advanced Features > Voice Mail > Voice Mail Pilot为集成创建语音邮件引导。

Voice Mail Pilot Information		
Voice Mail Pilot Number	2000	
Calling Search Space	< None > T	
Description	Default	

创建语音邮件配置文件,以将所有设置链接到Advanced Features > Voice Mail > Voice Mail Profile

Voice Mail Profile Information			
Voice Mail Profile	VoiceMailProfile-8000 (used by 0 devices)		
Voice Mail Profile Name*	VoiceMailProfile-8000	±.	
Description			
Voice Mail Pilot**	2000/< None >		
Voice Mail Box Mask			

通过转到呼叫路由(Call Routing)>目录号码(Directory number),将新创建的语音邮件配置文件分配 给旨在使用安全集成的DN

Directory Number Settings		
Voice Mail Profile	VoiceMailProfile-8000	(Choose <none> to use system default)</none>
Calling Search Space	< None > T	
BLF Presence Group*	Standard Presence group 🔻]
User Hold MOH Audio Source	< None > T]
Network Hold MOH Audio Source	< None >]

配置 — 由第三方CA对基于EC密钥的证书进行签名(可选)

证书可能由第三方CA签名,然后再设置系统之间的安全集成。按照以下步骤在两个系统上签名证书 。

Cisco Unity Connection

- 1. 为CUC Tomcat-ECDSA生成证书签名请求(CSR),并且由第三方CA签名
- 2. CA提供身份证书(CA签名证书)和CA证书(CA根证书),必须按如下方式上传: 将CA根证书上传到tomcat-trust存储 将身份证书上传到tomcat-EDCS存储
- 3. 在CUC上重新启动对话管理器

Cisco Unified CM

- 1. 为CUCM CallManager-ECDSA生成CSR,并且由第三方CA签名
- 2. CA提供身份证书(CA签名证书)和CA证书(CA根证书),必须按如下方式上传: 将CA根证书上传到callmanager-trust存储 将身份证书上传到callmanager-EDCS存储
- 3. 在每个节点上重新启动Cisco CCM和TFTP服务

同一过程将用于对基于RSA密钥的证书进行签名,其中CSR为CUC Tomcat证书和CallManager证 书生成,并分别上传到tomcat存储和callmanager存储。 使用本部分可确认配置能否正常运行。

安全SIP中继验证

按电话上的"语音邮件"按钮以呼叫语音邮件。如果Unity Connection系统上未配置用户分机,您应该 听到开场问候语。

或者,您可以启用SIP OPTIONS keepalive以监控SIP中继状态。此选项可在分配给SIP中继的 SIP配置文件中启用。启用此功能后,您可以通过Device > Trunk监控Sip中继状态,如下所示:

▼ begins with ▼ CUCv11 Find Clear Filter ⊕ = Select item or enter search text ▼								
Name [▲]	Description	Calling Search Space	Device Pool	Route Pattern	Trunk Type	SIP Trunk Status	SIP Trunk Duration	
CUCv11			Default	2000	SIP Trunk	Full Service	Time In Full Service: 0 day 0 hour 0 minute	

安全RTP呼叫验证

验证Unity Connection的呼叫中是否存在挂锁图标。这意味着RTP流已加密(设备安全配置文件必须是安全的,才能正常工作),如此图所示



相关信息

• Cisco Unity Connection版本11.x的SIP集成指南