

# Cisco NX-OS تارادصا

## تايوتحمل

قمدملا

ةماعلا ةيقرتلا تاداشرا

[Cisco Nexus 3000/9000 لاهب ىصوملا ةيقرتلا ةفوفصم](#)

[Cisco Nexus 7000 لاهب ىصوملا ةيقرتلا ةفوفصم](#)

لاهب ىصوملا رادصا لاقئاثو

[Cisco Nexus 3000 و 3100 و 3200 و 3400-S و 3500 و 3600 Series Switches تالوحملا](#)

[Cisco Nexus 9000 تالدم ةلسلس](#)

[Cisco Nexus 5500 تالدم ةلسلس](#)

[Cisco Nexus 5600 تالدم ةلسلس](#)

[Cisco Nexus 6000 تالدم ةلسلس](#)

[Cisco Nexus 7000 تالدم ةلسلس](#)

## ةمدملا

Cisco NX-OS ةيقرتلا Cisco Nexus زاهج دادعإ ةبولطملا ةلصلا تاذاوملا دن تسملا اذه فصى OS.

## ةماعلا ةيقرتلا تاداشرا

Cisco Nexus 3000/9000 لاهب ىصوملا ةيقرتلا ةفوفصم

Nexus 3000/9000: ةلسلسلا نم تالوحملا ةيقرتلا ةفوفصم

<https://www.cisco.com/c/dam/en/us/td/docs/dcn/tools/nexus-9k3k-issu-matrix/index.html>

Cisco Nexus 7000 لاهب ىصوملا ةيقرتلا ةفوفصم

Nexus 7000: ةلسلسلا نم تالوحملا ةيقرتلا لودج

<https://www.cisco.com/c/dam/en/us/td/docs/dcn/tools/nexus-7k-issu-matrix/index.html>

## لاهب ىصوملا رادصا لاقئاثو

Cisco Nexus 3000 و 3100 و 3200 و 3400-S و 3500 و 3600 Series Switches تالوحملا

Cisco Nexus ةلسلسلا نم تالوحملا ل Cisco NX لاهب ىصوملا لىغشتلا ماظن تارادصا 3000 و 3100 و 3200 و 3400-S و 3500 و 3600:

[https://www.cisco.com/c/en/us/td/docs/switches/datacenter/nexus3000/sw/recommended\\_release/b\\_Minor\\_OS\\_Releases\\_for\\_Cisco\\_Nexus\\_3000\\_Series\\_Switches.html](https://www.cisco.com/c/en/us/td/docs/switches/datacenter/nexus3000/sw/recommended_release/b_Minor_OS_Releases_for_Cisco_Nexus_3000_Series_Switches.html)

## Cisco Nexus 9000 تالدم ةلسلس

Cisco Nexus 9000 Series Switches: ن م ا ه ب ي ص و م ل ل NX-OS ل ي غ ش ت ل ا م ا ظ ن ت ا ر ا د ص ا

[https://www.cisco.com/c/en/us/td/docs/switches/datacenter/nexus9000/sw/recommended\\_release/b\\_Minior\\_OS\\_Releases\\_for\\_Cisco\\_Nexus\\_9000\\_Series\\_Switches.html](https://www.cisco.com/c/en/us/td/docs/switches/datacenter/nexus9000/sw/recommended_release/b_Minior_OS_Releases_for_Cisco_Nexus_9000_Series_Switches.html)

## Cisco Nexus 5500 تالدم ةلسلس

Cisco Nexus 5500 Series Switches: ن م ا ه ب ي ص و م ل ل NX-OS ل ي غ ش ت ل ا م ا ظ ن ت ا ر ا د ص ا

[https://www.cisco.com/c/en/us/td/docs/switches/datacenter/nexus5500/sw/release/recommended\\_release/os\\_releases.html](https://www.cisco.com/c/en/us/td/docs/switches/datacenter/nexus5500/sw/release/recommended_release/os_releases.html)

## Cisco Nexus 5600 تالدم ةلسلس

Cisco Nexus 5600 Series Switches: ن م ا ه ب ي ص و م ل ل NX-OS ل ي غ ش ت ل ا م ا ظ ن ت ا ر ا د ص ا

[https://www.cisco.com/c/en/us/td/docs/switches/datacenter/nexus5600/sw/release/recommended\\_release/os\\_releases.html](https://www.cisco.com/c/en/us/td/docs/switches/datacenter/nexus5600/sw/release/recommended_release/os_releases.html)

## Cisco Nexus 6000 تالدم ةلسلس

Cisco Nexus 6000 Series Switches: ن م ا ه ب ي ص و م ل ل NX-OS ل ي غ ش ت ل ا م ا ظ ن ت ا ر ا د ص ا

[https://www.cisco.com/c/en/us/td/docs/switches/datacenter/nexus6000/sw/release/recommended\\_release/os\\_releases.html](https://www.cisco.com/c/en/us/td/docs/switches/datacenter/nexus6000/sw/release/recommended_release/os_releases.html)

## Cisco Nexus 7000 تالدم ةلسلس

Cisco Nexus 7000 Series Switches: ن م ا ه ب ي ص و م ل ل NX-OS ل ي غ ش ت ل ا م ا ظ ن ت ا ر ا د ص ا

[https://www.cisco.com/c/en/us/td/docs/switches/datacenter/sw/nx-os/recommended\\_releases/recommended\\_nx-os\\_releases.html](https://www.cisco.com/c/en/us/td/docs/switches/datacenter/sw/nx-os/recommended_releases/recommended_nx-os_releases.html)

ةمچرتل هذه لوج

ةللأل تاي نقتل نم ةومچم مادختساب دن تسمل اذہ Cisco تچرت  
ملاعلاء انءمچي فني مدختسمل معدى وتحم مي دقتل ةيرشبل او  
امك ةقيقد نوك تنل ةللأل ةمچرت لصف أن ةظحال مچري. ةصاخل مه تلبل  
Cisco يلخت. فرتحم مچرت مامدقي يتل ةيفارتحال ةمچرتل عم لالحل وه  
ىل إأمئاد ةوچرلاب يصوت وتامچرتل هذه ةقدنع اهتيلوئسم Cisco  
Systems (رفوتم طبارل) يلصلأل يزي لچنل دن تسمل