

如何在網路安全裝置上配置手動DNS條目？

目錄

[問題](#)

[環境](#)

問題

如何在思科網路安全裝置上配置手動DNS條目？

環境

思科網路安全裝置(WSA)，所有AsyncOS版本

在命令列介面(CLI)中輸入以下命令，如下所示：

```
WSA> dnsconfig
```

```
Choose the operation you want to perform:
```

- NEW - Add a new server.
- SETUP - Configure general settings.
- SEARCH - Configure DNS domain search list.

```
[> localhosts
```

```
Local IP to Host mappings:
```

```
Choose the operation you want to perform:
```

- NEW - Add new local IP to host mapping.
- DELETE - Delete an existing mapping.

```
[> new
```

```
Enter the IP address of the host you are adding.
```

```
[> 1.1.1.1
```

```
Enter the canonical host name and any additional aliases (separate values with spaces)
```

```
[> example.com
```

```
Local IP to Host mappings:
```

```
1. 1.1.1.1 example.com
```

```
Choose the operation you want to perform:
```

- NEW - Add new local IP to host mapping.
- DELETE - Delete an existing mapping.

```
[>
```

在CLI提示符下，請使用CLI命令 — **commit** — 提交DNS配置更改。

附註：CLI命令「dnsconfig」中的「**localhosts**」選項是隱藏選項。