

# Client-Initiated L2TPv2 Tunnel with ISR4000 That Acts as a Server Configuration Example



Document ID: 118442

Contributed by Utsav Dutt, Cisco TAC Engineer.  
Nov 18, 2014

## Contents

### Introduction

#### Prerequisites

- Requirements
- Components Used

#### Background

#### Configure

- Network Diagram
- Configurations
  - Configuration on the Client Router
  - Configuration on the ISR4451 That Acts as a Server

#### Verify

- Verification on the Client Router
- Verification on the ISR4000 That Acts as a Server

#### Troubleshoot

#### Related Information

## Introduction

This document describes how to configure a client-initiated Layer 2 Tunneling Protocol version 2 (L2TPv2) tunnel with a Cisco 4000 Series Integrated Services Router- ISR4451-X/K9 (ISR4000) that acts as a server.

## Prerequisites

### Requirements

Cisco recommends that you meet these requirements before you attempt this configuration:

- Active *appxk9* license on the ISR4451-X/K9 that acts as a server
- Layer 2 connectivity between the client router and server

**Note:** This document was created with a Cisco 887VA as the client router. However, the client can be a Microsoft Windows machine as well.

### Components Used

This document is not restricted to specific software and hardware versions.

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, make sure

that you understand the potential impact of any command.

## Background

Client-initiated dial-in Virtual Private Dialup Network (VPDN) tunneling deployments allow remote users to access a private network over a shared infrastructure with end-to-end protection of private data.

Client-initiated VPDN tunneling does not require additional security to protect data between the client and the ISP Network Access Server (NAS).

Restriction – *appxk9* must be active on the ISR4000 router. Without this license, the route will get installed towards the client at the end of PPP negotiation, but Layer 3 connectivity between the client and the server will not be established.

## Configure

*Note:* Use the Command Lookup Tool (registered customers only) in order to obtain more information on the commands used in this section.

## Network Diagram



## Configurations

### Configuration on the Client Router

An example of the configuration on the client router is shown here:

```
!  
l2tp-class CISCO  
!  
pseudowire-class CLASS  
  encapsulation l2tpv2  
  ip local interface Vlan333  
!  
interface FastEthernet0/0  
  switchport access vlan 333  
  no ip address  
  no keepalive  
!  
interface Virtual-PPP1  
  ip address negotiated  
  ppp chap hostname cisco@cisco.com  
  ppp chap password 0 cisco  
  pseudowire 10.1.1.2 1 pw-class CLASS    !! Specifies the IP address of the tunnel  
  server and the 32-bit virtual circuit identifier (VCID) shared between the  
  devices at each end of the control channel.  
!  
interface Vlan333  
  ip address 10.1.1.1 255.255.255.0  
!
```

## Configuration on the ISR4451 That Acts as a Server

An example of the configuration on ISR4000 that acts as a server is shown here:

```
vpdn enable
!
vpdn-group 1
  accept-dialin
  protocol l2tp
  virtual-template 1
  terminate-from hostname CLIENT
  no l2tp tunnel authentication
!
license boot level appxk9 !! License must be appxk9

username cisco@cisco.com password 0 cisco
!
interface Loopback1
  ip address 192.168.1.2 255.255.255.0
!
interface FastEthernet0/0
  ip address 10.1.1.2 255.255.255.0
  negotiation auto
!
ip local pool TEST 10.1.1.3 10.1.1.100
!
interface Virtual-Template1
  ip unnumbered Loopback1
  peer default ip address pool TEST
  ppp authentication chap
!
```

## Verify

Use this section in order to verify your configuration.

The Output Interpreter Tool (registered customers only) supports certain *show* commands. Use the Output Interpreter Tool in order to view an analysis of *show* command output.

## Verification on the Client Router

Enter these commands in order to verify the configuration on client router:

```
CLIENT#show vpdn session
```

```
L2TP Session Information Total tunnels 1 sessions 1
```

LocID	RemID	TunID	Username, Intf/ Vcid, Circuit	State	Last Chg	Uniq ID
9886	40437	48058	1, Vp1	est	00:17:51	17

!! Session up since 17:51 Minutes

```
CLIENT#show caller ip
```

Line	User	IP Address	Local Number	Remote Number	<->
Vp1	SERVER	192.168.1.2	-	-	in

```
!! Tunnel Server
```

```
CLIENT#ping 192.168.1.2 !! Tunnel Server Reachable
```

```
Type escape sequence to abort.
```

```
Sending 5, 100-byte ICMP Echos to 192.168.1.2, timeout is 2 seconds:
```

```
!!!!
```

```
Success rate is 100 percent (5/5), round-trip min/avg/max = 1/1/1 ms
```

```
CLIENT#show ppp all
Interface/ID OPEN+ Nego* Fail-      Stage      Peer Address      Peer Name
-----
Vp1          LCP+ IPCP+ CDPCP-      LocalT      192.168.1.2      SERVER
```

## Verification on the ISR4000 That Acts as a Server

```
SERVER#show license feature
Feature name      Enforcement  Evaluation  Subscription  Enabled  RightToUse
appxk9           yes         yes         no            yes     yes
!! License must be Active
```

```
SERVER#show vpdn session
```

```
L2TP Session Information Total tunnels 1 sessions 1
```

```
LocID      RemID      TunID      Username, Intf/      State  Last Chg Uniq ID
          Vcid, Circuit
40437      9886      19763      cisco@cisc..., Vi3.1 est  00:16:56 2
```

```
SERVER#show caller ip
```

```
Line      User      IP Address      Local Number      Remote Number      <->
Vi3.1     cisco@cisco.com \
          10.1.1.4      -                -                in
```

```
!! IP address of the Client allocated from local address pool (TEST)
```

```
SERVER#ping 10.1.1.4 !! Client reachable
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 10.1.1.4, timeout is 2 seconds:
!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 1/1/1 ms
```

## Troubleshoot

**Note:** Refer to Important Information on Debug Commands before you use *debug* commands.

Use standard VPDN/ L2TP/ PPP procedures in order to troubleshoot any issues. However, this list of debugs can also be helpful.

```
debug ppp events
debug ppp error
debug ppp negotiation
debug vpdn error
debug vpdn event
debug vpdn l2x events
debug vpdn l2x errors
debug l2tp error
debug l2tp event
debug vtemplate event
debug vtemplate error
debug vtemplate cloning
```

## Related Information

- *Configuring Client-Initiated Dial-In VPDN Tunneling*
- *Technical Support & Documentation – Cisco Systems*

