



Release Notes for Cisco IOS Release 15.2(6)E0a

First Published: October 30, 2017

Cisco IOS Release 15.2(6)E0a runs on these platforms:

- Cisco 2500 Series Connected Grid Switches (CGS 2520)
- Cisco Connected Grid Ethernet Switch Module (CGR 2010 ESM)
- Cisco Embedded Service 2020 Series Switches (ESS 2020)
- Cisco Industrial Ethernet 2000 Series Switches (IE 2000)
- Cisco Industrial Ethernet 2000U Series Switches (IE 2000U)
- Cisco Industrial Ethernet 3000 Series Switches (IE 3000)
- Cisco Industrial Ethernet 3010 Series Switches (IE 3010)
- Cisco Industrial Ethernet 4000 Series Switches (IE 4000)
- Cisco Industrial Ethernet 4010 Series Switches (IE 4010)
- Cisco Industrial Ethernet 5000 Series Switches (IE 5000)

These release notes include important information about Cisco IOS Release 15.2(6)E0a and any limitations, restrictions, and caveats that apply to the release. Verify that these release notes are correct for your switch:

- If you are installing a new switch, see the Cisco IOS release label on the rear panel of your switch.
- If your switch is on, use the **show version** command. See [Finding the Software Version and Feature Set, page 6](#).
- If you are upgrading to a new release, see the software upgrade filename for the software version. See [Deciding Which Files to Use, page 6](#).

For a complete list of documentation for the platforms associated with this release, see [Related Documentation, page 13](#).

You can download the switch software from this site (registered Cisco.com users with a login password):

<http://software.cisco.com/download/navigator.html>

Organization

This document includes the following sections:

Conventions, page 2	Conventions used in this document.
New Features in Cisco IOS Release 15.2(6)E0a, page 3	New features supported for Releases 15.2(6)E0a.
System Requirements, page 5	System requirements for Releases 15.2(6)E0a.
Upgrading the Switch Software, page 6	Procedures for downloading software.
Caveats, page 11	Open caveats in Release 15.2(6)E0a.
Related Documentation, page 13	Updates to the IE switch product documentation.
Related Documentation, page 13	Links to the documentation for the hardware platforms associated with this release.

Conventions

This document uses the following conventions.

Conventions	Indication
bold font	Commands and keywords and user-entered text appear in bold font .
<i>italic font</i>	Document titles, new or emphasized terms, and arguments for which you supply values are in <i>italic font</i> .
[]	Elements in square brackets are optional.
{x y z }	Required alternative keywords are grouped in braces and separated by vertical bars.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
courier font	Terminal sessions and information the system displays appear in <code>courier font</code> .
< >	Nonprinting characters such as passwords are in angle brackets.
[]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

Note: Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the manual.

Caution: Means *reader be careful*. In this situation, you might perform an action that could result in equipment damage or loss of data.

Warning: IMPORTANT SAFETY INSTRUCTIONS

Means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. Use the statement number provided at the end of each warning to locate its translation in the translated safety warnings that accompanied this device.

SAVE THESE INSTRUCTIONS

Regulatory: Provided for additional information and to comply with regulatory and customer requirements.

New Features in Cisco IOS Release 15.2(6)E0a

Table 1 lists new features added in Cisco IOS Release 15.2(6)E0a.

Table 1 New Feature Summary for Cisco IOS Release 15.2(6)E0a

Feature	Platform	Description	Related Documentation
Global Navigation Satellite System (GNSS)	IE 5000	Embedded GNSS receiver within the IE 5000 enables the switch to determine its own location and get accurate time from a satellite constellation and serve as the source (Grand Master Clock) for time distribution in the network.	Global Navigation Satellite System for IE 5000
Parallel Redundancy Protocol (PRP) Enhancements	IE 4000, IE 4010, IE 5000	<p>Summary of Enhancements:</p> <ul style="list-style-type: none"> ■ Statistics for PRP Ports – contents, display (CLI and Device Manager) ■ SNMP for PRP <p>PRP provides hitless redundancy (zero recovery time) after a failure by providing end nodes, identified as dually-attached nodes (DANs) provide access to two independent, disjointed, parallel networks (LAN-A, LAN-B). (IEC 62439-3)</p>	Device Manager Online Help
Precision time Protocol (PTP) over Parallel Redundancy Protocol (PRP)	IE 4000, IE 4010, IE 5000	<p>PTP is supported over both LAN A and LAN B in the PRP network to provide redundancy for PTP.</p> <p>Previously, PTP traffic was supported over LAN A only.</p>	Parallel Redundancy Protocol (PRP) for IE 4000, IE 4010, and IE 5000 Switches
High-availability Seamless Redundancy (HSR)	IE 4000	<p>High-availability Seamless Redundancy (HSR) is defined in International Standard IEC 62439-3-2016 Clause 5.</p> <p>HSR is similar to Parallel Redundancy Protocol (PRP) in providing hitless redundancy. HSR is designed to work in a ring topology rather than two parallel independent networks of any topology (LAN-A and LAN-B), HSR defines a ring with traffic in opposite directions. Port-A sends traffic counter clockwise in the ring, and Port-B sends traffic clockwise.</p>	High-Availability Seamless Redundancy (HSR) for IE 4000 Configuration Guide
Entity Sensor MIB Support	IE 2000, IE 2000U, IE 3000, IE 4000, IE 4010, IE 5000	CISCO-ENTITY-SENSOR-MIB is used for SNMP support for sensors on IE switches instead of ENTITY-SENSOR-MIB.	<p>MIB Locator:</p> <p>http://tools.cisco.com/ITDIT/MIBS/ervlet/index</p>
QinQ Support	IE 4000, IE 5000	QinQ support is moved to Lanbase license for IE 4000 and IE 5000.	—
Trustsec - SGACL Support	IE 4010	Allows tracking and ensures protected communication between peers.	Cisco TrustSec Switch Configuration Guide

Table 1 New Feature Summary for Cisco IOS Release 15.2(6)E0a (continued)

Feature	Platform	Description	Related Documentation
Profinet - Pluggable SFP module support	IE 4000	IE 4000 Fiber SFP transceivers via combo ports are now visible to SIMATIC TIA Portal. Note: The combo port works in both copper and fiber mode. Note: IE 2000 and IE 5000 already support this capability. Initial support was supported in Cisco IOS Release 15.2(5)E2.	Pluggable Transceiver (SFP) Configuration Guide for SIMATIC STEP7/TIA Portal
Device Manager Enhancements	IE 2000, IE 3000, IE 4000, IE 4010, IE 5000	Configure Open Plug and Play (PnP) server settings to allow a switch to send a work request to a PnP server such as Industrial Network Director (IND) to allow further device configuration.	Device Manager Online Help
	IE 2000, IE 2000U, IE 4000, IE 4010, IE 5000	IND baseline configuration - Changes within Device Manager to make IOT switches IND discoverable.	
	IE 4000	Feature Mode manages the FPGA resources for a given set of features. The feature mode setting determines if TSN or HSR features are operational. Availability of Feature Mode on the switch is determined by supported features, applicable software licenses, and currently applied Feature Mode. The switch is configured with a default Feature Mode. The default Feature Mode is the most commonly-used feature. In a running system, if you deactivate the current active Feature Mode, the default mode will be applied.	
	IE 2000, IE 2000U, IE 4000, IE 4010, IE 5000	PnP configuration support in Device Manager - On Express setup, the user will point to the PNP server. The switch will send work request to the PNP server for further device configuration.	
	IE4000 (IOx)	MOTD - You can configure a Message of the Day (MOTD) banner to be displayed on the Device Manager Dashboard.	

System Requirements

Table 1 New Feature Summary for Cisco IOS Release 15.2(6)E0a (continued)

Feature	Platform	Description	Related Documentation
Device Manager Enhancements (cont.)	IE 2000, IE 2000U IE 4000, IE 4010, IE 5000	RSTP/MSTP bridge priority and diagnosis capability - You can select RSTP/MSTP bridge priority per port and display spanning-tree information for the selected VLAN.	Device Manager Online Help
	IE 2000, IE 2000U, IE 3000, IE 4000 (IOS), IE 4000 (IOx), IE 4010, IE 5000	Auto-Logout - If the device manager session is left inactive for the duration of the configured timeout value, the session will be logged out and the user must be re-authenticated. By default session timeout is 3 minutes. The timeout now can be configured only from CLI: <code>ip http session-idle-timeout <1-1200></code> The session timeout value configured while a user is logged in to DM will be used for auto-logout.	—
Device Manager Localization	IE 2000, IE 2000U, IE 3000, IE 4000 (IOS), IE 4000 (IOx), IE 4010, IE 5000	Online help for the Device Manager is available in the following languages: <ul style="list-style-type: none"> ■ Chinese (Traditional) ■ Chinese (Simplified) ■ Default: English ■ French ■ German ■ Japanese ■ Spanish (LATAM) 	Device Manager Online Help

System Requirements

This section describes the following system requirements for Cisco IOS Release 15.2(6)E0a:

- [Express Setup Requirements, page 5](#)

Express Setup Requirements

This section summarizes the hardware and software requirements for the Windows platform.

For a listing of Express Setup documentation, see [Table 3 Methods for Assigning IP Information, page 10](#).

Hardware

- 1 gigahertz (GHz) or faster 32-bit (x86) or 64-bit (x64) processor
- 1 gigabyte (GB) RAM (32-bit) or 2 GB RAM (64-bit)

Upgrading the Switch Software

- 16 GB available hard disk space (32-bit) or 20 GB (64-bit)

Software

- PC with Windows 7, Windows 10, or Mac OS 10.6.x
- Web browser (Internet Explorer 10.0 or 11.0, or Firefox 48.x and above) with JavaScript enabled
- Straight-through or crossover Category 5 or 6 cable

Express Setup verifies the browser version when starting a session, and it does not require a plug-in.

Upgrading the Switch Software

These are the procedures for downloading software. Before downloading software, read these sections for important information:

- [Finding the Software Version and Feature Set, page 6](#)
- [Deciding Which Files to Use, page 6](#)
- [IOS/IOx Upgrade Considerations, page 7](#)
- [Archiving Software Images, page 7](#)
- [Upgrading a Switch by Using the CLI, page 8](#)
- [Installation Notes, page 10](#)

Finding the Software Version and Feature Set

The Cisco IOS image is stored as a bin file in a directory that is named with the Cisco IOS release. A subdirectory contains the files needed for web management. The image is stored on the compact flash memory card.

You can use the **show version** privileged EXEC command to see the software version that is running on your switch. The second line of the display shows the version.

You can also use the **dir filesystem:** privileged EXEC command to see the directory names of other software images stored in flash memory. For example, use the **dir flash:** command to display the images in the flash memory.

Deciding Which Files to Use

The upgrade procedures in these release notes describe how to perform the upgrade by using a combined tar file. This file contains the Cisco IOS image file and the files needed for the embedded device manager. You must use the combined tar file to upgrade the switch through Express Setup. To upgrade the switch through the command-line interface (CLI), use the tar file and the **archive download-sw** privileged EXEC command.

[Table 2](#) lists the filenames for this software release.

Note: If you download the IP services image and plan to use Layer 3 functionality, you must use the Switch Database Management (SDM) routing template. To determine the currently active template, enter the **show sdm prefer** privileged EXEC command. If necessary, enter the **sdm prefer** global configuration command to change the SDM template to a specific template. For example, if the switch uses Layer 3 routing, change the SDM template from the default to the routing template. You must reload the switch for the new template to take effect.

Note: Beginning with Cisco IOS Release 15.2(5)E, we **no longer release** the IE 3000 IP services image. The latest release for the IP services image on the IE 3000 is 15.2(4)EA1.

Table 2 Cisco IOS Software Image Files

File Name	Description
cgs2520-ip-services-lmk9-tar.152-6.E0a.tar	CGS 2520 IP services image file
cgs2520-lan-base-lmk9-tar.152-6.E0a.tar	CGS 2520 LAN base image file
c2020-universalk9-tar.152-6.E0a.tar	ESS 2020 universal image file
ie2000-universalk9-tar.152-6.E0a.tar	IE 2000 universal image file
ie2000u-ip-services-lmk9-tar.152-6.E0a.tar	IE 2000U IP services image file
ie2000u-lan-base-lmk9-tar.152-6.E0a.tar	IE 2000U LAN base image file
ie3010-ip-services-k9-tar.152-6.E0a.tar	IE 3010 IP services image file
ie3010-lan-base-k9-tar.152-6.E0a.tar	IE 3010 LAN base image file
ies-lan-base-k9-tar.152-6.E0a.tar	IE 3000 LAN base image file
grwicdes-ip-services-lmk9-tar.152-6.E0a.tar	ESM IP services image file
grwicdes-lan-base-lmk9-tar.152-6.E0a.tar	ESM LAN base image file
ie4000-universalk9_iox-tar.152-6.E0a.tar	IE 4000 Universal image file bundles Cisco IOx and IOS
ie4000-universalk9-tar.152-6.E0a.tar	IE 4000 Universal image file (Cisco IOS only)
ie4010-universalk9-tar.152-6.E0a.tar	IE 4010 Universal image file
ie5000-universalk9-tar.152-6.E0a.tar	IE 5000 Universal image file

IOS/IOx Upgrade Considerations

Before upgrading, note the following Cisco IOS/IOx version incompatibilities:

- With switch running Cisco IOS 15.2(5)E2, IOx upgrade from version 1.3 to 1.4 and higher is not supported
- IOx 1.3 is not supported in Cisco IOS 15.2(6)E2 and higher

We recommend that you upgrade using the IOS and IOx bundle image to move to the higher version software. IOS/IOx bundle images will always have a compatible combination of IOS and IOx.

Archiving Software Images

Before upgrading your switch software, make sure that you archive copies of both your current Cisco IOS release and the Cisco IOS release to which you are upgrading. Keep these archived images until you have upgraded all devices in the network to the new Cisco IOS image and verified that the new Cisco IOS image works properly in your network.

Cisco routinely removes old Cisco IOS versions from Cisco.com. See *Product Bulletin 2863* for information:

http://www.cisco.com/en/US/prod/collateral/iosswrel/ps8802/ps6969/ps1835/prod_bulletin0900aecd80281c0e.html

You can copy the bin software image file on the flash memory to the appropriate TFTP directory on a host by using the **copy flash: tftp:** privileged EXEC command.

Note: Although you can copy any file on the flash memory to the TFTP server, it is time consuming to copy all of the HTML files in the tar file. We recommend that you download the tar file from Cisco.com and archive it on an internal host in your network.

You can also configure the switch as a TFTP server to copy files from one switch to another without using an external TFTP server by using the **tftp-server** global configuration command.

Upgrading a Switch by Using the CLI

This procedure is for copying the combined tar file to the switch. You copy the file to the switch from a TFTP server and extract the files. You can download an image file and replace or keep the current image.

Note: Make sure that the compact flash card is in the switch before downloading the software.

To download software, follow these steps:

1. Use [Table 2 on page 7](#) to identify the file that you want to download.
2. Download the software image file. If you have a SMARTnet support contract, go to this URL, and log in to download the appropriate files:

<http://software.cisco.com/download/navigator.html>

For example, to download the image for an IE 2000 switch, select Products > Switches > Industrial Ethernet Switches > Cisco Industrial Ethernet 2000 Series Switches, then select your switch model. Select IOS Software for Software Type, then select the image you want to download.

3. Copy the image to the appropriate TFTP directory on the workstation, and make sure that the TFTP server is properly configured.

For more information, see the “Assigning the Switch IP Address and Default Gateway” chapter in the applicable document for your switch as listed in [Table 3](#).

4. Log into the switch through the console port or a Telnet session.
5. (Optional) Ensure that you have IP connectivity to the TFTP server by entering this privileged EXEC command:

```
Switch# ping tftp-server-address
```

For more information about assigning an IP address and default gateway to the switch, see [Table 3](#).

6. Download the image file from the TFTP server to the switch.

If you are installing the same version of software that currently exists on the switch, overwrite the current image by entering this privileged EXEC command:

```
Switch# archive download-sw /overwrite /reload tftp://location /directory /image-name.tar
```

The command above untars/unzips the file. The system prompts you when it completes successfully.

— The **/overwrite** option overwrites the software image in flash memory with the downloaded one.

If you specify the command without the **/overwrite** option, the download algorithm verifies that the new image is not the same as the one on the switch Flash device. If the images are the same, the download does not occur. If the images are different, the old image is deleted, and the new one is downloaded. If there is not enough space to install the new image and keep the current running image, the download process stops, and an error message displays.

— The **/reload** option reloads the system after downloading the image unless the configuration has been changed and not saved.

— For *// location*, specify the IP address of the TFTP server. or hostname.

— For */directory/image-name.tar*, specify the directory and the image to download. Directory and image names are case sensitive. The directory is for file organization and it is generally a *tftpboot/user-ID* path.

This example shows how to download an image from a TFTP server at 198.30.20.19 and to overwrite the image on the switch:

```
Switch# archive download-sw /overwrite tftp://198.30.20.19/image-name.tar
```

You can also download the image file from the TFTP server to the switch and keep the current image by replacing the **/overwrite** option with the **/leave-old-sw** option. If there is not enough space to install the new image and keep the current running image, the download process stops, and an error message displays.

Upgrading IOS and FPGA on the Ethernet Switch Module (ESM)

This procedure is for copying the combined tar file to the switch. You copy the file to the switch from a TFTP server and extract the files. You can download an image file and replace or keep the current image.

To download software, follow these steps:

1. Refer to [Deciding Which Files to Use, page 6](#) to identify the file that you want to download.
2. Download the software image file. If you have a SMARTnet support contract, go to the URL below and log in to download the appropriate files.

<http://software.cisco.com/download/navigator.html>

For example, to download the image for a Connected Grid 10-Port Ethernet Switch Module Interface Card, select Products > Cisco Interfaces and Modules > Connected Grid Modules > Connected Grid 10-Port Ethernet Switch Module Interface Card. Select IOS Software for Software Type, then select the image you want to download.

Copy the image to the appropriate TFTP directory on the workstation, and make sure that the TFTP server is properly configured. For more information, see the “Assigning the Switch IP Address and Default Gateway” chapter in the applicable document listed in [Table 3 Methods for Assigning IP Information, page 10](#).

3. Copy the image to the appropriate TFTP directory on the workstation, and make sure that the TFTP server is properly configured.
4. Log in to the switch through the console port or a Telnet session.
5. (Optional) Ensure that you IP connectivity to the TFTP server by entering this privileged EXEC command:

```
Switch# ping tftp-server-address
```

6. Download the image file from the TFTP server to the switch.

If you are installing the same version of software that currently exists on the switch, overwrite the current image by entering this privileged EXEC command:

```
Switch# archive download-sw /overwrite tftp: //location /directory /image-name.tar
```

The command above untars/unzips the file. The system prompts you when it completes successfully.

- The **/overwrite** option overwrites the software image in flash memory with the downloaded one.

If you specify the command without the **/overwrite** option, the download algorithm verifies that the new image is not the same as the one on the switch Flash device. If the images are the same, the download does not occur. If the images are different, the old image is deleted, and the new one is downloaded. If there is not enough space to install the new image and keep the current running image, the download process stops, and an error message displays.

- The **/reload** option reloads the system after downloading the image unless the configuration has been changed and not saved.
- For *// location*, specify the IP address of the TFTP server. or hostname.
- For */directory/image-name.tar*, specify the directory and the image to download. Directory and image names are case sensitive. The directory is for file organization and it is generally a *ftpboot/user-ID* path.

This example shows how to download an image from a TFTP server at 198.30.20.19 and to overwrite the image on the switch:

```
Switch# archive download-sw /overwrite tftp://198.30.20.19/image-name.tar
```

You can also download the image file from the TFTP server to the switch and keep the current image by replacing the **/overwrite** option with the **/leave-old-sw** option. If there is not enough space to install the new image and keep the current running image, the download process stops, and an error message displays.

7. After the download and the untar are complete, power cycle the CGR2010.

Installation Notes

You can assign IP information to your switch using the methods shown in [Table 3](#)

Table 3 Methods for Assigning IP Information

Method	Platform	Document
Express setup program	IE 2000	Cisco IE 2000 Switch Hardware Installation Guide
	IE 3000	<i>Cisco IE 3000 Switch Getting Started Guide</i> , Device Manager Online Help
	ESM	<i>Connected Grid Ethernet Switch Module Interface Card Getting Started Guide</i>
	IE 4000	Cisco IE 4000 Switch Hardware Installation Guide
	IE 4010	Cisco IE 4010 Switch Hardware Installation Guide
	IE 5000	Cisco IE 5000 Hardened Aggregator Hardware Installation Guide
CLI-based setup program	ESS 2020	Cisco Embedded Service 2020 Series Software Configuration Guide
	IE 2000	<i>Cisco IE 2000 Switch Hardware Installation Guide</i>
	IE 2000U	<i>Cisco IE 2000U Switch Hardware Installation Guide</i>
	IE 3000	<i>Cisco IE 3000 Series Switch Hardware Installation Guide</i>
	IE 3010	<i>Cisco IE 3010 Switch Hardware Installation Guide</i>
	CGS 2520	<i>Cisco CGS 2520 Hardware Installation Guide</i>
	ESM	<i>Cisco CGS 2520 Hardware Installation Guide</i> Note: The <i>Cisco CGS 2520 Hardware Installation Guide</i> serves as CLI-based Setup reference for the ESM.
	IE 4000	Cisco IE 4000 Switch Hardware Installation Guide
	IE4010	Cisco Industrial Ethernet 4000, 4010 and 5000 Switch Software Configuration Guide
	IE 5000	Cisco IE 5000 Hardened Aggregator Hardware Installation Guide

Caveats

Table 3 Methods for Assigning IP Information (continued)

Method	Platform	Document
DHCP-based autoconfiguration	ESS 2020	Cisco Embedded Service 2020 Series Software Configuration Guide
	IE 2000	<i>Cisco IE 2000 Series Switch Software Configuration Guide</i>
	IE 2000U	<i>System Management Software Configuration Guide for Cisco IE 2000U and Connected Grid Switches</i>
	IE 3000	<i>Cisco IE 3000 Series Switch Software Configuration Guide</i>
	IE 3010	<i>Cisco IE 3010 Series Switch Software Configuration Guide</i>
	CGS 2520	<i>CGS 2520 Switch Software Configuration Guide</i>
	ESM	<i>Cisco Connected Grid Ethernet Switch Module Interface Card Software Configuration Guide</i>
	IE 4000	Cisco Industrial Ethernet 4000 Series Switch Software Configuration Guide
	IE4010	Cisco Industrial Ethernet 4000, 4010 and 5000 Switch Software Configuration Guide
	IE 5000	Cisco IE 5000 Hardened Aggregator Hardware Installation Guide
Manually assigning an IP address	IE 2000	<i>Cisco IE 2000 Series Switch Software Configuration Guide</i>
	IE 2000U	<i>System Management Software Configuration Guide for Cisco IE 2000U and Connected Grid Switches</i>
	IE 3000	<i>Cisco IE 3000 Series Switch Software Configuration Guide</i>
	IE 3010	<i>Cisco IE 3010 Series Switch Software Configuration Guide</i>
	CGS 2520	<i>CGS 2520 Switch Software Configuration Guide</i>
	ESM	<i>Cisco Connected Grid Ethernet Switch Module Interface Card Software Configuration Guide</i>
	IE 4000	Cisco Industrial Ethernet 4000 Series Switch Software Configuration Guide
	IE4010	Cisco Industrial Ethernet 4000, 4010 and 5000 Switch Software Configuration Guide
IE 5000	Cisco IE 5000 Hardened Aggregator Hardware Installation Guide	

Caveats

- [Cisco Bug Search Tool, page 11](#)
- [Open Caveats, page 13](#)
- [Resolved Caveats, page 13](#)

Cisco Bug Search Tool

The Bug Search Tool (BST), which is the online successor to Bug Toolkit, is designed to improve the effectiveness in network risk management and device troubleshooting. The BST allows partners and customers to search for software bugs based on product, release, and keyword, and aggregates key data such as bug details, product, and version. The tool has a provision to filter bugs based on credentials to provide external and internal bug views for the search input.

Caveats

To view the details of a caveat listed in this document:

1. Access the BST (use your Cisco user ID and password) at <https://tools.cisco.com/bugsearch/>.
2. Enter the bug ID in the Search For: field.

Open Caveats

Table 4 Open Caveats in Cisco IOS Release 15.2(6)E0a (Listed in descending order)

Bug ID	Headline
CSCvg44576	Unable to remove the PROFINET_dev_name variable that got set through TIA
CSCvg25742	LLDP transmit setting does not persist after power cycle when set thru a PROFINET Controller
CSCvg12115	LLDP timer and hold time settings from a PROFINET controller doesn't persist thru a power cycle
CSCvf23753	Express Setup Not Adding Access VLAN to Settings
CSCvf20668	Short press express setup work flow causes additional authentication dialog to popup in some cases
CSCvfi3976	IE4K (IE4000) MRP: Default mode CLI moves the node to mode client when configured manager and vice versa
CSCve99439	PRP channel should be suspended when there is a speed mismatch on the PRP interfaces
CSCve12164	DM: "SSL_WEAK_SERVER_CERT_KEY" issue seen with Mozilla Version 47.0.1 after Factory defaults
CSCvd42080	Profinet: SD card alarm not available to TIA but STEP7 only
CSCvd21083	Profinet: TIA alarm is not cleared if SFP is plugged in after switch bootup

Resolved Caveats

Table 5 Resolved Caveats in Cisco IOS Release 15.2(6)E0a (Listed in descending order)

Bug ID	Headline
CSCvf68802	With Profinet enabled, ip default gateway configuration gets removed.
CSCve17336	IE 4000 IOX: Use IPv4 Link-Local Addresses for internal communications
CSCvd51141	802.1AS: Performance degraded in offset testing.
CSCvd23231	VTP_INVALID_DATABASE_DATA, TRACEBACK=82A1C4z 2CEE50z 2CFC2D4z
CSCvc28935	IE 4010 reloads after configuring NTP
CSCvc04363	OLH: Some help pages appear in English on launching OLH in other languages
CSCvb01492	FNF: Configuration rejection of incomplete record not seen for members

Related Documentation

Table 6 Related Documentation

Device or Feature	Related Documents
Cisco 2500 Series Connected Grid Switches	http://www.cisco.com/go/cgs2520
Cisco Embedded Service 2020 Series Switches (ESS 2020)	http://www.cisco.com/c/en/us/support/switches/embedded-service-2020-series-switches/tsd-products-support-series-home.html
Cisco Ethernet Switch Module (ESM) for CGR 2010	http://www.cisco.com/go/cgr2000
Cisco Industrial Ethernet 2000 Series Switches	http://www.cisco.com/go/ie2000
Cisco Industrial Ethernet 2000U Series Switches	http://www.cisco.com/go/ie2000u
Cisco Industrial Ethernet 3000 Series Switches	http://www.cisco.com/go/ie3000
Cisco Industrial Ethernet 3010 Series Switches	http://www.cisco.com/go/ie3010

Table 6 **Related Documentation**

Device or Feature	Related Documents
Cisco Industrial Ethernet 4000 Series Switches	http://www.cisco.com/go/ie4000
Cisco Industrial Ethernet 4010 Series Switches	http://www.cisco.com/go/ie4010
Cisco Industrial Ethernet 5000 Series Switches	http://www.cisco.com/go/ie5000

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

No combinations are authorized or intended under this document.

© 2017 Cisco Systems, Inc. All rights reserved.