



The bridge to possible

Design and Deployment Guide

Cisco Public

Cisco UCS C-Series Rack Systems with Rubrik Security Cloud

Design and Deployment Guide

Published: March 2024



In partnership with:



About the Cisco Validated Design Program

The Cisco Validated Design (CVD) program consists of systems and solutions designed, tested, and documented to facilitate faster, more reliable, and more predictable customer deployments. For more information, go to: <http://www.cisco.com/go/designzone>.

Executive Summary

Digital transformation has brought significant benefits to organizations, including increased agility and flexibility, but it has also led to a rise in cyber attack vectors. 66 percent of organizations were hit with ransomware within the last year, according to a 2022 [Sophos survey](#). The widespread adoption of cloud services and Software-as-a-Service (SaaS) applications has expanded the attack surface, making it more challenging to manage and secure data. Additionally, the increased use of mobile devices and remote work have made it easier for cybercriminals to launch attacks from anywhere, at any time.

Rubrik Security Cloud is the leading data security platform built upon a unique backup architecture that secures data. Rubrik is designed with zero trust principles to incorporate a logical air gap, secure protocols, native immutability, encryption, and access controls. The principal economic benefit of Rubrik is reduced costs associated with combating cyber threats. Data Protection safeguards data with secure backups. Data Threat Analytics makes it easy to monitor data risk and investigate threats faster. Data Security Posture helps to proactively reduce data exposure risk. Cyber Recovery helps restore business operations faster.

Rubrik Security Cloud on Cisco UCS C-Series systems, managed through Cisco Intersight provides an appliance-like deployment model. Business resilience, agility, flexibility, and orchestration of resources at scale across the edge, public, and private cloud environments are a key value differentiators of this joint solution.

This Cisco Validated Design and Deployment Guide provides prescriptive guidance for the design, setup, configuration, and ongoing use of the Rubrik Security Cloud on the Cisco UCS C-Series Rack System. Together, Cisco and Rubrik deliver the unified computing and Zero Trust Data Security capabilities you need to meet the demands for increased development agility and management of distributed environments, while ensuring your data is resilient against cyber-attacks, malicious insiders, and operational disruptions.

Solution Overview

This chapter contains the following:

- [Audience](#)
- [Purpose of this Document](#)
- [Solution Summary](#)

With Rubrik, organizations can be confident that their critical data is safe from deletion, compromise, or encryption. This is because air-gapped, immutable, access-controlled backups enable organizations to withstand cyberattacks, malicious insiders, and operational disruptions. Data is stored in an immutable format and cannot be read, modified, or deleted. Additionally, data is encrypted in-flight and at rest, and backup data is stored in a purpose-built append-only file system.

Lastly, backed up data is logically air-gapped so it's offline and not accessible through standard network protocols. System interfaces are secure, role-based, least privileged, and protected by multifactor authentication (MFA) to further reduce the risk of intrusion.

Data Resilience services include:

- Enterprise Data Protection – to keep your enterprise data safe from attacks or disasters.
- Cloud Data Protection – to ensure your cloud data is secure from compromise.
- SaaS Data Protection – to secure your SaaS application data with automated protection.
- Unstructured Data Protection – to protect, monitor, and rapidly recover unstructured data at petabyte-scale.

The Rubrik CDM joint solution with Cisco UCS, provides customers with a solution that is easy to deploy, manage and expand as per the growing demands of data protection workloads. Besides the best in class cyber security Rubrik solution, the security of the Cisco UCS platform starts with Cisco's value chain or supply chain security, through a layered approach to the manufacturing facilities – all to ensure that there's no tampering happening while the platform is being built. Cisco UCS products are designed and tested to Cisco's rigorous security framework, using the latest technologies for prevention, and following comprehensive cybersecurity programs.

The Cisco Intersight platform uses a layered security architecture that builds on industry-standard security technologies. It also encrypts data, complies with strict Cisco security and data handling standards, and separates management and IT production network traffic for additional isolation. As a result, you can have confidence that your cloud-based systems management platform offers the strong security you require.

Audience

The intended audience for this document includes, but is not limited to, sales engineers, field consultants, professional services, IT managers, IT engineers, partners, and customers who are interested in learning about and deploying a secure, and scalable data protection solution for backup and recovery of workloads.

Purpose of this Document

This document describes the design, configuration, deployment steps for the Rubrik CDM on Cisco UCS C-Series platform managed through Cisco Intersight.

Solution Summary


This solution provides a reference architecture and validated deployment procedure for the Rubrik CDM on Cisco UCS C-Series platform managed through Cisco Intersight.

The key elements of this solution are as follows:

- Cisco Intersight—is a cloud operations platform that delivers intelligent visualization, optimization, and orchestration for applications and infrastructure across public cloud and on-premises environments. Cisco Intersight provides an essential control point for customers to get more value from hybrid IT investments by simplifying operations across on-prem and their public clouds, continuously optimizing their multi cloud environments and accelerating service delivery to address business needs.
- Cisco UCS C-Series platform— The Cisco UCS C240 M6 Rack Server is a 2-socket, 2-Rack-Unit (2RU) rack server offering industry-leading performance and expandability. It supports a wide range of storage and I/O-intensive infrastructure workloads, from big data and analytics to collaboration. Cisco UCS C-Series M6 Rack Servers can be deployed as standalone servers or as part of a Cisco Unified Computing System (Cisco UCS) managed environment, and now with Cisco Intersight is able to take advantage of Cisco’s standards-based unified computing innovations that help reduce customers’ Total Cost of Ownership (TCO) and increase their business agility.
- Rubrik Security Cloud — Rubrik Security Cloud gives organizations a single place to secure their data wherever it lives—across enterprise, cloud, and SaaS applications.

[Figure 1](#) illustrates the deployment overview of the Rubrik Security Cloud on Cisco UCS.

Figure 1. Solution Overview



Technology Overview


This chapter contains the following:

- [Cisco Intersight Platform](#)
- [Cisco UCS C240 M6 Large Form Factor \(LFF\) Rack Server](#)
- [Rubrik Security Cloud](#)

These components deployed in this solution are configured using best practices from both Cisco and Rubrik to deliver an enterprise-class data protection solution deployed on Cisco UCS C-Series Rack Servers. The upcoming sections provide a summary of the key features and capabilities available in these components.

Cisco Intersight Platform

As applications and data become more distributed from core data center and edge locations to public clouds, a centralized management platform is essential. IT agility will be a struggle without a consolidated view of the infrastructure resources and centralized operations. Cisco Intersight provides a cloud-hosted, management and analytics platform for all Cisco HyperFlex, Cisco UCS, and other supported third-party infrastructure deployed across the globe. It provides an efficient way of deploying, managing, and upgrading infrastructure in the data center, ROBO, edge, and co-location environments.



Cisco Intersight provides:

- **No Impact Transition:** Embedded connector (Cisco HyperFlex, Cisco UCS) will allow customers to start consuming benefits without forklift upgrade.
- **SaaS/Subscription Model:** SaaS model provides for centralized, cloud-scale management and operations across hundreds of sites around the globe without the administrative overhead of managing the platform.
- **Enhanced Support Experience:** A hosted platform allows Cisco to address issues platform-wide with the experience extending into TAC supported platforms.
- **Unified Management:** Single pane of glass, consistent operations model, and experience for managing all systems and solutions.

- Programmability: End to end programmability with native API, SDK's and popular DevOps toolsets will enable customers to deploy and manage the infrastructure quickly and easily.
- Single point of automation: Automation using Ansible, Terraform and other tools can be done through Intersight for all systems it manages.
- Recommendation Engine: Our approach of visibility, insight and action powered by machine intelligence and analytics provide real-time recommendations with agility and scale. Embedded recommendation platform with insights sourced from across Cisco install base and tailored to each customer.

In this solution, Cisco Intersight provides a single global SaaS platform allowing management of Cisco C-Series Rack servers running the Rubrik CDM deployed across multiple data centers, edge, or remote sites. The life cycle management capabilities that Cisco Intersight offers allows easier Day 0 deployment, continuous monitoring of infrastructure, proactive RMAs, firmware upgrades and easier expansion of Rubrik CDM Clusters.

For more information, go to the Cisco Intersight product page on cisco.com.

Cisco Intersight Virtual Appliance and Private Virtual Appliance

In addition to the SaaS deployment model running on Intersight.com, you can purchase on-premises options separately. The Cisco Intersight virtual appliance and Cisco Intersight private virtual appliance are available for organizations that have additional data locality or security requirements for managing systems. The Cisco Intersight virtual appliance delivers the management features of the Cisco Intersight platform in an easy-to-deploy VMware Open Virtualization Appliance (OVA) or Microsoft Hyper-V Server virtual machine that allows you to control the system details that leave your premises. The Cisco Intersight private virtual appliance is provided in a form factor designed specifically for users who operate in disconnected (air gap) environments. The private virtual appliance requires no connection to public networks or to Cisco network.

Cisco Intersight Assist

Cisco Intersight Assist helps you add endpoint devices to the Cisco Intersight platform. A datacenter could have multiple devices that do not connect directly with the platform. Any device that the Cisco Intersight platform supports but does not connect with directly must have a connection mechanism, and Cisco Intersight Assist provides it. In FlashStack, VMware vCenter and Pure Storage FlashArray connect to the Intersight platform with the help of the Cisco Intersight Assist virtual machine.

Cisco Intersight Assist is available within the Cisco Intersight virtual appliance, which is distributed as a deployable virtual machine contained within an OVA file format. Later sections in this paper have more details about the Cisco Intersight Assist virtual-machine deployment configuration.

Licensing Requirements

The Cisco Intersight platform uses a subscription-based license with multiple tiers. You can purchase a subscription duration of 1, 3, or 5 years and choose the required Cisco UCS server volume tier for the selected subscription duration. Each Cisco endpoint automatically includes a Cisco Intersight Base license at no additional cost when you access the Cisco Intersight portal and claim a device. You can purchase any of the following higher-tier Cisco Intersight licenses using the Cisco ordering tool:

- Cisco Intersight Essentials: Essentials includes all the functions of the Base license plus additional features, including Cisco UCS Central software and Cisco Integrated Management Controller (IMC) supervisor entitlement, policy-based configuration with server profiles, firmware management, and evaluation of compatibility with the Cisco Hardware Compatibility List (HCL).
- Cisco Intersight Advantage: Advantage offers all the features and functions of the Base and Essentials tiers. It also includes storage widgets and cross-domain inventory correlation across compute, storage,

and virtual environments (VMware ESXi). OS installation for supported Cisco UCS platforms is also included.

Servers in the Cisco Intersight managed mode require at least the Essentials license. For more information about the features provided in the various licensing tiers, see:

https://www.intersight.com/help/saas/getting_started/licensing_requirements

Cisco UCS C240 M6 Large Form Factor (LFF) Rack Server

The Cisco UCS C240 M6 Rack Server is a 2-socket, 2-Rack-Unit (2RU) rack server offering industry-leading performance and expandability. It supports a wide range of storage and I/O-intensive infrastructure workloads, from big data and analytics to collaboration. Cisco UCS C-Series M6 Rack Servers can be deployed as standalone servers or as part of a Cisco Unified Computing System (Cisco UCS) managed environment, and now with Cisco Intersight is able to take advantage of Cisco's standards-based unified computing innovations that help reduce customers' Total Cost of Ownership (TCO) and increase their business agility.

In response to ever-increasing computing and data-intensive real-time workloads, the enterprise-class Cisco UCS C240 M6 server extends the capabilities of the Cisco UCS portfolio in a 2RU form factor. It incorporates 3rd Generation Intel Xeon Scalable processors, supporting up to 40 cores per socket and 33 percent more memory versus the previous generation.

The Cisco UCS C240 M6 rack server brings many new innovations to the Cisco UCS rack server portfolio. With the introduction of PCIe Gen 4.0 expansion slots for high-speed I/O, DDR4 memory bus, and expanded storage capabilities, the server delivers significant performance and efficiency gains that will improve your application performance. Its features including the following:


- Supports the third-generation Intel Xeon Scalable CPU, with up to 40 cores per socket
- Up to 32 DDR4 DIMMs for improved performance, including higher density DDR4 DIMMs (16 DIMMs per socket)
- 16x DDR4 DIMMs + 16x Intel Optane persistent memory modules for up to 12 TB of memory
- Up to 8 PCIe Gen 4.0 expansion slots plus a modular LAN-on-motherboard (mLOM) slot
- Support for Cisco UCS VIC 1400 Series adapters as well as third-party options
- 16 LFF drives with options 4 rear SFF (SAS/SATA/NVMe) disk drives
- Support for a 12-Gbps SAS modular RAID controller in a dedicated slot, leaving the remaining PCIe Gen 4.0 expansion slots available for other expansion cards
- M.2 boot options
- Up to 960 GB with optional hardware RAID
- Up to five GPUs supported
- Modular LAN-on-motherboard (mLOM) slot that can be used to install a Cisco UCS Virtual Interface Card (VIC) without consuming a PCIe slot, supporting quad port 10/40 Gbps or dual port 40/100 Gbps network connectivity
- Dual embedded Intel x550 10GBASE-T LAN-on-motherboard (LOM) ports
- Modular M.2 SATA SSDs for boot

For more details and specification, go to: <https://www.cisco.com/c/dam/en/us/products/collateral/servers-unified-computing/ucs-c-series-rack-servers/c240m6-lff-specsheet.pdf>

Figure 2. Front View: Cisco UCS C240 M6 Large Form Factor (LFF) server



Figure 3. Rear View : Cisco UCS C240 M6 Large Form Factor (LFF) server



Cisco UCS VICs

Cisco UCS C240 M6 Rack Server support the following Cisco MLOM VICs and PCIe VICs:

- Cisco UCS VIC 1467 quad port 10/25G SFP28 mLOM
- Cisco UCS VIC 1477 dual port 40/100G QSFP28 mLOM
- Cisco UCS VIC 15428 quad port 10/25/50G MLOM
- Cisco UCS VIC 15238 dual port 40/100/200G MLOM
- Cisco UCS VIC 15427 Quad Port CNA MLOM with Secure Boot
- Cisco UCS VIC 15237, MLOM, 2x40/100/200G for Rack
- Cisco UCS VIC 1495 Dual Port 40/100G QSFP28 CNA PCIe
- Cisco UCS VIC 1455 quad port 10/25G SFP28 PCIe
- Cisco UCS VIC 15425 Quad Port 10/25/50G CNA PCIE
- Cisco UCS VIC 15235 Dual Port 40/100/200G CNA PCIE

In this configuration with Rubrik CDM, Cisco UCS VIC 1467 quad port 10/25G SFP28 mLOM with deployed on Cisco UCS C240 M6 LFF server.

Cisco UCS VIC 1467


The Cisco UCS VIC 1467 is a quad-port Small Form-Factor Pluggable (SFP28) mLOM card designed for Cisco UCS C-Series M6 Rack Servers. The card supports 10/25-Gbps Ethernet or FCoE. The card can present PCIe standards-compliant interfaces to the host, and these can be dynamically configured as either NICs or HBA. For

more details, go to: <https://www.cisco.com/c/en/us/products/collateral/interfaces-modules/unified-computing-system-adapters/datasheet-c78-741130.html>

Figure 4. Cisco UCS VIC 1467



Figure 5. Cisco UCS VIC 1467 Infrastructure



Cisco UCS 6400 Fabric Interconnects

The Cisco UCS fabric interconnects provide a single point for connectivity and management for the entire Cisco UCS system. Typically deployed as an active-active pair, the fabric interconnects of the system integrate all components into a single, highly available management domain that Cisco UCS Manager or the Cisco Intersight platform manages. Cisco UCS Fabric Interconnects provide a single unified fabric for the system, with low-latency, lossless, cut-through switching that supports LAN, storage-area network (SAN), and management traffic using a single set of cables ([Figure 6](#)).

Figure 6. Cisco UCS 6454 Fabric Interconnect



The Cisco UCS 6454 used in the current design is a 54-port fabric interconnect. This 1RU device includes twenty-eight 10-/25-GE ports, four 1-/10-/25-GE ports, six 40-/100-GE uplink ports, and sixteen unified ports that can support 10-/25-GE or 8-/16-/32-Gbps Fibre Channel, depending on the Small Form-Factor Pluggable (SFP) adapter.

Rubrik Security Cloud

Cyberattacks are increasing in frequency and sophistication. Despite large investments in infrastructure security tools, bad actors are finding their way through to the data. And they know legacy backup tools are vulnerable, so they are increasingly targeting backup data. When a cyberattack takes down data, it takes down businesses. It's time for a new approach. One that marries the investments made in infrastructure security with data security.

Rubrik is on a mission to secure the world's data. With Rubrik Security Cloud, you can automatically protect data from cyberattacks, continuously monitor data risks, and quickly recover data and applications across the enterprise, in the cloud, and in SaaS applications.

- Data Protection: Keep Data Readily Available

Ensure data integrity and availability with automated, secure, and access-controlled backups that are designed to withstand cyberattacks, malicious insiders, and operational disruptions.

- Data Threat Analytics: Monitor Data Risk and Investigate Faster


Continuously monitor for threats to data, including ransomware, data destruction, and indicators of compromise.

- Data Security Posture: Proactively Reduce Risk of Data Exposure

Proactively identify and monitor sensitive data exposure and use intelligent insights to mitigate risks to data.

- Cyber Recovery: Restore Business Operations Faster

Quickly return to business as usual within hours or days, not weeks or months. Orchestration and quarantining enable you to contain threats and rapidly recover your apps, files, or objects while avoiding malware reinfection.



Architecture and Design Considerations

This chapter contains the following:

- [Deployment Architecture for Cisco UCS C240 with Rubrik](#)
- [Network Bond Modes with Rubrik and Fabric Interconnect Managed Systems](#)
- [Licensing](#)
- [Physical Components](#)
- [Software Components](#)

Deployment Architecture for Cisco UCS C240 with Rubrik


The Rubrik CDM on Cisco UCS C-Series requires a minimum four (4) nodes. Each Cisco UCS C240 M6 LFF node is equipped with both the compute and storage required to operate the Rubrik operating system. The entire deployment is managed through Cisco Intersight.

Each Cisco UCS C240 M6 LFF node is equipped with:

- 2x Intel 5318N 2.1GHz/150W 24C/36MB DDR4 2667MHz
- 384 GB DDR4 memory
- 2x 240GB M.2 card managed through M.2 RAID controller, for Rubrik operating system
- 1x 1.6 TB NVMe
- 12x 12TB,12G SAS 7.2K RPM LFF HDD (4K) managed through 1x Cisco M6 12G SAS HBA

[Figure 7](#) illustrates the deployment architecture overview of Rubrik on Cisco UCS C-Series nodes.

Figure 7. Deployment Architecture as captured through Cisco Intersight



[Figure 8](#) illustrates the cabling diagram for Rubrik on the Cisco UCS C-Series Rack Servers.

Figure 8. Deployment Architecture Cabling





Figure 9 illustrates the cabling topology as captured through Cisco Intersight.

Figure 9. Cabling topology as captured through Cisco Intersight



The reference hardware configuration includes:

- Two Cisco Nexus 93360YC-FX Switches in Cisco NX-OS mode provide the switching fabric.
- Two Cisco UCS 6454 Fabric Interconnects (FI) provide the chassis connectivity. One 100 Gigabit Ethernet port from each FI, configured as a Port-Channel, is connected to each Cisco Nexus 93360YC-FX.
- Four (4) Cisco UCS C240 LFF nodes. Each node is equipped with Cisco UCS VIC 1467. The Cisco UCS VIC 1467 is a quad-port Small Form-Factor Pluggable (SFP28) mLOM card designed for Cisco UCS C-Series M6 Rack Servers. Port 1-2 are connected to Server ports on Fabric Interconnect A and Port 3-4 are connected to Server ports on Fabric Interconnect B.
- Cisco Intersight as the SaaS management platform for Cisco UCS Fabric Interconnects and Cisco UCS C-Series Rack Servers.

Note: Do not connect port 1 of the VIC 1467 to Fabric Interconnect A, and then connect port 2 of the VIC 1467 to Fabric Interconnect B. Using ports 1 and 2, each connected to FI A and FI B will lead to discovery and configuration failures.

Note: The Cisco UCS C-Series Servers are connected directly to the Cisco UCS Fabric Interconnects in Direct Connect mode. Internally the Cisco UCS C-Series servers are configured with the PCIe-based system I/O controller for Quad Port 10/25G Cisco VIC 1467. The standard and redundant connection practice is to connect port 1 and port 2 of each server's VIC card to a numbered port on FI A, and port 3 and port 4 of each server's VIC card to the same numbered port on FI B. The design also supports connecting just port 1 to FI A and port 3 to FI B. The use of ports 1 and 3 are because ports 1 and 2 form an internal port-channel, as does ports 3 and 4

Network Bond Modes with Rubrik and Fabric Interconnect Managed Systems

All teaming/bonding methods that are switch independent are supported in the Cisco UCS Fabric Interconnect environment. These bonding modes do not require any special configuration on the switch and Cisco UCS side.

The restriction is that any load balancing method used in a switch independent configuration must send traffic for a given source MAC address via a single Cisco UCS Fabric Interconnect other than in a failover event (where the traffic should be sent to the alternate fabric interconnect) and not periodically to redistribute load.

Using other load balancing methods that operate on mechanisms beyond the source MAC address (such as IP address hashing, TCP port hashing, and so on) can cause instability since a MAC address is flapped between UCS Fabric Interconnects. This type of configuration is unsupported.

Switch dependent bonding modes require a port-channel to be configured on the switch side. The fabric interconnect, which is the switch in this case, cannot form a port-channel with the VIC card present in the servers. Furthermore, such bonding modes will also cause MAC flapping on Cisco UCS and upstream switches and is unsupported.

Cisco UCS Servers with Linux Operating System and managed through fabric interconnects, support active-backup (mode 1), balance-tlb (mode 5) and balance-alb (mode 6). The networking mode in the Rubrik operating system (Linux based) deployed on Cisco UCS C-Series managed through a Cisco UCS Fabric Interconnect is validated with bond mode 1 (active-backup). For reference, go to:

<https://www.cisco.com/c/en/us/support/docs/servers-unified-computing/ucs-b-series-blade-servers/200519-UCS-B-series-Teaming-Bonding-Options-wi.html>

Licensing

Cisco Intersight Licensing

Cisco Intersight uses a subscription-based license with multiple tiers. Each Cisco automatically includes a Cisco Intersight Essential trial license when you access the Cisco Intersight portal and claim a device.

More information about Cisco Intersight Licensing and the features supported in each license can be found here: <https://www.cisco.com/site/us/en/products/computing/hybrid-cloud-operations/intersight-infrastructure-service/licensing.html>

In this solution, using Cisco Intersight Advantage License Tier enables the following:

- Configuration of Domain and Server Profiles for Rubrik on Cisco UCS C-Series Rack Servers.
- Rubrik OS installation on Cisco UCS C-Series nodes through Cisco Intersight. This requires enabling an NFS/SMB/HTTPS repository which has the certified Rubrik CDM software.

Physical Components

This section details the physical hardware, software revisions, and firmware versions required to install Rubrik CDM Clusters running on Cisco Unified Computing System. A Rubrik on-premises cluster requires a minimum of four physical nodes deployed either on Cisco UCS C-Series Rubrik-certified nodes.

[Table 1](#) lists the required hardware components and disk options for the Rubrik CDM on Cisco UCS C-Series Rack Servers.

Table 1. Cisco UCS C-Series nodes for the Rubrik CDM

Component		Hardware
Fabric Interconnects		Two (2) Cisco UCS 6454 Fabric Interconnects
Server Node		4x Cisco UCS C240 M6 LFF Server Node for Intel Scalable CPUs
Processors		Each server node equipped with two Intel 5318N 2.1GHz/150W 24C/36MB
Memory		Each server node equipped with 384 GB of total memory using twelve (12) 32GB RDIMM DRx4 3200 (8Gb)
Disk Controller		Cisco M6 12G SAS HBA
Storage (each server node)	OS Boot	2x M.2 (240GB) with M.2 HW RAID Controller
	Caching	1x 1.6 TB NVMe
	Storage	12x 12TB 12G SAS 7.2K RPM LFF HDD (4K)
Network (Each Server node)		Cisco UCS VIC 1467 4x25G mLOM

Software Components

[Table 2](#) lists the software components and the versions required for the Rubrik CDM and Cisco UCS C-Series nodes managed through Cisco UCS Fabric Interconnect in Intersight Managed mode (IMM), as tested, and validated in this document.

Table 2. Software Components

Component	Version
Rubrik CDM	rubrik_os_8.1.3-p6-25150_iv_3.5.0-138
Cisco Fabric Interconnect 6454	4.2 (3h)
Cisco UCS C240 M6 LFF servers	4.2 (3h)

Solution Deployment

This chapter contains the following:

- [Prerequisites](#)
- [Create Cisco Intersight Account](#)
- [Set up Intersight Managed Mode \(IMM\)](#)
- [Set up Domain Profile](#)
- [Manual Set up Server Template](#)
- [Install Rubrik CDM on Cisco UCS C-Series Nodes](#)
- [Configure Rubrik CDM Cluster](#)

This chapter describes the solution deployment for Rubrik CDM on Cisco UCS C-Series Rack Servers in Intersight Managed Mode (IMM), with step-by-step procedures for implementing and managing the solution.

Prerequisites

Prior to beginning the installation activities, complete the following necessary tasks and gather the required information.

IP addressing

IP addresses for the Rubrik CDM on Cisco UCS, need to be allocated from the appropriate subnets and VLANs to be used. IP addresses that are used by the system are comprised of the following groups:

- **Cisco UCS Management:** These addresses are used and assigned as management IPs for Cisco UCS Fabric interconnects. Two out of band, IP addresses are used; one address is assigned to each Cisco UCS Fabric Interconnect, this address should be routable to <https://intersight.com> or you can have proxy configuration.
- **Cisco UCS C240 M6 LFF node management:** Each Cisco UCS C240 M6 LFF server/node, is managed through an IMC Access policy mapped to IP pools through the Server Profile. Both In-Band or Out of Band configuration is supported for IMC Access Policy. One IP is allocated to each of the node configured through In-Band or Out of Band access policy. In the present configuration each Rubrik node is allocated both In-Band and Out of Band Access Policy. This allocates (two)2 IP addresses for each node using the IMC Access Policy
- **Rubrik Operating System IP:** These addresses are used by the Linux OS on each Rubrik node. One IP addresses per node required from the same subnet. Rubrik node is configured with bond0 and bond1 as two separate networks. Both bond0 and bond1 networks support active-passive failover mode. Only bond0 network should configured for Cisco C-Series nodes connected to Cisco Fabric Interconnect. Once the Rubrik CDM software is installed on each node, Both Rubrik Management and Rubrik Data network are allocated in the same VLAN and configured in bond0 network.
- Once Rubrik cluster is configured, Customers have the option to configure sub-interfaces for Rubrik nodes. This allows accessibility to **multiple networks** through different VLANs.

[Figure 10](#) elaborates on the network port (bond0). Only bond0 port should be configured for Cisco C-Series nodes connected to Cisco Fabric Interconnect.

Figure 10. Network Port configuration for Rubrik nodes

```

Checking networking ports...
Port | Device | Driver | State | Link | Speed
-----|-----|-----|-----|-----|-----
bond0 | | | up | yes | 50000Mb/s
bond1 | | | down | no | Unknown!
eth0 | Cisco VIC NIC (rev a2) | enic | down | no | Unknown!
eth1 | Cisco VIC NIC (rev a2) | enic | down | no | Unknown!
rketh0 | Intel 10G X550T | ixgbe | down | no | Unknown!
rketh1 | Intel 10G X550T | ixgbe | down | no | Unknown!
rketh2 | Cisco VIC NIC (rev a2) | enic | up | yes | 50000Mb/s
rketh3 | Cisco VIC NIC (rev a2) | enic | up | yes | 50000Mb/s

Bond0 Mode is fault-tolerance (active-backup)
Bond0 bond ports are: rketh2 rketh3
Current active port is rketh3

Bond1 Mode is fault-tolerance (active-backup)
Bond1 bond ports are: rketh0 rketh1
Current active port is None
WARNING: Bond1 has no active ports and is not operational.

-----
Checking for MCEs...
/var/log/mcelog is clean

-----
FRU Replacement Summary:
All FRUS in the node are healthy.
RC240WZP2649215W >>
RC240WZP2649215W >>
RC240WZP2649215W >>
RC240WZP2649215W >>

```

Note: *OS Installation through Intersight* for FI-attached servers in IMM requires an In-Band Management IP address.(ref: https://intersight.com/help/saas/resources/adding_OSimage). Deployments not using In-Band Management address can install OS by mounting the ISO through KVM.

Note: Rubrik CDM deployed on Cisco UCS C-Series Servers and attached to Cisco UCS Fabric Interconnect **do not support IPMI configuration**. In this configuration, Cisco UCS C-Series nodes are attached to Cisco Fabric Interconnect and do not utilize IPMI configuration. Therefore, in the below table the IPMI IPs are configured as 0.0.0.x

Note: Administrators deploying Rubrik CDM on standalone Cisco C-Series servers (not attached to Cisco Fabric Interconnect) **can use the node CIMC address as the IPMI IP**.

Note: Use the following tables to list the required IP addresses for the installation of a 4-node Rubrik CDM cluster and review an example IP configuration.

Note: Table cells shaded in black do not require an IP address.

Table 3. Rubrik Cluster IP Addressing

Address Group:	UCS Management		Rubrik CDM Nodes	
	KVM Management Addresses (Out of Band)	KVM Management Addresses (In-Band)	Node IP	Node IPMI IP
VLAN ID:				
Subnet Mask:				
Gateway:				
DNS				
NTP				
Device	KVM Management Addresses (Out of Band)	KVM Management Addresses (In-Band)	Node IP	Node IPMI IP
Fabric Interconnect A				
Fabric Interconnect B				
Rubrik Node #1				
Rubrik Node #2				
Rubrik Node #3				
Rubrik Node #4				

Note: [Table 4](#) is a true representation of configuration deployed during Solution Validation.

Table 4. Example Rubrik Cluster IP Addressing

Address Group:	UCS Management		Rubrik CDM Nodes	
VLAN ID:	KVM Management Addresses (Out of Band)	KVM Management Addresses (In-Band)	Node IP	Node IPMI IP
Subnet Mask:	255.255.255.0	255.255.255.0	255.255.255.0	0.0.0.0
Gateway:	10.108.0.254	10.108.1.254	10.108.0.254	0.0.0.0
DNS	10.108.1.6		10.108.1.6	
NTP	172.20.10.18		172.20.10.18	
Device	KVM Management Addresses (Out of Band)	KVM Management Addresses (In-Band)	Node IP	Node IPMI IP
Fabric Interconnect A	10.108.0.161			
Fabric Interconnect B	10.108.0.162			
Rubrik Node #1	10.108.0.163	10.108.0.167	10.108.1.163	0.0.0.1
Rubrik Node #2	10.108.0.164	10.108.0.168	10.108.1.164	0.0.0.2
Rubrik Node #3	10.108.0.165	10.108.0.169	10.108.1.165	0.0.0.3
Rubrik Node #4	10.108.0.166	10.108.0.170	10.108.1.166	0.0.0.4

VLANs

Prior to the installation, the required VLAN IDs need to be documented, and created in the upstream network if necessary. In present deployment the Rubrik Management and Backup Data traffic exist in the same VLAN on bond0 network. Customers can segregate Rubrik Management and Backup Data traffic by defining separate VLAN for Rubrik Management and Backup Data. Once the Rubrik cluster is bootstrapped and registered, customers can create sub-interfaces to segregate management and backup traffic.

Note: Ensure all VLANs are part of LAN Connectivity Policy defined in Cisco Server Profile for each C-Series node

Use the following tables to list the required VLAN information for the installation and review an example configuration.

Table 5. VLAN Information

Name	ID
<<rubrik-management-vlan>>	1081
<<rubrik-data-vlan>>	1081

Network Uplinks

The Cisco UCS uplink connectivity design needs to be finalized prior to beginning the installation.

Use the following tables to list the required network uplink information for the installation and review an example configuration.

Table 6. Network Uplink Configuration

Fabric Interconnect Port		Port Channel	Port Channel Type	Port Channel ID	Port Channel Name
A		<input type="checkbox"/> Yes <input type="checkbox"/> No	<input type="checkbox"/> LACP		
		<input type="checkbox"/> Yes <input type="checkbox"/> No	<input type="checkbox"/> vPC		
		<input type="checkbox"/> Yes <input type="checkbox"/> No			
		<input type="checkbox"/> Yes <input type="checkbox"/> No			
B		<input type="checkbox"/> Yes <input type="checkbox"/> No	<input type="checkbox"/> LACP		
		<input type="checkbox"/> Yes <input type="checkbox"/> No	<input type="checkbox"/> vPC		
		<input type="checkbox"/> Yes <input type="checkbox"/> No			
		<input type="checkbox"/> Yes <input type="checkbox"/> No			

Table 7. Network Uplink Example Configuration

Fabric Interconnect Port		Port Channel	Port Channel Type	Port Channel ID	Port Channel Name
A	1/53	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No	<input type="checkbox"/> LACP	61	Vpc61
	1/54	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No	<input checked="" type="checkbox"/> vPC		
		<input type="checkbox"/> Yes <input type="checkbox"/> No			
		<input type="checkbox"/> Yes <input type="checkbox"/> No			
B	1/53	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No	<input type="checkbox"/> LACP	62	Vpc62
	1/54	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No	<input checked="" type="checkbox"/> vPC		
		<input type="checkbox"/> Yes <input type="checkbox"/> No			
		<input type="checkbox"/> Yes <input type="checkbox"/> No			

Create Cisco Intersight Account


Procedure 1. Create an account on Cisco Intersight

Note: Skip this step if you already have a Cisco Intersight account.

The procedure to create an account in Cisco Intersight is explained below. For more details, go to: https://intersight.com/help/saas/getting_started/create_cisco_intersight_account


Step 1. Go to <https://intersight.com/> to create your Intersight account. You must have a valid Cisco ID to create a Cisco Intersight account.

Step 2. Click Create an account.




Step 3. Sign-In with your Cisco ID.

Step 4. Read the End User License Agreement and select I accept and click Next.




Step 5. Provide a name for the account and click Create.



The screenshot shows the Cisco Intersight interface. In the top left corner, the Cisco Intersight logo is displayed. A white dialog box titled "Account Creation" is centered on the screen. Inside the dialog box, there is a text input field labeled "Account Name *" with the text "Ru-DataProtection" entered. Below the input field, there are two buttons: "Cancel" and "Create".

Step 6. Register for Smart Licensing or Start Trial.



The screenshot shows the "Licensing" page. The title "Licensing" is centered at the top. Below the title, there is a paragraph of text: "If you have purchased license tiers for Cisco Intersight Services you can register smart licensing to start using the services." Below this text is a blue button labeled "Register Smart Licensing". A horizontal line with the word "Or" in the center separates this section from the next. Below the line, there is another paragraph of text: "If you would like to evaluate Intersight Services you can register for a trial." Below this text is a blue button labeled "Start Trial".

Step 7. Select Infrastructure Service & Cloud Orchestrator and click Start Trial.

Start Trial

Select the Intersight Service to request trial.

Infrastructure Service & Cloud Orchestrator
90 days trial

Workload Optimizer **Registration Required**
45 days trial

Cancel

Start Trial

Note: Go to: <https://intersight.com/help/saas> to configure Cisco Intersight Platform.

Set up Intersight Managed Mode (IMM)

Procedure 1. Set up Cisco Intersight Managed Mode on Cisco UCS Fabric Interconnects

The Cisco UCS fabric interconnects need to be set up to support Cisco Intersight managed mode. When converting an existing pair of Cisco UCS fabric interconnects from Cisco UCS Manager mode to Intersight Managed Mode (IMM), first erase the configuration and reboot your system.

Note: Converting fabric interconnects to Cisco Intersight managed mode is a disruptive process, and configuration information will be lost. You are encouraged to make a backup of their existing configuration. If a software version that supports Intersight Managed Mode (4.1(3) or later) is already installed on Cisco UCS Fabric Interconnects, do not upgrade the software to a recommended recent release using Cisco UCS Manager. The software upgrade will be performed using Cisco Intersight

Step 1. Configure Fabric Interconnect A (FI-A). On the Basic System Configuration Dialog screen, set the management mode to Intersight. All the remaining settings are similar to those for the Cisco UCS Manager Managed Mode (UCSM-Managed).

Cisco UCS Fabric Interconnect A

To configure the Cisco UCS for use in a FlexPod environment in ucsm managed mode, follow these steps: Connect to the console port on the first Cisco UCS fabric interconnect.

```
Enter the configuration method. (console/gui) ? console
```

```
Enter the management mode. (ucsm/intersight)? intersight
```

```
The Fabric interconnect will be configured in the intersight managed mode. Choose (y/n) to proceed: y
```

```
Enforce strong password? (y/n) [y]: Enter
```

```
Enter the password for "admin": <password>
```

```
Confirm the password for "admin": <password>
```

```
Enter the switch fabric (A/B) []: A
```

```
Enter the system name: <ucs-cluster-name>
```

```
Physical Switch Mgmt0 IP address : <ucsa-mgmt-ip>
```

```
Physical Switch Mgmt0 IPv4 netmask : <ucs-mgmt-mask>
```

```

IPv4 address of the default gateway : <ucs-mgmt-gateway>

DNS IP address : <dns-server-1-ip>

Configure the default domain name? (yes/no) [n]: n

Default domain name :

Following configurations will be applied:

Management Mode=intersight
Switch Fabric=A
System Name=<ucs-cluster-name>
Enforced Strong Password=yes
Physical Switch Mgmt0 IP Address=<ucsa-mgmt-ip>
Physical Switch Mgmt0 IP Netmask=<ucs-mgmt-mask>
Default Gateway=<ucs-mgmt-gateway>
DNS Server=<dns-server-1-ip>

Apply and save the configuration (select 'no' if you want to re-enter)? (yes/no): yes

```

Step 2. After applying the settings, make sure you can ping the fabric interconnect management IP address. When Fabric Interconnect A is correctly set up and is available, Fabric Interconnect B will automatically discover Fabric Interconnect A during its setup process as shown in the next step.

Step 3. Configure Fabric Interconnect B (FI-B). For the configuration method, select console. Fabric Interconnect B will detect the presence of Fabric Interconnect A and will prompt you to enter the admin password for Fabric Interconnect A. Provide the management IP address for Fabric Interconnect B and apply the configuration.

```

Cisco UCS Fabric Interconnect B
Enter the configuration method. (console/gui) ? console

Installer has detected the presence of a peer Fabric interconnect. This Fabric interconnect will be added
to the cluster. Continue (y/n) ? y

Enter the admin password of the peer Fabric interconnect: <password>
Connecting to peer Fabric interconnect... done
Retrieving config from peer Fabric interconnect... done
Peer Fabric interconnect Mgmt0 IPv4 Address: <ucsa-mgmt-ip>
Peer Fabric interconnect Mgmt0 IPv4 Netmask: <ucs-mgmt-mask>

Peer FI is IPv4 Cluster enabled. Please Provide Local Fabric Interconnect Mgmt0 IPv4 Address

Physical Switch Mgmt0 IP address : <ucsb-mgmt-ip>

Apply and save the configuration (select 'no' if you want to re-enter)? (yes/no): yes

```

Procedure 2. Set Up Cisco Intersight Resource Groups

A Resource Group represents a collection of resources. You can create a Resource Group to classify and manage resources. Resource Groups can be used for assigning resources to an organization. For more information, go to: <https://intersight.com/help/saas/resources/RBAC#role-based-access-control-in-intersight>

Note: In Cisco Intersight, all the resources and configurations in existing user accounts will automatically be placed in a default Resource Group, titled default Resource Group.


In this procedure, a Cisco Intersight organization is created where all Cisco Intersight Managed Mode configurations, including policies, are defined.

Step 1. Log into the Cisco Intersight portal.


Step 2. Select System. Click Settings (the gear icon).

Step 3. Click Organizations.

Step 4. Click + Create Resource Groups.



Step 5. Provide a name for the Resource group and click Create




Procedure 3. Set Up Cisco Intersight Organization

An organization is a logical entity which enables multi-tenancy through separation of resources in an account. The organization allows you to use the Resource Groups and enables you to apply the configuration settings on a subset of targets.

Note: Administrators can use “default” organization. “Default” organization is automatically created once an Intersight account is created.

In this procedure, a Cisco Intersight organization is created where all Cisco Intersight Managed Mode configurations, including policies, are defined.

- Step 1.** Log into the Cisco Intersight portal.
- Step 2.** Select System. Click Settings (the gear icon).
- Step 3.** Click Organizations.
- Step 4.** Click + Create Organization
- Step 5.** Provide a name for the organization (for example, Ru-Org).
- Step 6.** Select the Resource Group created in the last step (for example, Ru-ResourceGroup).
- Step 7.** Click Create.



Procedure 4. Claim Cisco UCS Fabric Interconnects in Cisco Intersight

Note: Make sure the initial configuration for the fabric interconnects has been completed. Log into the Fabric Interconnect A Device Console using a web browser to capture the Cisco Intersight connectivity information.

- Step 1.** Use the management IP address of Fabric Interconnect A to access the device from a web browser and the previously configured admin password to log into the device.
- Step 2.** Under DEVICE CONNECTOR, the current device status will show “Not claimed.” Note or copy, the Device ID, and Claim Code information for claiming the device in Cisco Intersight.

DEVICE CONSOLE AA08-XSeries

SYSTEM INFORMATION **DEVICE CONNECTOR** INVENTORY DIAGNOSTIC DATA

The Device Connector is an embedded management controller that enables the capabilities of Cisco Intersight, a cloud-based management platform. For detailed information about configuring the device connector, please visit [Help Center](#)

Device Connector

Settings Refresh

ACCESS MODE ALLOW CONTROL

Device Connector Internet Intersight

Not Claimed

The connection to the Cisco Intersight Portal is successful, but device is still not claimed. To claim the device open Cisco Intersight, create a new account and follow the guidance or go to the Targets page and click Claim a New Device for existing account. [Open Intersight](#)

1.0.11-3179

Step 3. Log into Cisco Intersight.

Step 4. Select System. Click Admin > Targets.

Step 5. Click Claim a New Target.

Step 6. Select Cisco UCS Domain (Intersight Managed) and click Start.

Claim a New Target

Select Target Type

Filters

Available for Claiming

Categories

- All
- Cloud
- Compute / Fabric
- Hyperconverged
- Network
- Orchestrator
- Platform Services

Search

Compute / Fabric

- Cisco UCS Server (Standalone)
- Cisco UCS Domain (Intersight Managed)
- Cisco UCS Domain (UCSM Managed)
- Cisco UCS C890
- Redfish Server

Platform Services

- Cisco Intersight Appliance
- Cisco Intersight Assist
- Intersight Workload Engine

Cloud

- Terraform Cloud

Orchestrator

- Cisco UCS Director
- PowerShell Endpoint
- HTTP Endpoint
- Ansible Endpoint
- SSH Endpoint


Hyperconverged

- Cisco HyperFlex Cluster


Cancel

Start

Step 7. Copy and paste the Device ID and Claim from the Cisco UCS FI to Intersight, select the Resource Group created in previous section and click Claim.



With a successful device claim, Cisco UCS FI should appear as a target in Cisco Intersight:




Step 8. In the Cisco Intersight window, click Settings and select Licensing. If this is a new account, all servers connected to the Cisco UCS domain will appear under the Base license tier. If you have purchased Cisco Intersight licenses and have them in your Cisco Smart Account, click Register and follow the prompts to register this Cisco Intersight account to your Cisco Smart Account. Cisco Intersight also offers a one-time 90-day trial of Advantage licensing for new accounts. Click Start Trial and then Start to begin this evaluation. The remainder of this section will assume Advantage licensing. A minimum of Cisco Intersight Essentials licensing is required to run the Cisco UCS C-Series platform in Intersight Managed Mode (IMM).


Procedure 5. Verify Addition of Cisco UCS Fabric Interconnects to Cisco Intersight

Step 1. Log into the web GUI of the Cisco UCS fabric interconnect and click the browser refresh button.

The fabric interconnect status should now be set to **Claimed**.



Step 2. Select Infrastructure Service.



Step 3. Go to the Fabric Interconnects tab and verify the pair of fabric interconnects are visible on the Intersight dashboard.

Step 4. You can verify whether a Cisco UCS fabric interconnect is in Cisco UCS Manager Managed Mode or Cisco Intersight managed mode by clicking the fabric interconnect name and looking at the detailed information screen for the fabric interconnect, as shown below:

Procedure 6. Upgrade Fabric Interconnect Firmware using Cisco Intersight

Note: If your Cisco UCS 6454 Fabric Interconnects are not already running firmware release 4.2(2c), upgrade them to 4.2(3d) or to the recommended release.

Note: If Cisco UCS Fabric Interconnects were upgraded to the latest recommended software using Cisco UCS Manager, this upgrade process through Intersight will still work and will copy the Cisco UCS firmware to the Fabric Interconnects.

Note: By default, Fabric Interconnect upgrades through Intersight are enabled with 'Fabric Interconnect Traffic Evacuation'. Since the present procedure is a new setup with no Domain Profile associated, Use Advanced Mode to exclude Fabric Interconnect traffic evacuation.

Step 1. Log into the Cisco Intersight portal.

Step 2. From the drop-down list, select Infrastructure Service and then select Fabric Interconnects under Operate.

Step 3. Click the ellipses “...” for either of the Fabric Interconnects and select Upgrade Firmware.

Step 4. Click Start.

Step 5. Verify the Fabric Interconnect information and click Next.

Step 6. Enable Advanced Mode and uncheck Fabric Interconnect traffic evacuation. This is only for new setup of Fabric Interconnects.


Step 7. Select 4.2(3d) release (or the latest release which has the Recommended icon) from the list and click Next.

Step 8. Verify the information and click Upgrade to start the upgrade process.

Step 9. Watch the Request panel of the main Intersight screen as the system will ask for user permission before upgrading each FI. Click the Circle with Arrow and follow the prompts on screen to grant permission.

Step 10. Wait for both the FIs to successfully upgrade.

Step 11. Snap shot below details in the Fabric Interconnect upgrade to firmware version 4.2(3d)



Set up Domain Profile

A Cisco UCS domain profile configures a fabric interconnect pair through reusable policies, allows configuration of the ports and port channels, and configures the VLANs and VSANs in the network. It defines the characteristics of and configured ports on fabric interconnects. The domain-related policies can be attached to the profile either at the time of creation or later. One Cisco UCS domain profile can be assigned to one fabric interconnect domain.

Some of the characteristics of the Cisco UCS domain profile for Rubrik environment include:

- A single domain profile is created for the pair of Cisco UCS fabric interconnects.

- Unique port policies are defined for the two fabric interconnects.
- The VLAN configuration policy is common to the fabric interconnect pair because both fabric interconnects are configured for the same set of VLANs.
- The Network Time Protocol (NTP), network connectivity, and system Quality-of-Service (QoS) policies are common to the fabric interconnect pair.


Next, you need to create a Cisco UCS domain profile to configure the fabric interconnect ports and discover connected chassis. A domain profile is composed of several policies. [Table 8](#) lists the policies required for the solution described in this document.

Table 8. Policies required for a Cisco UCS Domain Profile


Policy	Description
VLAN and VSAN Policy	Network connectivity
Port configuration policy for fabric A	Definition of Server Ports, FC ports and uplink ports channels
Port configuration policy for fabric B	Definition of Server Ports, FC ports and uplink ports channels
Network Time Protocol (NTP) policy	
Syslog policy	
System QoS	

Procedure 1. Create VLAN configuration Policy


Step 1. Select Infrastructure Services.



Step 2. Under Policies, select Policy, then select UCS Domain, select the VLAN policy option and click Start.






Step 3. Select organization, provide a name for the VLAN (for example, Ru-VLAN) and click Next.




Step 4. Click Add VLANs to add your required VLANs.

Step 5. Click Multicast Policy to add or create a multicast policy with default settings for your VLAN policy as show below:



Step 6. Add additional VLANs as required with same multicast policy in the network setup and click Create.




Note: If you will be using the same VLANs on fabric interconnect A and fabric interconnect B, you can use the same policy for both.

Note: In the event any of the VLANs are marked native on the uplink Cisco Nexus switch, ensure to mark that VLAN native during VLAN Policy creation. This will avoid any syslog errors.


Procedure 2. Create Port Configuration Policy

Note: This policy has to be created for each of the fabric interconnects.

Step 1. Under Policies, for the platform type, select UCS Domain, then select Port and click Start.




Step 2. Provide a name for the port policy, select the Switch Model (present configuration is deployed with FI 6454) and click Next.



Step 3. Click Next. Define the port roles; server ports for chassis and server connections, Fibre Channel ports for SAN connections, or network uplink ports.

Step 4. If you need Fibre Channel, use the slider to define Fibre Channel ports.


Step 5. Select ports 1 through 16 and click Next, this creates ports 1-16 as type FC with Role as unconfigured. When you need Fibre Channel connectivity, these ports can be configured with FC Uplink/Storage ports.




Step 6. Click Next.

Step 7. If required, configure the FC or Ethernet breakout ports, and click Next. In this configuration, no breakout ports were configured. Click Next.

Step 8. To configure server ports, select the ports that have chassis or rack-mounted servers plugged into them and click Configure.



Step 9. From the drop-down list, select Server and click Save.



Step 10. Configure the uplink ports as per your deployment configuration. In this setup, port 53/54 are configured as uplink ports. Select the Port Channel tab and configure the port channel ID 65 (or as defined in your configuration table) as per the network configuration. In this setup, port 53/54 are port channeled and provide uplink connectivity to the Cisco Nexus switch.

Create

i The combined maximum number of Ethernet Uplink, FCoE Uplink, and Appliance port channels permitted is 12 and the maximum number of FC port channels permitted is 4.

Role
Ethernet Uplink Port Channel

Port Channel ID *
65

Admin Speed
Auto

1 - 255

Ethernet Network Group

[Select Policy](#)

Flow Control

[Select Policy](#)

Link Aggregation

[Select Policy](#)

Link Control

[Select Policy](#)

Create

- General
- Unified Port
- Breakout Options
- 4 Port Roles**

Port Roles

Configure port roles to define the traffic type carried through a unified port connection.

Port Roles **Port Channels** Pin Groups

Create Port Channel



1 Items found 10 per page 1 of 1

ID	Role	Ports
65	Ethernet Uplink Port Channel	Port 53, Port 54

1 of 1

Cancel

Back Save

Step 11. Repeat this procedure to create a port policy for Fabric Interconnect B. Configure the port channel ID for Fabric B as per the network configuration. In this setup, the port channel ID 66 is created for Fabric Interconnect B, as shown below:

Create

- General
- Unified Port
- Breakout Options
- Port Roles**

Port Roles

Configure port roles to define the traffic type carried through a unified port connection.

Port Roles **Port Channels** Pin Groups

Create Port Channel



Ethernet Uplink Port Channel

1 items found 10 per page 1 of 1

ID	Role	Ports
66	Ethernet Uplink Port Channel	Port 53, Port 54

Procedure 3. Create NTP Policy


Step 1. Under Policies, select Create Policy, then select UCS Domain and then select NTP. Click Start.

The screenshot shows the 'Create' page for Policies in Cisco Intersight. The left sidebar shows the navigation menu with 'Policies' selected. The main content area is titled 'Create' and contains a 'Filters' section. Under 'Platform Type', 'UCS Domain' is selected. Under 'Filters', 'NTP' is selected. The 'Start' button is visible at the bottom right.

Step 2. Provide a name for the NTP policy.

Step 3. Click Next.

Step 4. Define the name or IP address for the NTP servers. Define the correct time zone.




Step 5. Click Create.

Procedure 4. Create syslog Policy

Note: You do not need to enable the syslog server.

Step 1. Under Policies, select Create Policy, then select UCS Domain, and then select syslog. Click Start.



Step 2. Provide a name for the syslog policy.

Step 3. Click Next.

Step 4. Define the syslog severity level that triggers a report.


Step 5. Define the name or IP address for the syslog servers.

Step 6. Click Create.

Procedure 5. Create QoS Policy

Note: QoS Policy should be created as per the defined QoS setting on uplink switch. In this Rubrik deployment, no Platinum/Gold/Silver, or Bronze Class of Service (CoS) were defined and thus all the traffic would go through best efforts.


Step 1. Under Policies, select Create Policy, select UCS Domain, then select System QoS. Click Start.



Step 2. Provide a name for the System QoS policy.

Step 3. Click Next.

Step 4. In this Rubrik configuration, no Platinum/Gold/Silver, or Bronze Class of Service (CoS) were defined and thus all the traffic would go through best efforts. Change the MTU of best effort to 9216. Click Create.



Note: All the Domain Policies created in this procedure will be attached to a Domain Profile. You can clone the Cisco UCS domain profile to install additional Cisco UCS Systems. When cloning the Cisco UCS

domain profile, the new Cisco UCS domains use the existing policies for consistent deployment of additional Cisco Systems at scale.

In the previous section, the following policies were created to successfully configure a Domain Profile

1. VLAN Policy and multicast policy
2. Port Policy for Fabric Interconnect A and B
3. NTP Policy
4. Syslog Policy
5. System QoS


The screenshot below displays the Policies created to configure a Domain Profile:

The screenshot displays the Cisco Intersight interface for the Policies page. The left sidebar shows the navigation menu with 'Infrastructure Service' selected and 'Policies' highlighted. The main content area shows a table of policies with columns for Name, Platform Type, Type, Usage, and Last Update. The policies listed are:


Name	Platform Type	Type	Usage	Last Update
Ru-syslog	UCS Server, UCS Domain	Syslog	0	a few seconds ago
Ru-NTP	UCS Server, UCS Domain	NTP	0	a few seconds ago
Ru-System-QoS	UCS Domain	System QoS	0	5 minutes ago
Ru-PortPolicy-B	UCS Domain	Port	0	12 minutes ago
Ru-PortPolicy	UCS Domain	Port	0	16 minutes ago
Ru-VLAN	UCS Domain	VLAN	0	29 minutes ago
Ru-multicast	UCS Domain	Multicast Policy	N/A	31 minutes ago

Procedure 6. Create Domain Profile

- Step 1.** Select the Infrastructure Service option and click Profiles.
- Step 2.** Select UCS Domain Profiles.
- Step 3.** Click Create UCS Domain Profile.



Step 4. Provide a name for the profile (for example, AA08-XSeries-DomainProfile) and click Next.



Step 5. Select the fabric interconnect domain pair created when you claimed your Fabric Interconnects.

UCS Domain Assignment

Choose to assign a fabric interconnect pair to the profile now or later.

[Assign Now](#) [Assign Later](#)

Choose to assign a fabric interconnect pair now or later. If you choose Assign Now, select a pair that you want to assign and click Next. If you choose Assign Later, click Next to proceed to policy selection.

Show Assigned

Domain Name	Model	Serial	Bundle Version	Model	Serial	Bundle Version
AA09-FI-DP-6454	UCS-FI-6454	FDO260419XX	4.2(3d)	UCS-FI-6454	FDO260419ZA	4.2(3d)

Selected 1 of 1 [Show Selected](#) [Unselect All](#)

[Close](#) [Back](#) [Next](#)

Step 6. Under VLAN Configuration, click Select Policy to select the policies created earlier. (Be sure that you select the appropriate policy for each side of the fabric.) In this configuration the VLAN policy is same for both the fabric interconnects.

VLAN & VSAN Configuration

Create or select a policy for the fabric interconnect pair.

Fabric Interconnect A 1 of 2 Policies Configured

VLAN Configuration [x](#) [edit](#) [eye](#) Ru-VLAN [lock](#)

VSAN Configuration [Select Policy](#)



Fabric Interconnect B 1 of 2 Policies Configured

VLAN Configuration [x](#) [edit](#) [eye](#) Ru-VLAN [lock](#)


VSAN Configuration [Select Policy](#)

[Close](#) [Back](#) [Next](#)


Step 7. Under Ports Configuration, select the port configuration policies created earlier. Each fabric has different port configuration policy with only the port channel ID different across both the Port Configuration Policy. Therefore, you need to select separate Port Policy for each Fabric Interconnect.



Step 8. Under UCS Domain Configuration, select syslog, System QoS, and the NTP policies created earlier. Click Next.



Step 9. Review the Summary and click Deploy. Accept the warning for the Fabric Interconnect reboot and click Deploy.



Step 10. Monitor the Domain Profile deployment status and ensure the successful deployment of Domain Profile.

Step 11. After the Cisco UCS domain profile has been successfully created and deployed, the policies, including the port policies, are pushed to Cisco UCS fabric interconnects. Screenshot below details successful configuration of Domain Profile on Cisco UCS Fabric Interconnect in IMM mode (Intersight Managed Mode).

Step 12. Verify the uplink and Server ports are online across both Fabric Interconnects. In the event, the uplink ports are not green, please verify the configuration on the uplink Nexus switches.

Cisco Intersight Infrastructure Service

← Fabric Interconnects
AA09-FI-DP-6454 FI-A Healthy

General Inventory Connections UCS Domain Profile

Details

Health Healthy

Name AA09-FI-DP-6454 FI-A

Peer Switch [AA09-FI-DP-6454 FI-B](#)

Model UCS-FI-6454

Serial FDO260419XX

Management IP 10.108.0.161

Mode **Intersight**

Properties

UCS-FI-6454 Front Rear

Locator LED Health Overlay

Mode	Access
Ethernet Switching Mode end-host	IP Address 10.108.0.161
FC Switching Mode end-host	Subnet Mask 255.255.255.0
Admin Evac State Disabled	Default Gateway 10.108.0.254

Command Palette: Navigate Intersight with Ctrl+K or go to Help > Command Palette

Cisco Intersight Infrastructure Service

← Fabric Interconnects
AA09-FI-DP-6454 FI-B Healthy

General Inventory Connections UCS Domain Profile

Details

Health Healthy

Name AA09-FI-DP-6454 FI-B

Peer Switch [AA09-FI-DP-6454 FI-A](#)

Model UCS-FI-6454

Serial FDO260419ZA

Management IP 10.108.0.162

Mode **Intersight**

Properties

UCS-FI-6454 Front Rear


Locator LED Health Overlay

Mode	Access
Ethernet Switching Mode end-host	IP Address 10.108.0.162
FC Switching Mode end-host	Subnet Mask 255.255.255.0
Admin Evac State Disabled	Default Gateway 10.108.0.254

Command Palette: Navigate Intersight with Ctrl+K or go to Help > Command Palette

In the Port Policy, port 17-32 were defined as Server Ports. The 4x C240 M6 LFF certified for Rubrik deployment were already attached to these ports. The Servers are automatically discovered when the Domain Profile is configured on the Fabric Interconnects.

Step 13. To view the servers, go to the Connections tab and select Servers from the right navigation bar.



Manual Set up Server Template

A server profile template enables resource management by simplifying policy alignment and server configuration. You can create a server profile template by using the server profile template wizard, which groups the server policies into the following categories to provide a quick summary view of the policies that are attached to a profile:


- **Pools:** KVM Management IP Pool, MAC Pool and UUID Pool.
- **Compute policies:** Basic input/output system (BIOS), boot order policy.
- **Network policies:** Adapter configuration and LAN policies.
 - The LAN connectivity policy requires you to create an Ethernet network group policy, Ethernet network control policy, Ethernet QoS policy and Ethernet adapter policy.
- **Storage policies** for RAID1 configuration of internal M.2 cards. This is required for Rubrik OS installation.
- **Management policies:** IMC Access Policy for Rubrik certified Cisco C240 M6 LFF node, Intelligent Platform Management Interface (IPMI) over LAN; local user policy.

Create Pools

Procedure 1. Create Out of Band IP Pool


The IP Pool is a group of IP for KVM access, Server management and IPMI access of Rubrik Certified nodes. The management IP addresses used to access the CIMC on a server can be out-of-band (OOB) addresses, through which traffic traverses the fabric interconnect via the management port.

Step 1. Click Infrastructure Service, select Pool, and click Create Pool.




Step 2. Select IP and click Start.

Step 3. Select Organization, Enter a Name for IP Pool and click Next.



Step 4. Enter the required IP details and click Next.




Step 5. Deselect the IPV6 configuration and click Create.

Procedure 2. Create In-Band IP Pool

The IP Pool is a group of IP for KVM access, Server management and IPMI access of Rubrik Certified nodes. The management IP addresses used to access the CIMC on a server can be inband addresses, through which traffic traverses the fabric interconnect via the fabric uplink port.


Note: Since vMedia is not supported for out-of-band IP configurations, the OS Installation through Intersight for FI-attached servers in IMM requires an In-Band Management IP address. For more information, go to: https://intersight.com/help/saas/resources/adding_OSimage.

Step 1. Click Infrastructure Service, select Pool, and click Create Pool.




Step 2. Select IP and click Start.

Step 3. Select Organization, Enter a Name for IP Pool and click Next.



Step 4. Enter the required IP details and click Next.



Step 5. Deselect the IPV6 configuration and click Create.

Procedure 3. Create MAC Pool

Note: Best practices mandate that MAC addresses used for Cisco UCS domains use 00:25:B5 as the first three bytes, which is one of the Organizationally Unique Identifiers (OUI) registered to Cisco Systems, Inc. The remaining 3 bytes can be manually set. The fourth byte (for example, 00:25:B5:xx) is often used to identify a specific UCS domain, meanwhile the fifth byte is often set to correlate to the Cisco UCS fabric and the vNIC placement order.


Note: Create two MAC Pools for the vNIC pinned to each of the Fabric Interconnect (A/B). This allows easier debugging during MAC tracing either on Fabric Interconnect or on the uplink Cisco Nexus switch.

Step 1. Click Infrastructure Service, select Pool, and click Create Pool.


Step 2. Select MAC and click Start.

Step 3. Select organization, Enter a Name for Mac Pool (A) and click Start.


Step 4. Enter the last three octet of MAC address and the size of the Pool and click Create.



Step 5. Repeat this procedure for the MAC Pool for the vNIC pinned to Fabric Interconnect B, shown below:




The screenshot below details two MAC Pool for each virtual NIC (vNIC) pinned to each Fabric Interconnect:



Procedure 4. Create UUID Pool

- Step 1.** Click Infrastructure Service, select Pool, and click Create Pool.
- Step 2.** Select UUID and click Start.
- Step 3.** Select Organization, Enter a Name for UUID Pool and click Next.
- Step 4.** Enter a UUID Prefix (the UUID prefix must be in hexadecimal format xxxxxxxx-xxxx-xxxx).
- Step 5.** Enter UUID Suffix (starting UUID suffix of the block must be in hexadecimal format xxxx-xxxxxxxxxxxx).
- Step 6.** Enter the size of the UUID Pool and click Create. The details are shown below:



Create Server Policies

Procedure 1. Create BIOS Policy


[Table 9](#) lists the required polices for the BIOS policy.

Table 9. Policies required for domain profile

Option	Settings
Memory -> Memory Refresh Rate	1x Refresh
Power and Performance -> Enhanced CPU Performance	Auto
Processor -> Boot Performance Mode	Max Performance
Processor -> Energy-Performance	Performance
Processor -> Processor EPP Enable	enabled
Processor -> EPP Profile	Performance
Processor -> Package C State Limit	C0 C1 state
Serial Port -> Serial A Enable	enabled

Step 1. Click Infrastructure Service, select Policies, and click Create Policy.

Step 2. Select UCS Server, BIOS and click Start.



Step 3. Select Organization and enter a name for BIOS Policy.

Step 4. Select UCS Server (FI-Attached), In the policy detail page, select processor option (+) and change the below options and click Create:

- Boot Performance Mode to Max Performance
- Energy Performance to Performance
- Processor EPP Enable to Enable

- EPP Profile to Performance
- Package C State Limit to C0 C1 State

Policies > BIOS

Create

General

Policy Details

Boot Performance Mode Max Performance	APBDIS platform-default
Downcore Control platform-default	Streaming Stores Control platform-default
Fixed SOC P-State platform-default	DF C-States platform-default
CCD Control platform-default	CPU Downcore control platform-default
CPU SMT Mode platform-default	ACPI SRAT L3 Cache As NUMA Domain platform-default
Channel Interleaving platform-default	Cisco xGMI Max Speed platform-default
Closed Loop Thermal Throttling platform-default	Processor CMCI platform-default


Policies > BIOS

Create

General

Policy Details

Core Multi Processing platform-default	Energy Performance performance
Frequency Floor Override platform-default	CPU Performance platform-default
Power Technology platform-default	Demand Scrub platform-default
Direct Cache Access Support platform-default	DRAM Clock Throttling platform-default
Energy Efficient Turbo platform-default	Energy Performance Tuning platform-default
Enhanced Intel Speedstep(R) Technology platform-default	Processor EPP Enable enabled
EPP Profile Performance	Execute Disable Bit platform-default



Step 5. Click Create.

Procedure 2. Create IPMI over LAN Policy

Note: The highest privilege level that can be assigned to an IPMI session on a server. All standalone rack servers support this configuration. FI-attached rack servers with firmware at minimum of 4.2.3a support this configuration.

Note: The encryption key to use for IPMI communication. It should have an even number of hexadecimal characters and not exceed 40 characters.


Step 1. Click Infrastructure Service, select Policies, and click Create Policy.

Step 2. Select UCS Server, IPMI over LAN and click Start.

Step 3. Select Organization, Name the IPMI Over LAN policy, then click Next.

Step 4. Select UCS Server (FI-Attached).

Step 5. For the Privilege Level, select admin and enter an encryption key.



Step 6. Click Save.

Procedure 3. Create Storage Policy

The Storage policy allows you to create drive groups, virtual drives, configure the storage capacity of a virtual drive, and configure the M.2 RAID controllers.

In this configuration, Rubrik certified C240 M6 LFF nodes are configured with:

- 2x M.2 SSDs managed through M2 RAID Controller. A RAID1 configuration would be created across these drives.
- 12x Large Form Factor (LFF) drives managed through pass through SAS controller. These drives are configured in JBOD mode.

Step 1. Click Infrastructure Service, select Policies, and click Create Policy.


Step 2. Select UCS Server, Storage and click Start.

Step 3. Select Organization, Name the Storage policy, then click Next.

Step 4. Select UCS Server (FI-Attached).

Step 5. Change the Default Drive State' to JBOD

Step 6. Enable M.2 RAID Configuration and select MSTOR-RAID-1 (MSTOR-RAID). (All Changes are marked in RED).



Step 7. Click Create.

LAN Connectivity Policy

LAN Connectivity Policy determines the connections, and the network communication resources between the server and the LAN on the network. Some of the key best practices which should be considered before creating a LAN Connectivity Policy for Rubrik nodes are explained below:

- To allow network access to Rubrik nodes, the LAN connectivity policy is used to create (four)4x virtual network interfaces (vNICs); vNIC0, vNIC1, vNIC2, vNIC3. vNIC0 and vNIC1 are pinned to Switch ID A and Switch ID B respectively, similarly vNIC2 and vNIC3 are pinned on Switch ID A and Switch ID B respectively, with the same Ethernet network group policy, Ethernet network control policy, Ethernet QoS policy and Ethernet adapter policy.
- Even though (four) 4x vNICs only (two)2 vNICs (vNIC2 and vNIC3) were created and are configured through Rubrik OS. vNIC0 and vNIC1 are never used by Rubrik OS. Four vNICs are created to ensure compatibility of configuration between C-Series nodes connect to Cisco Fabric Interconnect and standalone Cisco UCS C-Series nodes which allow Cisco UCS VIC directly connected to a uplink switch such as Cisco Nexus 9000 series.
- The primary network VLAN for Rubrik should be marked as native or the primary network VLAN should be tagged at the uplink switch.
- The two vNICs (vNIC2/vNIC3) managed by Rubrik for all UCS Managed mode or Intersight Managed mode (connected to Cisco UCS Fabric) should be in Active-Backup mode (bond mode 1). C-Series nodes connected to Cisco Fabric Interconnect does not support Active-Active mode (802.3ad / mode 4). Ref. <https://www.cisco.com/c/en/us/support/docs/servers-unified-computing/ucs-b-series-blade-servers/200519-UCS-B-series-Teaming-Bonding-Options-wi.html>

Figure 11 shows the mapping of vNIC2 and vNIC3 created in LAN connectivity Policy to network ports as identified on Rubrik nodes.

Figure 11. vNIC2 mapped with network ports on Rubrik node

```

Checking networking ports...
  Port |          Device          | Driver | State | Link | Speed
-----|-----|-----|-----|-----|-----
bond0 |                          |        | up    | yes  | 50000Mb/s
bond1 |                          |        | down  | no   | Unknown!
eth0  | Cisco VIC NIC (rev a2) | enic   | down  | no   | Unknown!
eth1  | Cisco VIC NIC (rev a2) | enic   | down  | no   | Unknown!
rketh0 | Intel 10G X550T       | ixgbe  | down  | no   | Unknown!
rketh1 | Intel 10G X550T       | ixgbe  | down  | no   | Unknown!
rketh2 | Cisco VIC NIC (rev a2) | enic   | up    | yes  | 50000Mb/s
rketh3 | Cisco VIC NIC (rev a2) | enic   | up    | yes  | 50000Mb/s

Bond0 Mode is fault-tolerance (active-backup)
Bond0 bond ports are: rketh2 rketh3
Current active port is rketh3

Bond1 Mode is fault-tolerance (active-backup)
Bond1 bond ports are: rketh0 rketh1
Current active port is None
WARNING: Bond1 has no active ports and is not operational.

-----
Checking for MCEs...
/var/log/mcelog is clean

-----
FRU Replacement Summary:
All FRUS in the node are healthy.
RC240WZP2649Z15W >>
RC240WZP2649Z15W >>
RC240WZP2649Z15W >>
RC240WZP2649Z15W >>

```

↑
vNIC2 & vNIC3

Table 10 lists the policy details which would be created through Intersight.


Table 10. LAN connectivity Policy details

Network Port	Mac Pool	Switch ID	PCI Order	OS mapping
vNIC0	MAC Pool A	A	0	eth0
vNIC1	MAC Pool B	B	1	eth1
vNIC2	MAC Pool A	A	2	rketh2
vNIC3	MAC Pool B	B	3	rketh3

Procedure 4. Create LAN Connectivity Policy


Step 1. Click Infrastructure Service, select Policies, and click Create Policy.

Step 2. Select UCS Server, then select Lan Connectivity Policy and click Start.



Step 3. Select Organization, Name the LAN Connectivity Policy and select UCS Server (FI Attached).


Step 4. Click Add vNIC.




Step 5. Name the vNIC “vNIC0.”

Step 6. For the for vNIC Placement, select Advanced.


Step 7. Select MAC Pool A previously created, Switch ID A, PCI Order 0.




Step 8. Create the Ethernet Network Group Policy; add the allowed VLANs and add the native VLAN. The primary network VLAN for Rubrik should be marked as native or the primary network VLAN should be tagged at the uplink switch.




Step 9. Create the Ethernet Network Control policy; name the policy, enable CDP, set MAC Register Mode as All Host VLANs, and keep the other settings as default.




Step 10. Create the Ethernet QoS Policy; edit the MTU to 9000 and keep the Priority as best-effort.




Step 11. Create the Ethernet Adaptor Policy; select UCS Server (FI-Attached), Interrupts=10, Receive Queue Count = 8, Receive Ring Size = 4096, Transmit Queue Count = 4, Transmit Ring Size = 4096, Completion Queue = 12, keep the others as default, ensure Receive Side Scaling is enabled.



Step 12. Ensure the four policies are attached and Enable Failover is disabled (default). Click Add.





Step 13. Add vNIC as vNIC1. Select the same setting as vNIC0.

Step 14. For Switch ID, select B, and the PCI Order should be 1.

Step 15. Optional. The MAC Pool can be selected as the MAC Pool for Fabric B.

Step 16. Select the Ethernet Network Group Policy, Ethernet Network Control Policy, Ethernet QoS, and Ethernet Adapter policy as created for vNIC0 and click Add.

Policies > LAN Connectivity

Create

Add vNIC

General

Name *
vNIC1

Pin Group Name

MAC

Pool Static

MAC Pool *
Selected Pool MAC-B

Placement

Simple Advanced

When Simple Placement is selected, the Slot ID and PCI Link are automatically determined by the system. vNICs are deployed on the first VIC. The Slot ID determines the first VIC. Slot ID numbering begins with MLOM, and thereafter it keeps incrementing by 1, starting from 1. Simple assignment is not applicable for 13xx series VICs that support dual-link.

Switch ID *
B

PCI Order
1

Consistent Device Naming (CDN)

Source
vNIC Name

Failover

Enabled

Ethernet Network Group Policy *
Selected Policy Ru-ethernet-netgroup

Ethernet Network Control Policy *
Selected Policy Ru-ethernet-networkcontrol

Ethernet QoS *
Selected Policy Ru-ethernetQoS

Ethernet Adapter *
Selected Policy Ru-ethernet-adapter

ISCSI Boot
[Select Policy](#)

Connection


Cancel Add

Step 17. Repeat steps 1 – 16 to add vNIC2 and vNIC3.

Step 18. vNIC2 and vNIC3 will have the same Ethernet Network Group Policy, Ethernet Network Control Policy, Ethernet QoS, and Ethernet Adapter policy as created for vNIC0 and vNIC1.

- vNIC2 needs to be pinned to Switch ID A, with AMC Pool B and PCI Order as 2.
- vNIC3 needs to be pinned to Switch ID B, with MAC Pool B and PCI Order as 3, select B, and the PCI Order should be 1.

Step 19. Ensure the LAN connectivity Policy is created as shown below with 4x vNIC and click Create.



Procedure 5. Create Boot Order Policy

The boot order policy is configured with the Unified Extensible Firmware Interface (UEFI) boot mode. The following are the Boot Order mapping for Rubrik nodes:

- PXE Boot
- Virtual Media to mount ISO
- Virtual Drive with RAID1 created across (two)2x M.2 boot drives. Rubrik OS is installed on this Virtual Drive.


Step 1. Click Infrastructure Service, select Policies, and click Create Policy.

Step 2. Select UCS Server, Boot Order, and click Start.


Step 3. Select Organization, Enter a Name for Boot Order Policy.

Step 4. Under Policy Detail, select UCS Server (FI Attached), and ensure UEFI is checked.


Step 5. Select Add Boot Device and select local disk and enter device name as 'os' and Slot as 'MSTOR-RAID.'




Step 6. Select Add Boot Device and click vMedia and name the 'vmedia-1' device name.



Step 7. Select Add Boot Device and select PXE Boot, enter device name as 'PXE-boot' and interface name as vNIC0.



Step 8. Ensure the boot Device Order is as provided in the following screenshot, with 1st Boot Order as PXE boot, 2nd Boot Order as vMedia and 3rd Boot Order as os(local disk). Click Create.




Procedure 6. Create IMC Access Policy

The IMC Access policy allows you to configure your network and associate an IP address from an IP Pool with a server. In-Band IP address, Out-Of-Band IP address, or both In-Band and Out-Of-Band IP addresses can be configured using IMC Access Policy and is supported on Drive Security, SNMP, Syslog, and vMedia policies.

In the present Rubrik configuration, customers can create both IN-Band Out of Band IMC Access Policy.

Note: In-Band IMC Access Policy is required to utilize operating system installation feature of Cisco Intersight.


- Step 1.** Click Infrastructure Service, select Policies, and click Create Policy.
- Step 2.** Select UCS Server, then select IMC Access and click Start.
- Step 3.** Select Organization, Name the IMC Access policy, then click Next.
- Step 4.** Select UCS Server (FI-Attached).
- Step 5.** Select the In-Band Configuration option.
- Step 6.** Enter VLAN for IN-Band Access and select the IN-Band IP Pool created during IP Pool configuration.
- Step 7.** Enable Out-of-Band (OOB) configuration, Select IP Pool (as created under ‘Create Pools’) section.
- Step 8.** Click Create.



Procedure 7. Create Local User Policy

Note: Local User Policy creates local user and password for access to KVM through Server Management IP allocated through IMC Access Policy. For example, access to server console through `https://<<KVM-IP>>/kvm/`.

- Step 1.** Click Infrastructure Service, select Policies, and click Create Policy.
- Step 2.** Select UCS Server, then select Local User and click Start.
- Step 3.** Select Organization, Name the Local User policy and click Next.
- Step 4.** Change the password history to '0', Add a local user with the name 'RUBRIK' and role as admin and enter a password. This is used to access the server KVM through KVM IP. Click Create. You can create multiple Local Users as required.



Create Server Profile

Procedure 1. Create Server Profile Template


A server profile template enables resource management by simplifying policy alignment and server configuration. All the policies created in previous section would be attached to Server Profile Template. You can derive Server Profiles from templates and attach to new Cisco UCS C-Series nodes deployed for Rubrik cluster. For more information, go to: https://www.intersight.com/help/saas/features/servers/configure#server_profiles

The pools and policies attached to Server Profile Template are listed in [Table 11](#).


Table 11. Policies required for Server profile template

Pools	Compute Policies	Network Policies	Management Policies	Storage Policy
KVM Management IP Pool for In-Band and Out-of-Band (OOB) Access	BIOS Policy	LAN Connectivity Policy	IMC Access Policy	Rubrik storage policy for RAID1 configuration across 2x M.2 cards. This is utilized for Rubrik OS installation
MAC Pool for Fabric A/B	Boot Order Policy	Ethernet Network Group Policy	IPMI over LAN	
UUID Pool		Ethernet Network Control Policy	Local User Policy	
		Ethernet QoS Policy	Serial Over LAN Policy	
		Ethernet Adapter Policy		

Step 1. Click Infrastructure Service, select Templates, and click Create UCS Server Profile Template.



Step 2. Select Organization, Name the Server Profile Template, select UCS Sever (FI-Attached) and click Next.



Step 3. Select UUID Pool and all Compute Policies (BIOS and Boot Order Policy) created in the previous section. Click Next.

← Templates

Create UCS Server Profile Template

General

2 Compute Configuration

3 Management Configuration

4 Storage Configuration

5 Network Configuration

6 Summary

Compute Configuration

Create or select existing Compute policies that you want to associate with this template.

UUID Assignment

UUID Pool Selected Pool Ru-UUID × | ↻ | ✎

BIOS	Ru-BIOS
Boot Order	Ru-BootOrder
Firmware	
Power	
Thermal	
Virtual Media	

Close Back Next

Step 4. Select all Management Configuration Policies (IMC Access, IPMI over LAN and Local User policies) and attach to the Server Profile Template.

← Templates

Create UCS Server Profile Template

General

Compute Configuration

3 Management Configuration

4 Storage Configuration

5 Network Configuration

6 Summary

Management Configuration


Create or select existing Management policies that you want to associate with this template.

Certificate Management


IMC Access	IMCAccess-1
IPMI Over LAN	Ru-IPMI
Local User	localuser-1
Serial Over LAN	
SNMP	
Syslog	
Virtual KVM	

Close Back Next

Step 5. In the next screen, under Storage Configuration, Select Storage Policy and click Next.



Step 6. Under Network Configuration, select the LAN connectivity Policy created in the previous section and click Next.



Step 7. Verify the summary and click Close. This completes the creation of Server Profile Template. The details of the policies attached to the Server Profile Template are detailed below.

← Templates

Create UCS Server Profile Template

- General
- Compute Configuration
- Management Configuration
- Storage Configuration
- Network Configuration
- 6 Summary**

Summary

Verify details of the template and the policies, resolve errors and deploy.

General

Template Name: Rubrik-Template-1 Organization: Ru-Org

Target Platform: UCS Server (FI-Attached)

Compute Configuration Management Configuration **Storage Configuration** Network Configuration Errors/Warnings (0)

Storage Ru-storage

Close

Back Derive Profiles

← Templates

Create UCS Server Profile Template

- General
- Compute Configuration
- Management Configuration
- Storage Configuration
- Network Configuration
- 6 Summary**

Summary

Verify details of the template and the policies, resolve errors and deploy.

General

Template Name: Rubrik-Template-1 Organization: Ru-Org

Target Platform: UCS Server (FI-Attached)

Compute Configuration Management Configuration Storage Configuration **Network Configuration** Errors/Warnings (0)

LAN Connectivity Ru-LANConnectivty_4vNIC

Close

Back Derive Profiles

Install Rubrik CDM on Cisco UCS C-Series Nodes

Rubrik OS can be installed on Rubrik certified Cisco UCS C240 M6 LFF nodes with one of two options:

- Install OS through Intersight OS installation.

This allows installing the Rubrik CDM operating System through Cisco Intersight. You are required to have an Intersight Advantage license for this feature. The operating system resides on a local software repository as an OS Image Link configured in Cisco Intersight. The repository can be a HTTPS, NFS or CIFS repository accessible through the KVM management network. This feature benefits in the following ways:


 - It allows the operating system installation simultaneously across several C-Series nodes provisioned for the Rubrik CDM cluster.
 - It reduces Day0 installation time by avoiding mounting the ISO as Virtual Media on the KVM console for each node deployed for Rubrik on each Cisco UCS C-Series node.
- Install the OS by mounting ISO as virtual Media for each node.

Derive and Deploy Server Profiles


Procedure 1. Derive and Deploy Server Profiles

In this procedure, Server Profiles are derived from Server Profile Template and deployed on Cisco C-Series nodes certified for the Rubrik CDM.


Step 1. Select Infrastructure Service, then select Templates and identify the Server Template created in the previous section.



Step 2. Select the Server Template created in previous section, click the ... icon and select Derive Profiles.



Step 3. Identify and select the Cisco UCS C-Series nodes for Server Profile deployment and click Next.



Step 4. Select organization (Ru-Org in this deployment), edit the name of Profiles if required and click Next.

Derive

- General
- Details**
- Summary

Details

Edit the description, tags, and auto-generated names of the profiles.

General

Organization * Ru-Org Target Platform UCS Server (FI-Attached)

Description Set Tags

Derive

1	Name *	Assigned Server
	Ru-SP-Template-1_DERIVED-1	AA09-FI-DP-8454-1

Back
Next

Step 5. All Server policies attached to the template will be attached to the derived Server Profiles. Click Derive.

Derive

- General
- Details
- Summary**

Summary

Summary of the profiles that need to be derived from the profile template.

General

Template Name Ru-SP-Template-1 Organization Ru-Org

Target Platform UCS Server (FI-Attached)


UCS Server Profiles

Name	Assigned Server
Ru-SP-Template-1_DERIVED-1	AA09-FI-DP-8454-1


Compute Configuration	Management Configuration	Storage Configuration	Network Configuration	Errors/Warnings (0)
BIOS				Ru-BIOS
Boot Order				Ru-BootOrder
Power				Ru-Power

Back
Derive

Step 6. The Server Profiles will be validated and ready to be deployed to the Cisco UCS C-Series. A “Not Deployed” icon will be displayed on the derived Server Profiles.




Step 7. Select the Not Deployed Server Profiles, click the ... icon and click Deploy.



Step 8. Enable Reboot Immediately to Activate and click Deploy.

Deploy (3 UCS Server Profiles)

Selected UCS server profiles will be deployed to their assigned servers.

 If policy configuration requires an immediate reboot and the option below is disabled, then profile deployment will not be initiated.

Reboot Immediately to Activate 

[^ More Details](#)

3 items page   1 of 1   

 Add Filter

Server Profile Name	Server Name	Reboot
Ru-SP-Template-1_DERIVED-4	AA09-FI-DP-6454-4	<input checked="" type="radio"/> YES
Ru-SP-Template-1_DERIVED-3	AA09-FI-DP-6454-3	<input checked="" type="radio"/> YES
Ru-SP-Template-1_DERIVED-2	AA09-FI-DP-6454-2	<input checked="" type="radio"/> YES

  1 of 1  

Cancel

Deploy

Step 9. Monitor the Server Profile deployment status and ensure the Profile deploys successfully to the Cisco UCS C-Series node.

← Requests ×

Deploy Server Profile

Details

Status
In Progress

Name
Deploy Server Profile

ID
64a85fa7696f6e330197478a

Target Type
Rack Server

Target Name
AA09-FI-DP-6454-1

Source Type
Server Profile

Source Name
Ru-SP-Template-1_DERIVE...

Initiator
andhiman@cisco.com

Start Time
Jul 7, 2023 11:55 AM

End Time

Execution Flow

Progress 5%

Wait For BIOS POST Completion

Prepare Server Profile Deploy Jul 7, 2023 11:55 AM

Power On Server Jul 7, 2023 11:55 AM

Requests ×

* All Requests +

Status In Progress x Add Filter Export 3 items found 12 per page 1 of 1

Status

In Progress 3

Execution Type

Execute 3

<input type="checkbox"/>	Name	Status	Initiator	Target Type	Target Name	Start Time	Duration	ID	Execution Type	
<input type="checkbox"/>	Deploy Server P...	In Progress 5%	andhiman@cisc...	Rack Server	AA09-FI-DP-64...	7 hours ago	7 h 12 m 2 s	64a9913e696f6...	Execute	...
<input type="checkbox"/>	Deploy Server P...	In Progress 5%	andhiman@cisc...	Rack Server	AA09-FI-DP-64...	7 hours ago	7 h 12 m 2 s	64a9913e696f6...	Execute	...
<input type="checkbox"/>	Deploy Server P...	In Progress 5%	andhiman@cisc...	Rack Server	AA09-FI-DP-64...	7 hours ago	7 h 12 m 3 s	64a9913e696f6...	Execute	...

1 of 1

Step 10. Once the Server Profile deployment completes successfully, you can proceed to the Rubrik CDM deployment on the Cisco UCS C-Series nodes.

The screenshot shows the Cisco Intersight interface. The left sidebar has the 'Profiles' menu item highlighted. The main content area is titled 'Profiles' and has tabs for 'HyperFlex Cluster Profiles', 'UCS Chassis Profiles', 'UCS Domain Profiles', and 'UCS Server Profiles'. The 'UCS Server Profiles' tab is active. Below the tabs, there are summary cards for 'Status' (OK 4), 'Inconsistency Reason' (No data available), and 'Target Platform' (FI-Attached 4). A table below shows the list of profiles:


Name	Status	Target Platform	UCS Server Template	Server	Last Update
Ru-SP-Template-1_DERIVED-2	OK	UCS Server (FI-Attached)	Ru-SP-Template-1	AA09-FI-DP-6454-2	Dec 5, 2023 4:47 PM
Ru-SP-Template-1_DERIVED-4	OK	UCS Server (FI-Attached)	Ru-SP-Template-1	AA09-FI-DP-6454-4	Dec 5, 2023 4:49 PM
Ru-SP-Template-1_DERIVED-3	OK	UCS Server (FI-Attached)	Ru-SP-Template-1	AA09-FI-DP-6454-3	Dec 5, 2023 4:49 PM
Ru-SP-Template-1_DERIVED-1	OK	UCS Server (FI-Attached)	Ru-SP-Template-1	AA09-FI-DP-6454-1	Dec 5, 2023 6:32 PM

Step 11. Access KVM with KVM username > kvm-user (RUBRIK) and password > <<as configured in local user policy>>, and make sure the node is accessible.

Step 12. Virtual KVM can be accessed by directly launching from Cisco Intersight (Launch vKVM) or access the node management IP.

The screenshot shows the Cisco Intersight 'Servers' page. At the top, there are summary cards for Health (23 total: 12 Critical, 1 Warning, 10 Healthy), Power (5 Off, 18 On), HCL Status (19 Incomplete, 4 Validated), Models (23 total: 6 C220 M5L, 4 HXAF240C M5SX, 4 C240 M5L, 9 Other), Contract Status (23 Not Covered), and Profile Status (Inconsistent). Below these is a table of servers with columns for Management IP, Model, Server Profile, Serial, UCS Domain, and Name. The server with IP 10.108.0.20 is selected, and a context menu is open over it, showing options like 'Launch vKVM', 'Upgrade Firmware', and 'Set License Tier'. The browser address bar shows 'https://10.108.0.166/kvm/index.html'.

Management IP	Model	Server Profile	Serial	UCS Domain	Name
172.25.178.202	HXAF220C-M5SX		WZP22440AX5		C220-W2
172.25.178.201	HXAF220C-M5SX		WZP22440AZC		C220-W2
10.41.2.131	UCSC-C220-M5L	Cohesity-C240-SP_CLO...	WZP233414DG		C220-W2
10.108.0.14	HXAF240C-M5SX	org-root/org-AFCluster4...	WZP22120NWQ	AA08-FI6332	AA08-FI6332
10.108.0.15	HXAF240C-M5SX	org-root/org-AFCluster4...	WZP2211157K	AA08-FI6332	AA08-FI6332
10.108.0.16	HXAF240C-M5SX	org-root/org-AFCluster4...	WZP22120CAX	AA08-FI6332	AA08-FI6332
10.108.0.17	HXAF240C-M5SX	org-root/org-AFCluster4...	WZP22120C9B	AA08-FI6332	AA08-FI6332
10.108.0.20	UCSX-210C-M6	AA08-XSeries-Manual_...	FCH250671P5	AA08-XSeries	AA08-XSeries-2-1 5.0(2b)
10.108.0.21	UCSX-210C-M6	AA08-XSeries-Manual_...	FCH243974YZ	AA08-XSeries	AA08-XSeries-2-2 5.10.230i



Install OS through Intersight

Procedure 1. Install Rubrik CDM through Cisco Intersight OS Installation feature

This procedure details the process to install the Rubrik CDM operating system through the Cisco Intersight OS installation feature.


Note: This feature is only supported with the Intersight Advantage Tier License.

Note: Make sure the certified Rubrik CDM ISO is available from a local repository, for example an HTTPS/NFS/CIFS server. This is a one-time process for each version of the Rubrik CDM ISO.


Step 1. Login to Cisco Intersight and click System.

Step 2. Click Software Repository and click the OS Image Links tab.


Step 3. Click Add OS Image Link.




Step 4. Select organization, add the location of the Rubrik CDM ISO (NFS/CIFS or HTTPS server) and click Next.




Step 5. Enter a name for the Repository, for the Vendor enter Ubuntu, and for the Version enter Ubuntu 18.04. Click Add.




Step 6. Make sure the OS Repository is successfully created in Cisco Intersight.




Step 7. From Cisco Intersight, click Infrastructure Service, then click Servers, and select the Cisco UCS C-Series nodes ready for the Rubrik CDM OS installation. Click the ... and select Install Operating System. Click the ... and select Install Operating System.




Step 8. In the General tab, ensure the nodes are selected. Click Next.




Step 9. Select the Operating System repository which was previously created for Rubrik CDM ISO and click Next.



Step 10. From Configuration, click Embedded and click Next (the OS configuration file is already part of Rubrik CDM ISO). Click Next




Step 11. Click Next on the Server Configuration Utility (SCU) tab.




Step 12. Click Next from the Installation target. Rubrik CDM ISO automatically identifies the Installation target as the RAID1 virtual drive created across 2x M.2 internal drives configured in the Boot Order Server Policy.

Step 13. Verify the summary and click Install.




Step 14. Accept the warning for overwriting the existing OS image on the node and click Install.




Step 15. The OS installation for Rubrik on Cisco UCS C-Series nodes require few confirmations. Therefore, you need to open a vKVM window for each of the nodes wherein Rubrik OS is getting installed. The node will reboot for OS installation and the ISO would be automatically mounted.



Step 16. Confirm the Rubrik CDM version.



Rubrik Installer will verify the hardware compatibility.



Step 17. When the verification completes, confirm the errors detected. Ignore the NIC count, CPU and SSD model check errors.


Following error(s) detected. Would you like to proceed?

TPM version check.....	Pass
NIC count check.....	Fail
SSD count check.....	Pass
HDD count check.....	Pass
CPU core count check.....	Fail
CPU model check.....	Fail
CPU speed check.....	Pass
Total memory size check.....	Pass
IPMI check.....	Pass
BIOS check.....	Pass
NIC 10/25Gb Bond0 Model check.....	Pass
NIC 10/25Gb Bond0 PCIe Slot check.....	Pass
NIC 1/10Gb Bond1 Model check.....	Pass
NIC 1/10Gb Bond1 PCIe Slot check.....	Pass
SSD Size check.....	Pass
HDD Size check.....	Pass
SSD Model check.....	Fail

< Yes >

< No >

Next, the stage 2 of installation proceeds.



Step 18. When the OS is installed, login to each node (admin/rubrik) and verify the hardware health. Execute 'cluster hw_health' on each node to confirm on any hardware issue and the node is healthy.

Note: Ensure the bond0 is created across rketh2 and rketh3 and the network port status is up.

```
Checking networking ports...
  Port | Device | Driver | State | Link | Speed
  -----|-----|-----|-----|-----|-----
  bond0 | | | up | yes | 50000Mb/s
  bond1 | | | down | no | Unknown!
  eth0 | Cisco VIC NIC (rev a2) | enic | down | no | Unknown!
  eth1 | Cisco VIC NIC (rev a2) | enic | down | no | Unknown!
  rketh0 | Intel 10G X550T | ixgbe | down | no | Unknown!
  rketh1 | Intel 10G X550T | ixgbe | down | no | Unknown!
  rketh2 | Cisco VIC NIC (rev a2) | enic | up | yes | 50000Mb/s
  rketh3 | Cisco VIC NIC (rev a2) | enic | up | yes | 50000Mb/s

Bond0 Mode is fault-tolerance (active-backup)
Bond0 bond ports are: rketh2 rketh3
Current active port is rketh3

Bond1 Mode is fault-tolerance (active-backup)
Bond1 bond ports are: rketh0 rketh1
Current active port is None
WARNING: Bond1 has no active ports and is not operational.

-----
Checking for MCEs...
/var/log/mcelog is clean

-----
FRU Replacement Summary:
All FRUS in the node are healthy.
RC240WZP2649215W >>
RC240WZP2649215W >>
RC240WZP2649215W >>
RC240WZP2649215W >>
```


Install OS through Virtual Media

Procedure 1. Install Rubrik CDM OS through Virtual Media


This procedure details the process to install the Rubrik CDM operating system through virtual media. You need to open a virtual KVM session for each node. Virtual KVM session can be accessed through Cisco Intersight or logging into node management IP assigned during Server Profile deployment.

Note: If you are installing the OS through virtual media and it times out, please use a different browser such as Mozilla Firefox.


Step 1. Login to virtual KVM, click Virtual Media and click vKVM-Mapped DVD.




Step 2. Select the Rubrik CDM ISO from your local file system and click Map Drive.



Step 3. Click Boot Device and then select Any Virtual Media as a one time boot device. This ensures the next boot of the node attaches to the ISO mounted on the Virtual Media.




Step 4. Click Power and then click Reset System to reset the power cycle on the node. The Rubrik CDM ISO automatically loads.




Step 5. The entire installation takes about an hour. When all the nodes are installed with Rubrik ISO, you can proceed to configure the Rubrik cluster.


Rubrik Installer will verify the hardware compatibility.




Step 6. When the verification completes, confirm the errors detected. Ignore the NIC count, CPU and SSD model check errors.




Next, the stage 1 of installation will proceed. It may take about 70-80 minutes for completion of stage 1.




Step 7. When Stage 1 is complete, the installer will reboot the system and proceed to Stage 2.



Step 8. When Stage2 is complete and installation succeeds, the node would be ready for normal setup and cluster configuration.





Step 9. Login to each node (admin/rubrik) and verify the hardware health. Execute 'cluster hw_health' on each node to confirm on any hardware issue and the node is healthy.

Note: Ensure the bond0 is created across rketh2 and rketh3 and the network port status is up.

```

Checking networking ports...
  Port | Device | Driver | State | Link | Speed
  -----|-----|-----|-----|-----|-----
  bond0 | | | up | yes | 50000Mb/s
  bond1 | | | down | no | Unknown!
  eth0 | Cisco VIC NIC (rev a2) | enic | down | no | Unknown!
  eth1 | Cisco VIC NIC (rev a2) | enic | down | no | Unknown!
  rketh0 | Intel 10G X550T | ixgbe | down | no | Unknown!
  rketh1 | Intel 10G X550T | ixgbe | down | no | Unknown!
  rketh2 | Cisco VIC NIC (rev a2) | enic | up | yes | 50000Mb/s
  rketh3 | Cisco VIC NIC (rev a2) | enic | up | yes | 50000Mb/s

Bond0 Mode is fault-tolerance (active-backup)
Bond0 bond ports are: rketh2 rketh3
Current active port is rketh3

Bond1 Mode is fault-tolerance (active-backup)
Bond1 bond ports are: rketh0 rketh1
Current active port is None
WARNING: Bond1 has no active ports and is not operational.

-----
Checking for MCEs...
/var/log/mcelog is clean

-----
FRU Replacement Summary:
All FRUS in the node are healthy.
RC240W2P2649215W >>
RC240W2P2649215W >>
RC240W2P2649215W >>
RC240W2P2649215W >>

```

Step 10. Repeat this procedure for all Cisco C-Series nodes to be configured for the Rubrik CDM cluster.

Configure Rubrik CDM Cluster

This section elaborates on the configuration of the Rubrik CDM Cluster on Cisco UCS C-Series nodes. The existing deployment is deployed with four (4) Cisco UCS C240 M6 LFF servers.

Note: Make sure the Rubrik CDM ISO is installed on each Cisco C-Series nodes.

Note: The network bonding mode on the Rubrik operating systems with Cisco UCS C-Series servers connected to Cisco UCS Fabric Interconnect, does not support bond mode 4. For reference, go to: <https://www.cisco.com/c/en/us/support/docs/servers-unified-computing/ucs-b-series-blade-servers/200519-UCS-B-series-Teaming-Bonding-Options-wi.html>)

Note: The following section is for reference; make sure to involve Rubrik support during cluster configuration.

The Rubrik CDM cluster configuration is a three-step process:

- Verify node network status and change node to UCS Managed (UCSM) mode
- Bootstrap cluster
- Register Cluster

Verify node network status and change node to UCS Managed (UCSM) mode.

Procedure 1. Verify network active status

In this procedure, administrators should verify the network status of each Cisco UCS C-Series server to be configured as part of Rubrik CDM cluster

Step 1. Ensure Rubrik CDM OS is installed on each node. Login to each node (admin/rubrik) and execute cluster hw_health to verify the node health and network status. The following screenshot displays the output of cluster hw_health. The active network is Bond0 with ports as rketh2 and rketh3 with active-backup fault tolerance mode. These network ports are mapped to vNIC2/vNIC3 created in the LAN Connectivity Policy for Server Profile of Cisco UCS C-Series server. This was created in the [Create Server Profile](#) template section.

```

-----
Checking for PCIe errors...
No PCIe errors found.
-----
Checking networking ports...
  Port |           Device | Driver | State | Link | Speed
bond0 |                   |        | up    | yes  | 50000Mb/s
bond1 |                   |        | down  | no   | Unknown!
eth0  | Cisco VIC NIC (rev a2) | enic  | down  | no   | Unknown!
eth1  | Cisco VIC NIC (rev a2) | enic  | down  | no   | Unknown!
rketh0 | Intel 10G X550T | ixgbe | down  | no   | Unknown!
rketh1 | Intel 10G X550T | ixgbe | down  | no   | Unknown!
rketh2 | Cisco VIC NIC (rev a2) | enic  | up    | yes  | 50000Mb/s
rketh3 | Cisco VIC NIC (rev a2) | enic  | up    | yes  | 50000Mb/s
-----
Bond0 Mode is fault-tolerance (active-backup)
Bond0 bond ports are: rketh3 rketh2
Current active port is rketh3

Bond1 Mode is fault-tolerance (active-backup)
Bond1 bond ports are: rketh0 rketh1
Current active port is None
WARNING: Bond1 has no active ports and is not operational.
-----
Checking for MCEs...
/var/log/mcelog is clean
-----
FRU Replacement Summary:
All FRUS in the node are healthy.
RC240WZP2649Z1B2 >>

```

Procedure 2. Convert to UCS Managed node

Step 1. Convert each node in UCS Managed mode. Execute `cluster change_cisco_UCS_mode`. The following screenshot displays the output. This should be executed across each node which would be configured in Rubrik CDM cluster. This is required for all Cisco UCS C-Series servers configured as Rubrik CDM nodes and connected to Cisco UCS Fabric Interconnect in Intersight Managed Mode (IMM).

```

RC240WZP2649Z15W login: admin
Password:
=====
Welcome to Rubrik CLI++
=====
Type 'help' or '?' to list commands
Type 'commands list' to list all available commands

It is recommended to use the Rubrik CDM web UI for cluster setup. Please use this URL "https://[fe80::225:b5ff:fe55:55c1]" to access the UI from inside the same subnet. Alternatively, use the "cluster setupnetwork" command on the CLI to assign a routable IPv4 address to any of the nodes and then access the UI via IPv4
RC240WZP2649Z15W >> cluster change_cisco_UCS_mode
Node is set to managed mode.
RC240WZP2649Z15W >>

```

Bootstrap Rubrik Cluster

Note: The following section is for reference. Customers and administrators should contact Rubrik support to bootstrap and register Rubrik Cluster.

Note: This section explains the bootstrap process using the CLI method. To bootstrap Rubrik cluster through the UI, please refer to Setting up a Rubrik cluster using the UI in the [Rubrik CDM Install and Upgrade Guide](#).

This section details the cluster bootstrap process. All IP address details should be pre-populated as provided in [Table 3 Rubrik Cluster IP Addressing](#). It is recommended to involve Rubrik support during this process.

Procedure 1. Bootstrap cluster

Step 1. Login to any Rubrik node (admin/rubrik).

Step 2. Execute 'cluster bootstrap' Once the general inputs such as cluster name, DNS, NTP are entered, all the nodes pre-installed with Rubrik CDM OS will be discovered.

The following screenshots display the user inputs, marked in RED. All user inputs are detailed [Table 3 Rubrik Cluster IP Addressing](#).

```
RC240W2P2649215T >> cluster bootstrap
Waiting for Rubrik API to become available
```

```
Select your role from the following options:
```

- 1 Customer
- 2 Support
- 3 Rubrik Professional Service
- 4 Partner
- 5 Sales Engineer

```
User configuration
```

```
Input your role: 1
E-mail:
Password:
Re-enter Password:
Re-entered password does not match
Password:
Re-enter Password:
```

```
Cluster configuration
```

```
Cluster name: ru-chx-02
DNS Nameservers [8.8.8.8]: 10.108.1.6,172.20.4.53
DNS Search Domains (Optional - press [Enter] to continue):
NTP Servers [pool.ntp.org]: 172.20.10.18,172.20.10.15
```

```
Management Gateway: 10.108.1.254
Management Subnet Mask: 255.255.255.0
Management VLAN (Optional - press [Enter] to continue):
```

```
IPMI Gateway: 0.0.0.0
IPMI Subnet Mask: 0.0.0.0
```

```
Data Subnet Mask (Optional - press [Enter] to continue):
```

```
Enable Software Encryption (y/n) (Optional - press [Enter] to continue) [y]:
```

```
Node configuration
```

```
Discovering nodes...
```

```
Node configuration
```

```
Discovering nodes...
```

```
Discovered nodes:
1: RC240W2P26492157
2: RC240W2P2649215T
3: RC240W2P2649215W
4: RC240W2P2649218Z
```

```
Type a node index or name to configure. Type 0 to find more nodes or hit Enter to begin bootstrap
Select node: (Optional - press [Enter] to continue): _
```



```
1: RC240WZP2649Z157*
2: RC240WZP2649Z15T
3: RC240WZP2649Z15W
4: RC240WZP2649Z18Z
```

Type a node index or name to configure. Type 0 to find more nodes or hit Enter to begin bootstrap

Select node: (Optional - press [Enter] to continue): 2

Configuring node RC240WZP2649Z15T

Management IP [10.108.1.164]:

IPMI IP [0.0.0.2]:

Discovered nodes:

```
1: RC240WZP2649Z157*
```

```
2: RC240WZP2649Z15T*
```

```
3: RC240WZP2649Z15W
```

```
4: RC240WZP2649Z18Z
```

Type a node index or name to configure. Type 0 to find more nodes or hit Enter to begin bootstrap

Select node: (Optional - press [Enter] to continue): 33

Invalid index

Discovered nodes:

```
1: RC240WZP2649Z157*
```

```
2: RC240WZP2649Z15T*
```

```
3: RC240WZP2649Z15W
```

```
4: RC240WZP2649Z18Z
```

Type a node index or name to configure. Type 0 to find more nodes or hit Enter to begin bootstrap

Select node: (Optional - press [Enter] to continue): 3

Configuring node RC240WZP2649Z15W

Management IP [10.108.1.165]:

IPMI IP [0.0.0.3]:

Discovered nodes:

```
1: RC240WZP2649Z157*
```

```
2: RC240WZP2649Z15T*
```

```
3: RC240WZP2649Z15W*
```

```
4: RC240WZP2649Z18Z
```

Type a node index or name to configure. Type 0 to find more nodes or hit Enter to begin bootstrap

Select node: (Optional - press [Enter] to continue): 4

Configuring node RC240WZP2649Z18Z

Management IP [10.108.1.166]:

IPMI IP [0.0.0.4]:

Discovered nodes:

```
1: RC240WZP2649Z157*
```


```
2: RC240WZP2649Z15T*
```

```
3: RC240WZP2649Z15W*
```

```
4: RC240WZP2649Z18Z*
```

Type a node index or name to configure. Type 0 to find more nodes or hit Enter to begin bootstrap

Select node: (Optional - press [Enter] to continue): _




Step 3. When the bootstrap is successful, proceed to registering the cluster to Rubrik Security Cloud (RSC) instance.


Procedure 2. Rubrik Cluster Registration

Note: Ensure you have a Rubrik Security Cloud Instance created for your Rubrik account.


Step 1. Open a browser and login to Rubrik node with the Node OS IP address configured during the bootstrap process.



Step 2. Enter the Rubrik Security Cloud URL (RSC) and sign in to Rubrik.



Step 3. Enter your Rubrik Security Cloud instance login and password.



Step 4. Select the SaaS instance service type and confirm the cluster details for registration, click Next.

Online Cluster Registration ✕

Choose Service Type

Your account has multiple orders of different service types.

Rubrik Security Cloud (SaaS)

Enable centralized data management through Rubrik Security Cloud's single interface only.

CDM (Software) Latest order

Manage your clusters locally. Rubrik Security Cloud may already be available to you. You can register a Rubrik cluster using this limited-time option, which allows you manage your cluster in dual management mode (CDM and RSC).

Confirm the cluster that will be granted registration permission:

Cluster Name: ru-cluster-03
Cluster ID: 2bbcfa26-f3e2-4a2b-9ced-17d2e317f9e4
Cluster Address: 10.108.1.163

NEXT

Step 5. Cluster registration may take few minutes, confirm the successful cluster registration to Rubrik Security Cloud instance.

- Discover Nodes
- Configure
- Bootstrap
- Register Cluster**
- Initiate Access



Registering the cluster...

This could take up to 6 min

- Discover Nodes
- Configure
- Bootstrap
- Register Cluster
- Initiate Access**



Registration Successful!

Cluster ru-cluster-03 (UUID 2bbcfa26-f3e2-4a2b-9ced-17d2e317f9e4) is now registered with Rubrik.

[ACCESS CLUSTER](#)

Cluster Expansion and Firmware Upgrades

This chapter contains the following:

- [Rubrik Cluster Expansion](#)
- [Upgrade Cisco UCS C-Series Node Firmware](#)

Note: Rubrik support should be involved for both Cluster Expansion and Cisco C-Series Firmware Upgrades.

Rubrik Cluster Expansion

Cluster Expansion is a two-step process:

1. Derive, Deploy Server Profile, and Install Rubrik CDM operating system.
2. Add node through Rubrik management console.

Derive-Deploy Server Profile

Procedure 1. Derive and Deploy Server Profile to new node

Step 1. Go to <https://intersight.com/>, click Infrastructure Service and click Server.

Step 2. Verify the Cisco UCS Fabric Interconnect port assigned for the new C-Series node is enabled and has the role as Server. This can be confirmed by viewing the 'port policy' assigned to Domain Profile

The screenshot displays the Cisco Intersight web interface. The top navigation bar shows 'Infrastructure Service' selected. The left sidebar has 'Configure' > 'Profiles' highlighted. The main content area shows the configuration for 'Ru-DomainProfile-AA09'. The 'Policies' section is expanded to 'Port Configuration', where 'Fabric Interconnect A' is set to 'Configured'. Under 'General', the 'Port' is assigned to 'Ru-PortPolicy'. A callout box points to 'Port 1/21' with 'Port Type: Ethernet' and 'Role: Server'. The 'Port Details' sidebar on the right shows 'Name: Ru-PortPolicy', 'Organization: Ru-Org', 'Device Model: UCS-FI-6454', and 'Port 1/1 (Unconfigured)' with 'Role: Unconfigured'.

Step 3. Ensure additional Cisco UCS C-Series nodes for Rubrik Cluster is cabled to the Sever Port on Cisco UCS Fabric Interconnect. The following screenshot displays the cabling to Cisco UCS Fabric Interconnect.

Overview

Operate

Servers

Chassis

Fabric Interconnects

HyperFlex Clusters

Integrated Systems

Analyze

Explorer **Now**

Configure

Profiles

Templates

Policies

Pools

AA09-FI-DP-6454-4 Healthy Actions

General Inventory UCS Server Profile HCL Statistics Topology

AA09-FI-DP-6454-4 Last Refresh Time: a few seconds ago Refresh

Command Palette

Navigate Intersight with Ctrl+K or go to Help > Command Palette

Step 4. Ensure there is an available IP in 'IP Pool Policy' assigned to Server Profile Template. This is required for CIMC access to the new Cisco UCS C-Series node.

Overview

Operate

Servers

Chassis

Fabric Interconnects

HyperFlex Clusters

Integrated Systems

Analyze

Explorer **Now**

Configure

Profiles

Templates

Policies

Pools

Pools Reserved Identifiers VRFs

Create Pool

All Pools

Export 5 items found 10 per page 1 of 1

IP: Used 8, Available 2

MAC: Used 22, Available 26

UUID: Available 24

WWNN: NO WWNN POOLS

WWPN: NO WWPN POOLS

IQN: NO IQN POOLS

Name	Type	Size	Used	Available	Reserved	Description	Last Update
<input type="checkbox"/> Ru-IP-Pool	IP	5	4	1	0		a few seconds a...
<input type="checkbox"/> Ru-InBand-Pool	IP	5	4	1	0		a minute ago

Step 5. Identify the new Cisco UCS C-Series server node, click the ellipses "...", select Profile and Derive Profile from the template.

Starting on January 25, 2024, any target disconnected for more than 5 minutes will generate an alarm. This new feature means that initial notifications will be high, if your infrastructure has many disconnected targets. As usual, acknowledge alarms to dismiss them.

Servers

All Servers +

Export 4 items found 10

Derive from Template Profile

Install Operating System Upgrade Firmware Launch vKVM Launch Tunneled vKVM Start Alarm Suppression Open TAC Case Set License Tier Collect Tech Support Bundle WZP2651055Z

Name	Health	Model	CP...	Memo...	UCS D...	Serve...	F...	A...
AA09-FI-DP-6454-1	Healthy 4	UCSC-C24...	128.0	384.0	AA09-FI-D...	Ru-SP-...	4.2(2f)	No
AA09-FI-DP-6454-2	Healthy	UCSC-C24...	128.0	384.0	AA09-FI-D...	Ru-SP-...	4.2(2f)	No
AA09-FI-DP-6454-3	Healthy	UCSC-C24...	128.0	384.0	AA09-FI-D...	Ru-SP-...	4.2(3e)	No
AA09-FI-DP-6454-4	Healthy	UCSC-C24...	128.0	384.0	AA09-FI-D...		4.2(2f)	No

Step 6. The Cisco UCS C-Series node is displayed, click Next.

Starting on January 25, 2024, any target disconnected for more than 5 minutes will generate an alarm. This new feature means that initial notifications will be high, if your infrastructure has many disconnected targets. As usual, acknowledge alarms to dismiss them.

Templates

1 General

2 Template

3 Details

4 Summary

General

Please confirm the Server selection

Confirm Server Selection 1 selected

Export 1 items found 10 per page 1 of 1

Name	User Label	Health	Model	UCS Domain	Serial Nu...
AA09-FI-DP-6454-4		Healthy	UCSC-C240...	AA09-FI-DP-6...	WZP2651055Z

Selected 1 of 1 Show All Unselect All

Cancel Next

Step 7. Select the Server Profile template created to deploy the Cisco UCS C-Series node for the Rubrik CDM cluster and click Next.

Intersight Infrastructure Service

Starting on January 25, 2024, any target disconnected for more than 5 minutes will generate an alarm. This new feature means that initial notifications will be high, if your infrastructure has many disconnected targets. As usual, acknowledge alarms to dismiss them.

Templates

- General
- Template**
- Details
- Summary

Template

Select the Template that need to be assigned to profile.

UCS Server Profile Template

Add Filter 2 items found 10 per page 1 of 1

Name	Description	Last Update
<input type="radio"/> Rubrik-Template-1		Dec 22, 2023 3:38 PM
<input checked="" type="radio"/> Ru-SP-Template-1		Oct 18, 2023 7:38 PM

Selected 1 of 2 Show Selected Unselect All 1 of 1

Close Back Next

Step 8. Rename the Derive profile and click Next.

Intersight Infrastructure Service

Starting on January 25, 2024, any target disconnected for more than 5 minutes will generate an alarm. This new feature means that initial notifications will be high, if your infrastructure has many disconnected targets. As usual, acknowledge alarms to dismiss them.

Templates

- General
- Template
- Details**
- Summary

Details

Edit the description, tags, and auto-generated names of the profiles.

General

Organization * Ru-Orig Target Platform UCS Server (FI-Attached)


Description Set Tags

Derive


1 Name *	Organization *	Assigned Server
Ru-SP-Template-1.DERIVED-1	Ru-Orig	AA09-FI-DP-6454-4

Close Back Next

Step 9. Verify the policies and click Derive.



Step 10. When the Sever Profile is derived, go to the Servers tab, identify the Profile displayed as “Not Deployed,” click the ellipses “...” and select Deploy.



Step 11. On the Deploy Profile confirmation screen, enable Reboot Immediately to Activate and click Deploy.

Deploy UCS Server Profile

UCS Server profile "Ru-SP-Template-1_DERIVED-4" will be deployed to server "AA09-FI-DP-6454-4".



If policy configuration requires an immediate reboot and the option below is disabled, then profile deployment will not be initiated.



Reboot Immediately to Activate ⓘ

Cancel

Deploy

Step 12. Monitor the Sever Profile Deployment task and ensure profile is deployed successfully.

← Requests ×

Deploy Server Profile

Details

Status: In Progress

Name: Deploy Server Profile

ID: 65aab7cc699f6e3301db2e4e

Target Type: Rack Server

Target Name: AA09-FI-DP-6454-4

Source Type: Server Profile

Source Name: Ru-SP-Template-1_DERIVE...

Initiator: andhiman@cisco.com

Start Time: Jan 19, 2024 12:56 PM

End Time:

Execution Flow

Progress: 13%

- Wait For BIOS POST Completion
- Power On Server Jan 19, 2024 12:56 PM
- Validate user access to the storage policies Jan 19, 2024 12:56 PM
- Validate user access to the network policies Jan 19, 2024 12:56 PM
- Validate user access to the compute and management policies Jan 19, 2024 12:56 PM
- Validate user access to the profile Jan 19, 2024 12:56 PM
- Prepare Server Profile Deploy Jan 19, 2024 12:56 PM

Step 13. When the profile is successfully deployed, install the OS using Cisco Intersight 'OS installation' feature or by mounting the Rubrik ISO to KVM console. Once Rubrik OS is installed, verify the node with cluster hw_health.

```

Checking networking ports...
  Port |           Device | Driver | State | Link | Speed
  ---- | -
bond0 |                   |        | up    | yes  | 50000Mb/s
bond1 |                   |        | down  | no   | Unknown!
eth0  | Cisco VIC NIC (rev a2) | enic  | down  | no   | Unknown!
eth1  | Cisco VIC NIC (rev a2) | enic  | down  | no   | Unknown!
rketh0 | Intel 10G X550T | ixgbe | down  | no   | Unknown!
rketh1 | Intel 10G X550T | ixgbe | down  | no   | Unknown!
rketh2 | Cisco VIC NIC (rev a2) | enic  | up    | yes  | 50000Mb/s
rketh3 | Cisco VIC NIC (rev a2) | enic  | up    | yes  | 50000Mb/s

Bond0 Mode is fault-tolerance (active-backup)
  Bond0 bond ports are: rketh2 rketh3
  Current active port is rketh3

Bond1 Mode is fault-tolerance (active-backup)
  Bond1 bond ports are: rketh0 rketh1
  Current active port is None
WARNING: Bond1 has no active ports and is not operational.

-----
Checking for MCEs...
/var/log/mcelog is clean

-----
FRU Replacement Summary:
  All FRUS in the node are healthy.
RC240WZP2649Z15W >>
RC240WZP2649Z15W >>
RC240WZP2649Z15W >>
RC240WZP2649Z15W >>

```


Procedure 2. Add Node through Rubrik Management Console

When the Rubrik CDM operating system is installed and the cluster hw_health is 'healthy, contact Rubrik support to add the new node to existing cluster.


Note: The Add Node process demonstrates an expansion from three node cluster to four node cluster. Rubrik recommends having a minimum of four node in the cluster. Rubrik support should be involved for both Cluster Expansion and Cisco UCS C-Series Firmware Upgrades.

Note: Ensure the new node has Rubrik OS installed as detailed in the previous section.


Step 1. Ensure the existing cluster is an healthy state.



Step 2. Go to the Node tab. It displays a three node cluster. Click Add Node.



Step 3. Existing cluster automatically identifies the new node. Enter available Node IP address. In present configuration Cisco UCS C-Series nodes are attached to Cisco Fabric Interconnect and do not utilize IPMI configuration. Therefore, the IPMI IPs are configured as 0.0.0.x. Click Next.



Step 4. Enter the subnet mask and Gateway. In present configuration Cisco UCS C-Series nodes are attached to Cisco Fabric Interconnect and do not utilize IPMI configuration. Therefore, the IPMI Gateway and subnet are 0.0.0.0. The node is registered to the cluster.

Add Node

Check or edit the following fields to add nodes to this cluster.

Default Gateway

Gateway IP: 10.108.1.254

Gateway Network: Management Network Data Network VLAN

Management Network

Subnet Mask: 255.255.255.0

Management VLAN (Optional): Type the Management VLAN

IPMI

Subnet Mask: 0.0.0.0


IPMI Gateway: 0.0.0.0

New IPMI Password

1 node selected

[BACK](#) [ADD](#)

Step 5. It takes about 10–15 minutes for the new node to be visible in the cluster. The screenshot below confirms the addition of new node to the existing cluster:



Upgrade Cisco UCS C-Series Node Firmware

Note: With the Intersight SaaS Management platform, the server firmware upgrade does not require you to download any firmware bundles to a local repository. When the suggested firmware upgrade request is issued, it automatically downloads the selected firmware and starts the upgrade process.

For detailed instructions to perform firmware upgrades, see [Firmware Management in Intersight](#)

Firmware upgrade of Cisco UCS C-Series nodes connected to Cisco UCS Fabric Interconnect is a two-step process. Administrators should upgrade the Cisco UCS Fabric Interconnect Firmware, thereafter, upgrade the Cisco UCS C-Series node firmware.

Note: Firmware upgrade of Cisco UCS Fabric Interconnect is non-disruptive, but firmware upgrade of Cisco UCS C-Series node is disruptive, administrators should have a maintenance window in which the Rubrik cluster is shutdown. Please contact Rubrik support to provision a maintenance window.

To successfully upgrade the Cisco UCS Fabric Interconnect and IO module firmware, see:

https://intersight.com/help/saas/resources/Upgrading_Fabric_Interconnect_Firmware_imm#procedure

Note: During the upgrade of the Intersight Managed Fabric Interconnect, the fabric interconnect traffic evacuation is enabled by default. The fabric interconnect traffic evacuation evacuates all traffic that flows through the fabric interconnect from all servers attached to it, and the traffic will fail over to the peer fabric interconnect for fail over vNICs with no disruptions in the network.


Upgrade Fabric Interconnect

Procedure 1. Upgrade Cisco UCS Fabric Interconnect Firmware


This procedure details the high-level procedure to upgrade firmware of the Cisco UCS Fabric Interconnect in Intersight Managed Mode (IMM). For more details, go to:

https://intersight.com/help/saas/resources/Upgrading_Fabric_Interconnect_Firmware_imm#before_you_begin

Step 1. Login to <https://intersight.com>, click Infrastructure Service, then click Fabric Interconnects, and select the Fabric Interconnect Pair (IMM). Click the ellipses“...” and select Upgrade Firmware.



Step 2. Click Start and from Upgrade firmware make sure the UCS Domain Profile is selected and click Next.



Step 3. Select the recommended Firmware release (currently 4.2(3h)). By default, the upgrade enables the Fabric Interconnect traffic evacuation. Use Advanced Mode to exclude the Fabric Interconnect traffic evacuation.

The screenshot shows the 'Upgrade Firmware' page in the Cisco Intersight interface. The left sidebar contains navigation options like Overview, Operate, Servers, Chassis, Fabric Interconnects, HyperFlex Clusters, Integrated Systems, Analyze, Explorer, Configure, Profiles, Templates, Policies, and Pools. The main content area is titled 'Upgrade Firmware' and has three tabs: General, Version, and Summary. The 'Version' tab is active, showing a list of firmware bundles. A red box highlights the selected bundle: 4.2(3h) with a size of 1.70 GiB and a release date of Sep 30, 2023 1:51 PM. The description is 'Cisco Intersight Infrastructure Bundle'. Below the list are 'Cancel', 'Back', and 'Next' buttons.

Step 4. On the summary page, confirm the firmware to be upgraded and click Upgrade.

The screenshot shows the 'Upgrade Firmware' page in the Cisco Intersight interface, now on the 'Summary' tab. The left sidebar is the same as in the previous screenshot. The main content area is titled 'Upgrade Firmware' and has three tabs: General, Version, and Summary. The 'Summary' tab is active, showing a confirmation message: 'Selected firmware bundle will be downloaded to the Fabric Interconnects and upgraded. Click on Requests to monitor the progress of the firmware upgrade.' Below this is a table showing the selected firmware version (4.2(3h)) and size (1.70 GiB). Underneath, there is a table titled 'Fabric Interconnects to be Upgraded' with one item found. A red box highlights the table row for Fabric Interconnect B, showing its domain name, model, serial, and bundle version. The table has columns for Domain Name, Model, Serial, Bundle Version, and another set of Model, Serial, and Bundle Version. Below the table are 'Cancel', 'Back', and 'Upgrade' buttons.

Step 5. Monitor the upgrade process and wait for it to complete.

Step 6. When the Firmware downloads, acknowledge the Fabric Interconnect B upgrade, and click Continue.

← Requests ×

Upgrade Firmware

Details

Status
Action Required

Name
Upgrade Firmware

ID
65aac302696f6e3301dbb6a2

Target Type
Fabric Interconnect

Target Name
[AA09-FI-DP-6454 FI-A](#)
[AA09-FI-DP-6454 FI-B](#)

Source Type
Firmware Upgrade

Source Name
AA09-FI-DP-6454 FI-A,AA...

Initiator
andhiman@cisco.com

Execution Flow

Progress 26%

i Wait for a user acknowledgement on Fabric Interconnect - B.

i Ensure Fabric Interconnects meet requirements to continue upgrade. Please acknowledge to continue with Fabric Interconnect - B upgrade. Learn more at [Help Center](#).

Proceed

- ✔ Wait for MAC address synchronization on Fabric Interconnect - B.
MAC address synchronization is complete. Jan 19, 2024 1:57 PM
- ✔ Evacuate data traffic on Fabric Interconnect - B. Jan 19, 2024 1:52 PM
- ✔ Wait for image download to complete in endpoint.
Image ucs-intersight-infra-4gfi.4.2.3h.bin successfully cached in Fabric Interconnect(s). Jan 19, 2024 1:52 PM
- ✔ Initiate image download to the endpoint.
Download ucs-intersight-infra-4gfi.4.2.3h.bin request is submitted successfully. Jan 19, 2024 1:44 PM
- ✔ Validate the requirements for the endpoint.
Validation of pre-upgrade space availability completed successfully. Jan 19, 2024 1:44 PM

Step 7. When Fabric Interconnect -B is upgraded, acknowledge the Fabric Interconnect - A upgrade.

← Requests ×

Upgrade Firmware

Details

Status
Action Required

Name
Upgrade Firmware

ID
65aac302696f6e3301dbb6a2

Target Type
Fabric Interconnect

Target Name
[AA09-FI-DP-6454 FI-A](#)
[AA09-FI-DP-6454 FI-B](#)

Source Type
Firmware Upgrade

Source Name
AA09-FI-DP-6454 FI-A,AA...

Initiator
andhiman@cisco.com

Start Time
Jan 19, 2024 1:44 PM

Execution Flow

Progress 58%

i Wait for a user acknowledgement on Fabric Interconnect - A.

i Firmware upgrade for Fabric Interconnect - B is complete. Ensure Fabric Interconnects meet requirements to continue upgrade. Please acknowledge to continue with Fabric Interconnect - A upgrade. Learn more at [Help Center](#).

Proceed

- ✔ Wait for image download to complete.
Image ucs-intersight-infra-4gfi.4.2.3h.bin successfully cached in Fabric Interconnect(s). Jan 19, 2024 2:11 PM
- ✔ Initiate image download to endpoint.
Image ucs-intersight-infra-4gfi.4.2.3h.bin already available in a cache, skipping the download. Image will be synced to the selected endpoints. Jan 19, 2024 2:11 PM
- ✔ Check if the image has been cached.
Verified that image is available in the cache. Jan 19, 2024 2:11 PM
- ✔ Wait for firmware upgrade in Fabric Interconnect - B.
Successfully upgraded Fabric Interconnect. Jan 19, 2024 2:11 PM
- ✔ Initiate firmware upgrade in Fabric Interconnect - B.
Firmware upgrade request submitted successfully. Jan 19, 2024 1:56 PM
- ✔ Wait for a user acknowledgement on Fabric Interconnect - B.
- ✔ Wait for MAC address synchronization on Fabric Interconnect - B.
MAC address synchronization is complete. Jan 19, 2024 1:57 PM

Step 8. Make sure the Firmware upgrade completed successfully.

Requests
Upgrade Firmware

Details

Status: Success

Name: Upgrade Firmware

ID: 65aac302696fe3301dbb6a2

Target Type: Fabric Interconnect

Target Name: AA09-FI-DP-6454 FI-A, AA09-FI-DP-6454 FI-B

Source Type: Firmware Upgrade

Source Name: AA09-FI-DP-6454 FI-A, AA...

Initiator: andhiman@cisco.com

Start Time: Jan 19, 2024 1:44 PM

Execution Flow

- Wait for firmware upgrade in Fabric Interconnect - A. Successfully upgraded Fabric Interconnect. Jan 19, 2024 2:31 PM
- Initiate firmware upgrade in Fabric Interconnect - A. Firmware upgrade request submitted successfully. Jan 19, 2024 2:18 PM
- Wait for MAC address synchronization on Fabric Interconnect - A. MAC address synchronization is complete. Jan 19, 2024 2:16 PM
- Evacuate data traffic on Fabric Interconnect - A. Jan 19, 2024 2:13 PM
- Wait for a user acknowledgement on Fabric Interconnect - A. Jan 19, 2024 2:11 PM
- Wait for image download to complete. Image ucs-intersight-infra-4gfi.4.2.3h.bin successfully cached in Fabric Interconnect(s). Jan 19, 2024 2:11 PM
- Initiate image download to endpoint. Image ucs-intersight-infra-4gfi.4.2.3h.bin already available in a cache, skipping the download. Image will be synced to the selected endpoints. Jan 19, 2024 2:11 PM
- Check if the image has been cached. Verified that image is available in the cache. Jan 19, 2024 2:11 PM
- Wait for firmware upgrade in Fabric Interconnect - B. Successfully upgraded Fabric Interconnect. Jan 19, 2024 2:11 PM
- Initiate firmware upgrade in Fabric Interconnect - B. Firmware upgrade request submitted successfully. Jan 19, 2024 1:58 PM
- Wait for a user acknowledgement on Fabric Interconnect - B. Jan 19, 2024 1:58 PM

Step 9. Verify the firmware upgraded on the Cisco UCS Fabric Interconnect.

Fabric Interconnects

Health: 2 Healthy 2

Connection: Connected 2

Contract Status: Not Covered 2

Bundle Version: 2 4.2(3h) 2

NX-OS Version: 2 9.3(5)42(3f) 2

Models: 2 6454 2

Name	Health	Model	Bundle Version	UCS Domain Profile	Total	Ports Used	Availa...
AA09-FI-DP-6454 FI-A	Healthy	UCS-FI-6454	4.2(3h)	Ru-DomainProfile-AA09	54	18	36
AA09-FI-DP-6454 FI-B	Healthy	UCS-FI-6454	4.2(3h)	Ru-DomainProfile-AA09	54	18	36

Upgrade Cisco UCS C-Series Node Firmware

This section details the procedure to upgrade the firmware of only Cisco UCS C-Series Rubrik certified nodes. The Rubrik CDM software upgrade is not part of this procedure.


Note: Since the Cisco UCS C-Series firmware upgrade requires a reboot, contact Rubrik support to shut down the cluster during the maintenance window.

This section is utilized in two key circumstances.


- Only the Cisco C-Series node firmware requires an upgrade.
- You are comfortable with having a maintenance window for the Rubrik cluster downtime.

Procedure 1. Upgrade Cisco UCS C-Series Node Firmware

Step 1. Login to <https://intersight.com>, click Infrastructure Service, then click Servers. Select the Cisco UCS C-Series nodes that are part of the Rubrik cluster. Click the ellipses... icon and select Upgrade Firmware.



Step 2. Make sure all Cisco UCS C-Series nodes are selected for upgrade. Click Next.



Step 3. Select the recommended Server Firmware version and click Next. At the time of publishing this guide, the suggested firmware was 4.2(3h) If the firmware upgrade does not require drive firmware updates, select Advanced Mode, and check the Exclude Drive option.

The screenshot shows the 'Upgrade Firmware' page in the Cisco Intersight interface. The 'Version' tab is selected, and a list of firmware bundles is displayed. The bundle '4.2(3h)' is highlighted with a red box. The interface includes a search bar, a navigation menu on the left, and a 'Command Palette' at the bottom left.

Version

Select a firmware version to upgrade the servers to.

Select Firmware Bundle Advanced Mode

1 The selected firmware bundle will be downloaded from intersight.com. All the server components will be upgraded along with drives and storage controllers. Use Advanced Mode to exclude upgrade of drives and storage controllers.

Add Filter 18 items found 10 per page 1 of 2

Version	Size	Release Date	Description
4.3(2.230270)	804.67 MiB	Nov 15, 2023 2:12 ...	Cisco Intersight Server Bundle
4.3(2.230207)	797.57 MiB	Aug 16, 2023 2:11 ...	Cisco Intersight Server Bundle
4.2(3i)	854.30 MiB	Nov 7, 2023 1:26 PM	Cisco Intersight Server Bundle
4.2(3h)	854.30 MiB	Sep 30, 2023 2:19 ...	Cisco Intersight Server Bundle
4.2(3g)	828.34 MiB	Jul 31, 2023 2:36 PM	Cisco Intersight Server Bundle
4.2(3e)	828.18 MiB	May 16, 2023 2:41 ...	Cisco Intersight Server Bundle
4.2(3d)	823.63 MiB	Mar 22, 2023 12:2...	Cisco Intersight Server Bundle

Cancel Back Next

Step 4. Click Upgrade.

The screenshot shows the 'Upgrade Firmware' page in the Cisco Intersight interface, now on the 'Summary' tab. The 'Summary' section displays the selected firmware version '4.2(3h)' and a table of servers to be upgraded. The table is highlighted with a red box. The 'Upgrade' button at the bottom right is also highlighted with a red box.

Summary

Confirm configuration and initiate the upgrade.

Firmware

Version: 4.2(3h) Size: 854.30 MiB

Servers to be Upgraded

Add Filter Export 4 items found 13 per page 1 of 1

Name	User Label	Model	Firmware Versi...	Requires Reboot	UCS Domain
AA09-FI-DP-6454-2		UCSC-C240-M6L	4.2(2f)	Yes	AA09-FI-DP-6454
AA09-FI-DP-6454-3		UCSC-C240-M6L	4.2(3e)	Yes	AA09-FI-DP-6454
AA09-FI-DP-6454-1		UCSC-C240-M6L	4.2(2f)	Yes	AA09-FI-DP-6454
AA09-FI-DP-6454-4		UCSC-C240-M6L	4.2(2f)	Yes	AA09-FI-DP-6454

Cancel Back **Upgrade**

Step 5. Select the Reboot Immediately to Begin Upgrade option. This initiates the firmware upgrade across all Cisco UCS C-Series Rubrik certified nodes.

Starting on January 25, 2024, any target disconnected for more than 5 minutes will generate an alarm. This new feature means that initial notifications will be high, if your infrastructure has many disconnected targets. As usual, acknowledge alarms to dismiss them.

Upgrade Firmware

Summary

General

Version

Summary

Size: 854.30 MiB

Reboot Immediately to Begin Upgrade

Cancel Upgrade

Name	User Label	Model	Firmware Versi...	Requires Reboot	UCS Domain
AA09-FI-DP-6454-2		UCSC-C240-M6L	4.2(2f)	Yes	AA09-FI-DP-6454
AA09-FI-DP-6454-3		UCSC-C240-M6L	4.2(3e)	Yes	AA09-FI-DP-6454
AA09-FI-DP-6454-1		UCSC-C240-M6L	4.2(2f)	Yes	AA09-FI-DP-6454
AA09-FI-DP-6454-4		UCSC-C240-M6L	4.2(2f)	Yes	AA09-FI-DP-6454

The Firmware image is downloaded to the end point and staged to the respective node:

Upgrade Firmware

Details

Status: In Progress

Name: Upgrade Firmware

ID: 65aafb74696f6e3301dee8cb

Target Type: Rack Server

Target Name: AA09-FI-DP-6454-4

Source Type: Firmware Upgrade

Source Name: AA09-FI-DP-6454-4

Initiator: andhiman@cisco.com

Start Time: Jan 19, 2024 5:45 PM

End Time:

Execution Flow

Progress: 13%

- Wait for image download to complete in endpoint. 0% completed.
- Initiate image download to endpoint. Download intersight-ucs-server-c240-m6.4.2.3h.bin request is submitted successfully. Jan 19, 2024 5:45 PM
- Validate the requirements for the endpoint. Jan 19, 2024 5:45 PM

Step 6. Confirm the firmware upgrade across all Cisco UCS C-Series nodes is complete.

Intersight Infrastructure Service

Starting on January 25, 2024, any target disconnected for more than 5 minutes will generate an alarm. This new feature means th notifications will be high, if your infrastructure has many disconnected targets. As usual, acknowledge alarms to dismiss them.

Last Login Time : Jan 19, 2024 2:37 PM
Last Login IP : 192.133.242.70

Servers

All Servers 4 items found 10 per page 1 of 1

Health: 4 Healthy 4

Power: On 4

HCL Status: Incomplete 4

Models: C240 M6L 4

Contract Status: Not Covered 4

Profile Status: OK 4

Name	Health	Model	CP...	Memo...	UCS D...	Serve...	FL...	A.	Serial	
AA09-FI-DP-6454-1	Healthy	UCSC-C24...	128.0	384.0	AA09-FI-D...	Ru-SP-...	4.2(3)h	No	WZP26510561	1 ...
AA09-FI-DP-6454-2	Healthy	UCSC-C24...	128.0	384.0	AA09-FI-D...	Ru-SP-...	4.2(3)h	No	WZP2651059D	1 ...
AA09-FI-DP-6454-3	Healthy	UCSC-C24...	128.0	384.0	AA09-FI-D...	Ru-SP-...	4.2(3)h	No	WZP2651056H	1 ...
AA09-FI-DP-6454-4	Healthy	UCSC-C24...	128.0	384.0	AA09-FI-D...	Ru-SP-...	4.2(3)h	No	WZP2651055Z	1 ...

Step 7. Once the firmware across all Cisco UCS C240 LFF nodes are upgraded, restart the Rubrik CDM Cluster.

Rubrik Certified Cisco UCS Nodes

This solution utilizes 4x Cisco UCS C240 M6 LFF nodes configured with Rubrik CDM. Along with this configuration, Cisco and Rubrik have certified solutions with different capacity points available on Cisco UCS C-Series Rack Servers. This allows you to select your configuration based on key characteristics such as:

- Total Capacity
- Cluster Resiliency
- Performance requirements.

Note: Customers should contact Rubrik Sizing Team or Rubrik Sales Specialist for identification of Rubrik Cluster configuration.

[Table 12](#) lists the Rubrik-certified nodes on Cisco UCS Platform.

Table 12. Rubrik Certified Cisco UCS Nodes

Solution Name	Cisco UCS Platform	Capacity per Node	Caching SSDs/NVMe per Node
Rubrik-C240M6 LFF	Cisco UCS C240 M6 LFF Rack Server with 12 drive options	48 TB (12x 4TB)	1.6 TB
		96 TB (12x 8TB)	1.6 TB
		144 TB (12x 12TB)	1.6 TB
		168 TB (12x 14TB)	1.6 TB
		192 TB (12x 16TB)	1.6 TB
		240 TB (12x 20TB)	1.6 TB
		264 TB (12x 22TB)	1.6 TB

About the Authors

Anil Dhiman, Technical Leader, Technical Marketing Engineering, UCS Solutions, Compute & Networking Group, Cisco Systems, Inc.

Anil Dhiman has nearly 20 years of experience specializing in data center solutions on Cisco UCS servers, and performance engineering of large-scale enterprise applications. Over the past 12 years, Anil has authored several Cisco Validated Designs for enterprise solutions on Cisco data center technologies. Currently, Anil's focus is on Cisco's portfolio of hyperconverged infrastructure and data protection solutions.

Acknowledgements

For their support and contribution to the design, validation, and creation of this Cisco Validated Design, the authors would like to thank:

- Urshila Lohani, Product Manager, Cisco Systems Inc.
- Matt Tangvald, Director of Product Management at Rubrik
- Khush Nezam, Product Manager at Rubrik
- Ken Chao, Manufacturing Operations Support Engineer at Rubrik
- Rui Xiao, Staff Hardware Engineer at Rubrik
- Venkat Nitin P., Sr Software Engineer at Rubrik
- Daryl Stanbery, Senior, Director of Alliances at Rubrik

Appendices

This appendix is organized into the following sections:

- [Appendix A – Bill of Materials](#)
- [Appendix B – References Used in this Guide](#)

Appendix A – Bill of Materials

[Table 13](#) provides an example the Bill of Materials used for four (4) node Rubrik CDM cluster deployed on a single Cisco UCS C-Series systems, along with a pair of Cisco Fabric Interconnects, used in the testing and reference design described in this document.

Table 13. Cisco UCS Bill of Materials

Cisco C-Series estimate (4x C240 M5 LFF nodes) for Rubrik CDM Cluster			
1.0	UCS-M6-MLB	UCS M6 RACK, BLADE MLB	1
1.1	DC-MGT-SAAS	Cisco Intersight SaaS	1
1.1.1	DC-MGT-IS-SAAS-AD	Infrastructure Services SaaS/CVA - Advantage	4
1.1.2	SVS-DCM-SUPT-BAS	Basic Support for DCM	1
1.1.3	DC-MGT-UCSC-1S	UCS Central Per Server - 1 Server License	4
1.2	UCSC-C240-M6L	UCS C240 M6 Rack w/o CPU, mem, drives, 2U w LFF	4
1.2.0.1	CON-L1NCO-UCSCC2L4	CX LEVEL 1 8X7XNCDOSUCS C240 M6 Rack wo CPU mem drives 2	4
1.2.1	UCSC-M-V25-04	Cisco UCS VIC 1467 quad port 10/25G SFP28 mLOM	4
1.2.2	CIMC-LATEST	IMC SW (Recommended) latest release for C-Series Servers.	4
1.2.3	UCS-M2-240G	240GB SATA M.2	8
1.2.4	UCS-M2-HWRAID	Cisco Boot optimized M.2 Raid controller	4
1.2.5	UCSX-TPM-002C	TPM 2.0, TCG, FIPS140-2, CC EAL4+ Certified, for M6 servers	4
1.2.6	N20-BKVM	KVM local IO cable for UCS servers console port	4
1.2.7	UCSC-RAIL-M6	Ball Bearing Rail Kit for C220 & C240 M6 rack servers	4
1.2.8	UCSC-BBLKD-S2	UCS C-Series M5 SFF drive blanking panel	12

1.2.9	UCS-DIMM-BLK	UCS DIMM Blanks	80
1.2.10	UCSC-RIS1B-240M6	C240 M6 Riser1B; 2xHDD/SSD; StBkt; (CPU1)	4
1.2.11	UCSC-RIS2A-240M6	C240 / C245 M6 Riser2A; (x8;x16;x8);StBkt; (CPU2)	4
1.2.12	UCSC-RIS3B-240M6	C240 M6 Riser 3B; 2xHDD; StBkt; (CPU2)	4
1.2.13	UCSC-HSLP-M6	Heatsink for 1U/2U LFF/SFF GPU SKU	8
1.2.14	UCSC-M2EXT-240M6	C240M6 / C245M6 2U M.2 Extender board	4
1.2.15	UCSC-MPSTOM6L-KIT	C240M6L MID PLANE KIT 4x3.5" HDD	4
1.2.16	UCS-CPU-I5318N	Intel 5318N 2.1GHz/150W 24C/36MB DDR4 2667MHz	8
1.2.17	UCS-MR-X32G2RW	32GB RDIMM DRx4 3200 (8Gb)	48
1.2.18	UCSC-SAS-M6HD	Cisco M6 12G SAS HBA (32 Drives)	4
1.2.19	UCS-HD12T7KL4KN	12TB 12G SAS 7.2K RPM LFF HDD (4K)	48
1.2.20	UCS-NVMEI4-I1600	1.6TB 2.5in U.2 Intel P5600 NVMe High Perf Medium Endurance	4
1.2.21	UCSC-PSU1-1600W	UCS 1600W AC PSU Platinum (Not EU/UK Lot 9 Compliant)	8
1.2.22	CAB-C13-C14-2M	Power Cord Jumper, C13-C14 Connectors, 2 Meter Length	8
1.2.23	UCS-SID-INFR-OI	Other Infrastructure	4
1.2.24	UCS-SID-WKL-OW	Other Workload	4
1.3	UCSX-FI-6454-U	UCS Fabric Interconnect 6454	2
1.3.0.1	CON-OSP-UCSXUFI6	SN7C-24X7X4OS UCS Fabric Interconnect 6454	2
1.3.1	N10-MGT018	UCS Manager v4.2 and Intersight Managed Mode v4.2	2
1.3.2	UCS-PSU-6332-AC	UCS 6332/ 6454 Power Supply/100-240VAC	4
1.3.3	CAB-C13-C14-3M-IN	Power Cord Jumper, C13-C14 Connectors, 3 Meter Length, India	4
1.3.4	UCS-ACC-6332	UCS 6332/ 6454 Chassis Accessory Kit	2
1.3.5	UCS-FAN-6332	UCS 6332/ 6454 Fan Module	8

Appendix B - References Used in this Guide

Cisco Intersight

<https://www.cisco.com/c/en/us/products/servers-unified-computing/intersight/index.html>

Cisco Unified Computing System

<http://www.cisco.com/en/US/products/ps10265/index.html>

Cisco UCS Manager

<http://www.cisco.com/en/US/products/ps10281/index.html>

Cisco UCS C-Series Rack Servers

<https://www.cisco.com/c/dam/en/us/products/collateral/servers-unified-computing/ucs-c-series-rack-servers/c240m6-lff-specsheet.pdf>

Rubrik CDM

<https://www.rubrik.com/products/cloud-data-management>

Feedback

For comments and suggestions about this guide and related guides, join the discussion on [Cisco Community](https://cs.co/en-cvds) at <https://cs.co/en-cvds>.

CVD Program

ALL DESIGNS, SPECIFICATIONS, STATEMENTS, INFORMATION, AND RECOMMENDATIONS (COLLECTIVELY, "DESIGNS") IN THIS MANUAL ARE PRESENTED "AS IS," WITH ALL FAULTS. CISCO AND ITS SUPPLIERS DISCLAIM ALL WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE. IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THE DESIGNS, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

THE DESIGNS ARE SUBJECT TO CHANGE WITHOUT NOTICE. USERS ARE SOLELY RESPONSIBLE FOR THEIR APPLICATION OF THE DESIGNS. THE DESIGNS DO NOT CONSTITUTE THE TECHNICAL OR OTHER PROFESSIONAL ADVICE OF CISCO, ITS SUPPLIERS OR PARTNERS. USERS SHOULD CONSULT THEIR OWN TECHNICAL ADVISORS BEFORE IMPLEMENTING THE DESIGNS. RESULTS MAY VARY DEPENDING ON FACTORS NOT TESTED BY CISCO.

CCDE, CCENT, Cisco Eos, Cisco Lumin, Cisco Nexus, Cisco StadiumVision, Cisco TelePresence, Cisco WebEx, the Cisco logo, DCE, and Welcome to the Human Network are trademarks; Changing the Way We Work, Live, Play, and Learn and Cisco Store are service marks; and Access Registrar, Aironet, AsyncOS, Bringing the Meeting To You, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, CCSP, CCVP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unified Computing System (Cisco UCS), Cisco UCS B-Series Blade Servers, Cisco UCS C-Series Rack Servers, Cisco UCS S-Series Storage Servers, Cisco UCS Manager, Cisco UCS X-Series, Cisco UCS Management Software, Cisco Unified Fabric, Cisco Application Centric Infrastructure, Cisco Nexus 9000 Series, Cisco Nexus 7000 Series, Cisco Prime Data Center Network Manager, Cisco NX-OS Software, Cisco MDS Series, Cisco Unity, Collaboration Without Limitation, EtherFast, EtherSwitch, Event Center, Fast Step, Follow Me Browsing, FormShare, GigaDrive, HomeLink, Internet Quotient, IOS, iPhone, iQuick Study, LightStream, Linksys, MediaTone, MeetingPlace, MeetingPlace Chime Sound, MGX, Networkers, Networking Academy, Network Registrar, PCNow, PIX, PowerPanels, ProConnect, ScriptShare, SenderBase, SMARTnet, Spectrum Expert, StackWise, The Fastest Way to Increase Your Internet Quotient, TransPath, WebEx, and the WebEx logo are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries. (LDW_P3)

All other trademarks mentioned in this document or website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0809R)

Americas Headquarters
Cisco Systems, Inc.
San Jose, CA

Asia Pacific Headquarters
Cisco Systems (USA) Pte. Ltd.
Singapore

Europe Headquarters
Cisco Systems International BV Amsterdam,
The Netherlands

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco Website at <https://www.cisco.com/go/offices>.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/go/trademarks>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)