

# Séquence de démarrage uBR10012

## Contenu

[Introduction](#)

[Conditions préalables](#)

[Conditions requises](#)

[Components Used](#)

[Conventions](#)

[Séquence de démarrage PRE](#)

[Séquence de démarrage de la carte de ligne RF](#)

[Séquence de démarrage de la carte LAN ou WAN](#)

[Séquence de démarrage de la carte TCC+](#)

[Informations connexes](#)

## [Introduction](#)

Ce document décrit la séquence de démarrage du routeur haut débit universel de la gamme Cisco uBR10000, depuis le PRE (Performance Routing Engine) jusqu'aux cartes de radiofréquence (RF), LAN, WAN et TCC+ (Timing, Communications, and Control Plus).

## [Conditions préalables](#)

### [Conditions requises](#)

Les lecteurs de ce document devraient avoir connaissance des sujets suivants :

- Architecture de routeur Cisco de base
- Interface de ligne de commande du logiciel Cisco IOS®

### [Components Used](#)

Les informations contenues dans ce document sont basées sur les versions de matériel et de logiciel suivantes :

- Routeur haut débit universel Cisco uBR10012
- Logiciel Cisco IOS pour la gamme uBR10000 (UBR10K-P6-M)

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, make sure that you understand the potential impact of any command.

### [Conventions](#)

For more information on document conventions, refer to the [Cisco Technical Tips Conventions](#).

## Séquence de démarrage PRE

La séquence de démarrage du PRE comporte les étapes suivantes :

1. Chargez l'aide de démarrage.

```
c10k-eboot-mz.120-16.6.ST1
```

Cela ne prend en charge aucune carte de ligne ; seule l'interface Fast Ethernet (FE) du PRE est utilisable.

2. Chargez l'image principale.

```
ubr10k-p6-mz.122-1.XF  
ubr10k-k8p6-mz.122-1.XF
```

Chacun de ces types de cartes de ligne interroge le PRE pour le micrologiciel : Carte de ligne de câble TCC+Toaster Gigabit Ethernet POS (Optical Carrier 12) (OC-12)

Cette sortie montre la séquence de démarrage en direct réelle et ses messages de journal :

```
System Bootstrap, Version 12.0(9r)SL2, RELEASE SOFTWARE (fc1)  
!--- Bootstrap version. Copyright (c) 2000 by cisco Systems, Inc. Reset Reason Register =  
RESET_REASON_RESET_REG (0x76) !--- Reason for reload: RESET. C10000 platform with 524288 Kbytes  
of main memory Self decompressing the image : #####  
##### Self decompressing the image :  
#####  
##### Self decompressing the image :  
#####  
##### Self decompressing the image :  
#####  
##### Self decompressing the image :  
#####  
##### Self decompressing the image :  
##### [OK] Restricted Rights Legend Use,  
duplication, or disclosure by the Government is subject to restrictions as set forth in  
subparagraph (c) of the Commercial Computer Software - Restricted Rights clause at FAR sec.  
52.227-19 and subparagraph (c) (1) (ii) of the Rights in Technical Data and Computer Software  
clause at DFARS sec. 252.227-7013. cisco Systems, Inc. 170 West Tasman Drive San Jose,  
California 95134-1706 Cisco Internetwork Operating System Software IOS (tm) 10000 Software  
(UBR10K-P6-M), Version 12.2(1)XF, EARLY DEPLOYMENT RELEASE SOFTWARE (fc1) !--- Main image. TAC  
Support: http://www.cisco.com/cgi-bin/ibld/view.pl?i=support Copyright (c) 1986-2001 by cisco  
Systems, Inc. Compiled Fri 18-May-01 16:15 by ccai Image text-base: 0x60008960, data-base:  
0x612E0000 cisco uBR10000 (PRE-RP) processor with 393215K/131072K bytes of memory. !---  
Processor type. Processor board ID TBA05100542 R7000 CPU at 262Mhz, Implementation 39, Rev 2.1,  
256KB L2, 2048KB L3 Cache Backplane version 1.0, 8 slot Last reset from register reset Toaster  
processor tmc0 is running. Toaster processor tmc1 is running. 1 Ethernet/IEEE 802.3 interface(s)  
1 FastEthernet/IEEE 802.3 interface(s) 509K bytes of non-volatile configuration memory. 46976K  
bytes of ATA PCMCIA card at slot 0 (Sector size 512 bytes). 32768K bytes of Flash internal SIMM  
(Sector size 256KB). 00:00:15: Downloading Microcode: file=system:pxf/c10k102-3.ucode,  
version=102.3(40.4), description=Experimental Software created Wed 31-Jan-01 16:22 by clauer in  
view clauer-omega_dev !--- Microcode for Parallel eXpress Forwarding (PXF) engine. 00:00:16:  
%SYS-7-NV_BLOCK_INIT: Initalized the geometry of nvram 00:00:22: %LINK-3-UPDOWN: Interface  
Ethernet0/0/0, changed state to up !--- 10Base2 interface. 00:00:22: %LINK-5-CHANGED: Interface  
FastEthernet0/0/0, changed state to reset !--- Management FE interface. !--- Each of these lines  
of output appear on one line: 00:00:23: %UBR10000-5-USFREQCHG: Interface Cable6/1/0 Port U0,  
frequency changed to 34.992 MHz 00:00:23: %UBR10000-5-UPDOWN: Interface Cable6/1/0 Port U0,  
changed state to down 00:00:23: %UBR10000-5-UPDOWN: Interface Cable6/1/0 Port U1, changed state  
to down 00:00:23: %UBR10000-5-UPDOWN: Interface Cable6/1/0 Port U2, changed state to down  
00:00:23: %UBR10000-5-UPDOWN: Interface Cable6/1/0 Port U3, changed state to down 00:00:24:
```

```

%LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet0/0/0, changed state to up 00:00:24:
%LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet0/0/0, changed state to down
00:00:25: %LINK-5-CHANGED: Interface POS2/0/0, changed state to administratively down 00:00:25:
%LINK-5-CHANGED: Interface GigabitEthernet4/0/0, changed state to administratively down
00:00:26: %LINEPROTO-5-UPDOWN: Line protocol on Interface POS2/0/0, changed state to down
00:00:26: %LINEPROTO-5-UPDOWN: Line protocol on Interface GigabitEthernet4/0/0, changed state to
down 00:00:29: !!pxf clients started, forwarding code operational!! !--- The PFX engine
microcode is decompressed and executed. 00:00:30: %SYS-5-RESTART: System restarted -- Cisco
Internetwork Operating System Software IOS (tm) 10000 Software (UBR10K-P6-M), Version 12.2(1)XF,
EARLY DEPLOYMENT RELEASE SOFTWARE (fc1) TAC Support: http://www.cisco.com/cgi-
bin/ibld/view.pl?i=support Copyright (c) 1986-2001 by cisco Systems, Inc. Compiled Fri 18-May-01
16:15 by ccai 00:00:30: %SYS-6-BOOTTIME: Time taken to reboot after reload = 349 seconds !---
The time taken to boot after the reload initiated. 00:00:31: %LINK-3-UPDOWN: Interface
FastEthernet0/0/0, changed state to up 00:00:32: %LINEPROTO-5-UPDOWN: Line protocol on Interface
FastEthernet0/0/0, changed state to up 00:00:34: %IPCOIR-5-CARD_DETECTED: Card type 2cable-mc28
(0x254) in slot 6/1 !--- RF card registration request received. 00:00:34: %IPCOIR-5-
CARD_DETECTED: Card type 2cable-mc28 (0x254) in slot 7/0 !--- RF card registration request
received. 00:00:34: %IPCOIR-5-CARD_LOADING: Loading card in slot 6/1 !--- TFTP is used to
transfer the RF card microcode. 00:00:34: %IPCOIR-5-CARD_LOADING: Loading card in slot 7/0 !---
TFTP is used to transfer the RF card microcode. 00:00:34: %IPCOIR-5-CARD_DETECTED: Card type
2cable-tccplus (0x2AF) in slot 1/1 !--- TCC+ registration request received. 00:00:34: %IPCOIR-5-
CARD_DETECTED: Card type loc12pos-1 (0x164) in slot 2/0 !--- LAN to WAN registration received.
00:00:34: %IPCOIR-5-CARD_DETECTED: Card type 1gigetherenet-1 (0x166) in slot 4/0 !--- LAN to WAN
registration received. 00:00:34: %IPCOIR-2-CARD_UP_DOWN: Card in slot 1/1 is up. Notifying
2cable-tccplus driver. 00:00:34: %IPCOIR-2-CARD_UP_DOWN: Card in slot 2/0 is up. Notifying
loc12pos-1 driver. 00:00:34: %UBR10KTCC-2-ACTIVE_TCC: TCCplus card 1/1 is active with Local
oscillator as clock reference 00:00:35: %IPCOIR-2-CARD_UP_DOWN: Card in slot 4/0 is up.
Notifying 1gigetherenet-1 driver. 00:00:35: %C10KGE-6-GBIC_OK: Interface GigabitEthernet4/0/0,
1000BASE-SX Gigabit Interface Converter (GBIC) inserted

```

## Séquence de démarrage de la carte de ligne RF

La séquence de démarrage de la carte de ligne RF comporte les étapes suivantes :

1. Le moniteur ROM (ROMmon) charge l'aide de démarrage dans la carte de ligne.
2. L'aide au démarrage envoie le numéro de version du logiciel et le type de carte.
3. Le PRE télécharge l'image qui correspond au type de carte.
4. L'image du logiciel Cisco IOS est décompressée et exécutée.
5. L'interface Barium est configurée pour que les données puissent être transmises au PRE.

```
brubeck# debug ipc events
```

```
Special Events debugging is on
```

```

*Aug 1 05:12:10.596: IPC: Registration request for seat 'clc_6_1'
!--- The RF line card requests registration with the software version !--- number and the line
card type. *Aug 1 05:12:10.604: IPC: Got an open port request for port 0x10008 *Aug 1
05:12:10.604: IPC: Got an open port request for port 0x10009 1w1d: %IPCOIR-5-CARD_DETECTED: Card
type 2cable-mc28 (0x254) in slot 6/1 !--- The card type is detected. 1w1d: %IPCOIR-2-
CARD_UP_DOWN: Card in slot 6/1 is up. Notifying 2cable-mc28 driver. !--- Microcode for the RF
line card. SLOT 6/1: 00:00:16: %IPCGRP-6-UCODEVER: Reported microcode version, 990227862. SLOT
6/1: 00:00:16: %IPCGRP-6-INTENBDISAB: Interface disabled <REMOVED> !--- The main image is
downloaded, decompressed, and executed. SLOT 6/1: 00:00:19: %IPCGRP-6-BARENBDISAB: Barium
interface enabled !--- Enable Barium interface. 1w1d: %LINK-3-UPDOWN: Interface Cable6/1/1,
changed state to up SLOT 6/1: 00:00:20: %LINK-3-UPDOWN: Interface Cable6/1/1, changed state to
up SLOT 6/1: 00:00:20: %LINK-3-UPDOWN: Interface Barium3/0, changed state to up !--- The Barium
interface is set to up.

```

```
1w1d: %LINEPROTO-5-UPDOWN: Line protocol on Interface Cable6/1/1,
changed state to up
```

```
1w1d: %LINEPROTO-5-UPDOWN: Line protocol on Interface Cable6/1/0,
```

```
changed state to up
SLOT 6/1: 00:00:21: %LINEPROTO-5-UPDOWN: Line protocol on Interface Barium3/0,
changed state to up
!--- The Barium line protocol is up and can now pass data to the PRE.
```

L'aide au démarrage continue d'envoyer le numéro de version du logiciel et le type de carte en tant que keepalive. Si le microcode est mis à niveau sur le PRE, le nouveau microcode est téléchargé et la mise à niveau se produit automatiquement.

## Séquence de démarrage de la carte LAN ou WAN

La séquence de démarrage d'une carte LAN ou WAN comporte les étapes suivantes :

1. La carte de ligne demande l'enregistrement à l'aide du numéro de version du logiciel et du type de carte.
2. Le PRE télécharge l'image qui correspond au type de carte.
3. L'image du logiciel Cisco IOS est décompressée et exécutée.

```
brubeck# debug ipc events
```

```
Special Events debugging is on
*Aug 1 05:08:01.496: IPC: Registration request for seat
'C10K Line Card slot 2/0'
!--- The LAN or WAN card requests registration with the software !--- version and the card type.
*Aug 1 05:08:01.500: IPC: Got an open port request for port 0x10008 1wld: %IPCOIR-5-
CARD_DETECTED: Card type loc12pos-1 (0x164) in slot 2/0 !--- The card type is detected. 1wld:
%IPCOIR-5-CARD_LOADING: Loading card in slot 2/0 !--- TFTP is used to transfer the microcode to
the line card. 1wld: %C10K-5-LC_NOTICE: Slot[2/0] loc12pos-1 Image Downloaded...Booting... !---
The image is decompressed and the code is executed.
```

## Séquence de démarrage de la carte TCC+

La séquence de démarrage d'une carte TCC+ comporte les étapes suivantes :

1. La carte TCC+ demande l'enregistrement en utilisant le numéro de version du logiciel et le type de carte.
2. Le PRE télécharge l'image qui correspond au type de carte.
3. L'image du logiciel Cisco IOS est décompressée et exécutée

```
brubeck# debug ipc events
```

```
Special Events debugging is on
*Aug 1 07:00:40.751: IPC: Registration request for seat
'C10K Line Card slot 1/1'
!--- The TCC+ card requests registration. *Aug 1 07:00:40.755: IPC: Got an open port request for
port 0x10008 1wld: %IPCOIR-5-CARD_DETECTED: Card type 2cable-tccplus (0x2AF) in slot 1/1 !---
The card type is detected. 1wld: %IPCOIR-5-CARD_LOADING: Loading card in slot 1/1 !--- TFTP is
used to transfer the microcode to the TCC+ card. 1wld: %C10K-5-LC_NOTICE: Slot[1/1] utility-card
Image Downloaded...Booting... !--- The image is decompressed and the code is executed. 1wld:
%IPCOIR-5-CARD_DETECTED: Card type 2cable-tccplus (0x2AF) in slot 1/1 1wld: %IPCOIR-2-
CARD_UP_DOWN: Card in slot 1/1 is up. Notifying 2cable-tccplus driver. 1wld: %UBR10KTCC-2-
ACTIVE_TCC: TCCplus card 1/1 is active with Local oscillator as clock reference !--- The card is
active and reports its clock source.
```

## Informations connexes

- [Support pour la technologie de câble haut débit](#)
- [Routeur haut débit universel Cisco uBR10012](#)
- [Notes de version du routeur haut débit universel de la gamme Cisco uBR10000](#)
- [Support technique - Cisco Systems](#)