



Release Notes for Cisco IOS XRv 9000 Routers, IOS XR Release 24.3.1

Release Notes for Cisco IOS XRv 9000 Router, IOS XR Release 24.3.1 2

Cisco IOS XRv 9000 Router Overview 2

Supported Cisco IOS XR Technologies 9

Caveats 13

Other Important Information 13

Full Cisco Trademarks with Software License 14

Release Notes for Cisco IOS XRv 9000 Router, IOS XR Release 24.3.1

Cisco IOS XRv 9000 Router is a cloud-based router that is deployed on a virtual machine (VM) instance on x86 server hardware running 64 bit IOS XR software. Cisco IOS XRv 9000 Router provides traditional Provider Edge (PE) services in a virtualized form factor, as well as virtual Route Reflector (vRR) capabilities.

Cisco IOS XRv 9000 Router Overview

The Cisco IOS XRv 9000 Router is based on Cisco IOS XR software, so it inherits and shares the wide breadth of routing functionality available on other IOS XR platforms. The IOS XR features available on the Cisco IOS XRv 9000 Router are discussed in *Supported Cisco IOS XR Technologies* section.

When the Cisco IOS XRv 9000 Router virtual IOS XR software is deployed as a VM, the Cisco IOS XR software functions just as if it were deployed on a traditional Cisco IOS XR hardware platform. The Cisco IOS XRv 9000 Router combines Route Processor, Line Card, and virtualized forwarding capabilities into a single, centralized forwarding instance. The Cisco IOS XRv 9000 Router has a fully featured, high speed virtual x86 data plane.

Cisco IOS XRv 9000 Router supports the same look and feel as Cisco ASR 9000 Series Aggregation Services Routers and North-bound APIs. Cisco IOS XRv 9000 Router does not support hardware specific configurations. The configuration commands for control plane and data plane features follow the same syntax as the Cisco ASR 9000 Series Aggregation Services Routers. See Cisco ASR 9000 Series Aggregation Services Routers command references for more information on configuration commands.

What's New in Cisco IOS XR Release 24.3.1

For more details on the Cisco IOS XR release model and associated support, see Software Lifecycle Support Statement - IOS XR.

Software Features Enhanced and Introduced

Feature	Description			
Segment Routing	Segment Routing			
Delay Measurement Using Software Timestamp	You can now use software timestamp on your router to measure the delay and loss of each network path, when the existing hardware lacks timestamp support, which aids in identifying performance issues caused by the network, disk I/O, processing, or other factors. Software timestamping for delay measurement measures the time it takes for data to travel within a network or system.			
	You can implement it across various platforms and operating systems without needing specialized hardware, making it a flexible solution to easily deploy.			
	The feature introduces these changes:			
	CLI:			
	• The timestamp-format NTP keyword is introduced in the performance-measurement delay-profile command.			
Routing				

Feature	Description	
Enhanced BGP BFD Strict-Mode Capabilities for Improved Interoperability	You now have the capability of upgrading your network with Cisco's "BGP BFD strict-mode negotiate and "override" modes, which enhance stability and device cooperation between Cisco IOS XR and Cisco XE systems. These modes ensure BGP sessions initiate only if BFD sessions are active, with the overrid option enforcing this even if a peer device lacks strict-mode support. This feature resolves interoperability issues, secures route propagation, and adheres to IETF standards, leading to a more reliable network.	
	This feature introduces these changes:	
	CLI:	
	The bfd-state keyword is introduced in the show bgp sessions command.	
	• The BFDmode and BFDState fields were added to show bgp neighbors command output.	
	YANG Data Models:	
	New XPaths for Cisco-IOS-XR-um-router-bgp-cfg.yang	
	(See GitHub, YANG Data Models Navigator)	

System Requirements

Appliance Model

Cisco IOS XRv 9000 Appliance is the pre-installed Cisco IOS XRv 9000 Router software that is sent from the factory on a bare metal UCS server hardware. It supports hyper scalability as it can scale to 70 Million route prefixes when run as a Virtual Route Reflector. Therefore, the extra layer of software (hypervisor) is not required.

The Appliance also supports Zero Touch Provisioning (ZTP) which allows easier insertion into existing networks.

Hypervisors

A hypervisor enables multiple operating systems to share a single hardware host machine. While each operating system appears to have the dedicated use of the host's processor, memory, and other resources; the hypervisor controls and allocates only needed resources to each operating system and ensures that the operating systems (VMs) do not disrupt each other.

Installation of the Cisco IOS XRv 9000 Router is supported on selected Type 1 (native, bare metal) hypervisors. Installation is not supported on Type 2 (hosted) hypervisors, such as VMware Fusion, VMware Player, or Virtual Box. The following table lists release specific supported hypervisor versions.

Table 1: Support Matrix for Hypervisor Versions

Cisco IOS XR Version	VMWare ESXi	Kernel Based Virtual Machine (KVM)
Release 24.3.1	version 6.5, 6.7,7.0	Linux KVM based on
		• Red Hat Enterprise Linux 7, 7.1, 7.2, 7.3, 7.4, 7.5, 7.6, 7.7, and 8.0
		• Ubuntu 14.04.03 LTS
		• Ubuntu 16.04 LTS
		• CentOS 7, 7.1, 7.2, 7.3, 7.4, 7.5, 7.6, and 7.7
		• Openstack 10

Virtual Machines

Cisco IOS XRv 9000 Router virtual machines must meet the following requirements:

Table 2: VM Requirement for VMware Environment

Parameters	Supported	
VMware ESXi	Version 6.5, 6.7, 7.0	
Virtual CPU cores	1 socket with a minimum of 2 cores	
	Note For production environment minimum of 4 cores is recommended.	
	Note For multicast heavy deployments we recommend to configure 8 cores (with 4 assigned for control plane and 4 assigned for data plane).	
Virtual Machine memory size	12GB minimum, 19GB recommended for 10G interfaces	
Virtual Machine hard disk size	64GB minimum for vPE and vRR image variants	
Virtual Interfaces	• E1000	
	VMXNET3 for traffic interfaces only	
Physical NICs	For pass-through:	
	• Intel X710	
	SR-IOV supported for:	
	• Intel E810 XXV (Trunk VFs Only)	

Parameters	Supported	
Number of interfaces	Maximum of 11 NICs where:	
	• 1 for management	
	• 2 are reserved	
	• 8 for traffic	
Default video, SCSI controller set	Required	
	SCSI controller not required for IDE disk.	
Virtual CD/DVD drive installed	Virtual CD/DVD is required when installing the Cisco IOS XRv 9000 Router on the VM using ISO template.	
IDE hard disk	Single IDE hard disk	
	Note Multiple hard disk drives on a VM are not supported.	



Note

The maximum traffic performance with pass-through NIC interfaces in ESXi is lower than the performance that can be achieved in KVM environments. This is because it is not possible to configure 1G huge-pages in the ESXi hypervisor (as of VMware ESXi 6.0).

Table 3: VM Requirement for KVM Environment

Parameters	Supported	
KVM versions	• Linux KVM based on Red Hat Enterprise Linux 7, 7.1, 7.2, 7.3 and 7.4	
	Ubuntu 14.04.03 LTS Server 64 Bits	
	• Ubuntu 16.04 LTS	
	Openstack Release 5 (Icehouse), Openstack Juno/Icehouse (RHEL 7), Kilo (RHEL 7.1), Liberty (RHEL 7.2), Openstack 10 (Newton)	
	• CentOS 7, 7.1, 7.2, 7.3, 7.4, 7.5, 7.6, and 7.7	
Virtual CPU cores	1 socket with minimum of 2 cores.	
	Note For multicast heavy deployments we recommend to configure 8 cores (with 4 assigned for control plane and 4 assigned for data plane).	
Virtual Machine memory size	12GB Minimum, 19GB recommended for 10G interfaces	
Virtual Machine hard disk size	64GB minimum	

Parameters	Supported	
Virtual Interfaces	E1000, VirtIO and	
	VMXNET3 for traffic interfaces only	
Physical NICs	For pass-through:	
	• Intel X710	
Number of interfaces	Minimum of 4 NICs where:	
	• 1 is for management	
	• 2 are reserved	
	• 1 is for traffic	
	Maximum of 11 NICs where:	
	• 1 is for management	
	• 2 are reserved	
	• 8 is for traffic	
Virtual CD/DVD drive installed	Virtual CD/DVD drive is required for ISO installation	



Note

In the Cisco IOS XRv 9000 Router, some CPU cores are dedicated to the control plane while others are dedicated to the data plane. Each data plane's core runs a single thread that performs packet forwarding. To achieve maximum performance, these threads constantly look for data packets to process. As a result, the OS records that these cores run at 100% utilization. This is expected behavior and not an indication that packet forwarding has reached its threshold limit.

10G Optic Support

Product	Product Code	Supplier Part Number
Cisco 10GBASE SFP+, Short Range	Cisco SFP-10G-SR	Cisco SFP-10G-SR
		Note This optic is recommended for the better performance and interoperability with IOS XRv 9000.
Cisco 10GBASE SFP+, Long Range	Cisco SFP-10G-LR	Cisco SFP-10G-LR
		Note This optic is recommended for the better performance and interoperability with IOS XRv 9000.

Product	Product Code	Supplier Part Number
Intel Ethernet SFP SR Optics	E10GSFPSR	FTLX8571D3BCVIT1 or
Dual Rate 10GBASE-SR/1000BASE-SX		AFBR-709DMZ-IN2

Server

The server must support:

- Intel Westmere or later CPU versions with clock frequency of 2.0GHz for instances with Gigabit or paravirtualized interfaces
- Intel Ivy Bridge or later CPU versions for instances with 10Gb or higher interfaces
- Intel CPU must support the **sse4_2** capability flag. This can be checked in KVM by looking for the **sse4_2** flag in the flags section of /proc/cpuinfo. For example:

```
cat /proc/cpuinfo | grep sse4_2 flags : fpu vme de pse tsc msr pae mce cx8 apic sep mtrr pge mca cmov pat pse36 clflush mmx fxsr sse sse2 ss syscall nx pdpe1gb rdtscp lm constant_tsc arch_perfmon nopl xtopology tsc_reliable nonstop_tsc aperfmperf pni pclmulqdq vmx ssse3 fma cx16 pcid sse4_1 sse4_2 x2apic movbe popcnt aes xsave avx f16c rdrand hypervisor lahf lm ida arat epb pln pts dtherm tpr shadow vnmi ept vpid fsgsbase smep
```



Note

To use passthrough interfaces in KVM, you must set the option intel_iommu=on command in the grub configuration.

Licensing

Starting with Cisco IOS XR Release 24.1.1, Smart Licensing Using Policy (SLP) is the default Licensing model. When you upgrade to the Cisco IOS XR Release 24.1.1 release or later, the Smart Licensing Using Policy is enabled by default.

You can migrate your devices to Smart Licensing with Policy model, see *Migrating from Smart Licensing to Smart Licensing Using Policy*, Smart Licensing Using Policy on Cisco IOS XR Routers.

We recommend that you update to the latest version of SSM On-Prem or Cisco Smart Licensing Utility.



Note

SSM On-Prem and CSSM both support SLP devices and SL devices. SLP devices and SL devices can coexist in a network. The Smart Licensing (SL) model is available in releases Cisco IOS XR Release 7.11.1 and earlier.

Cisco IOS XRv 9000 Router Licensing Model

The Cisco IOS XRv 9000 Router supports activation using Cisco Smart Licensing. By default the Cisco IOS XRv 9000 Router (without license) is rate limited to 200 Kbps.

For more information on licensing model supported on Cisco IOS XRv 9000 Router, see the *Cisco IOS XRv 9000 Router Smart Licensing* chapter in the Cisco IOS XRv 9000 Router Installation and Configuration Guide.

See Cisco Smart Software Licensing Overview for more information on Cisco Smart Licensing.

License Ordering Information

The Cisco IOS XRv 9000 Router offers a flexible licensing scheme, with multiple tiers to choose from, such as Scale, and Throughput. This table lists details of Cisco IOS XRv 9000 Router's pool of software licenses or entitlements, arranged according to licensing PIDs.



Note

The XRv9000 router only consumes and reports VPE licenses. VRR licenses are not consumed or reported.

Table 4: Cisco IOS XRv 9000 Router Licensing PIDs

PIDs	Description	
R-IOSXRV-SUBSCRIP	Bundle PID for IOS XRV SBP	
R-VROUTER-SUB	Subscription license for Cisco IOS XRv 9000 Software	
R-IOSXRV-SUB-IMG	ATO for XRv SUB	
S-XRV-SUB-RR-1M	Subscription license for virtual Route Reflector (vRR) functionality with 1 million routes	
S-XRV-SUB-RTU	IOS XRv 9000 license for one virtual router instantiation	
S-XRV-SUB-RR-4M	Subscription license for virtual Route Reflector (vRR) scale upgrade from 4 million routes	
S-XRV-SUB-RR-10M	Subscription license for virtual Route Reflector (vRR) scale upgrade from 4 to 10 million routes	
S-XRV-SUB-RR-20M	Subscription license for virtual Route Reflector (vRR) scale upgrade from 10 to 20 million routes	
S-XRV-SUB-XTC	Billing PID for SBP XRV9K -SR-PCE (XTC) RTU	
S-XRV-B-SUB-1G	IOS XRv 9000 1G throughput license for IP MPLS base package	
S-XRV-P-SUB-1G	IOS XRv 9000 1G throughput license for IP MPLS premium package	
S-XRV-L3-B-SUB-1G	IOS XRv 9000 1G throughput license for IP MPLS L3VPN base package	
S-XRV-L3-P-SUB-1G	IOS XRv 9000 1G throughput license for IP MPLS L3VPN premium package	
S-XRV-LI-SUB-RTU	IOS XRv 9000 Advance software license for Lawful Intercept	
S-XRV-HQOS-SUB-1G	IOS XRv 9000 1G Advance software license for HQoS	
SVS-XRV-SUPT-BA XRV Support - Basic		

Supported Cisco IOS XR Technologies

Cisco IOS XRv 9000 Router supports selected Cisco IOS XR technologies.

This table lists the major Cisco IOS XR technologies Cisco IOS XRv 9000 supports. Not all features in a given technology may be supported. To verify support for specific features, use Cisco Feature Navigator.

Table 5: Cisco IOS XR Technologies Supported on the Cisco IOS XRv 9000 Router

Feature	See the Following Documentation	Introduced in Release
Application Hosting	Cisco IOS XR Application Hosting Configuration Guide	Release 6.1.2
BFD over Logical Bundle	 Routing Configuration Guide for Cisco ASR 9000 Series Routers Routing Command Reference for Cisco ASR 9000 Series Routers 	Release 6.1.2
Bi-directional Policing and Marking	 Cisco ASR 9000 Series Aggregation Services Router Modular Quality of Service Configuration Guide Cisco ASR 9000 Series Aggregation Services Router Modular Quality of Service Command Reference 	Release 5.4.0
BGP Persistence	 Cisco ASR 9000 Series Aggregation Services Router Routing Configuration Guide Cisco ASR 9000 Series Aggregation Services Router Routing Command Reference 	Release 6.2.1
BGP Optimal Route Reflector	Cisco IOS XRv 9000 Router Installation and Configuration Guide	Release 6.0.1
Customize Installation using Golden ISO	Customize Installation using Golden ISO	Release 7.3.1
Cisco IOS XRv 9000 Router Deployment on AWS	Cisco IOS XRv 9000 Router Installation and Configuration Guide	Release 6.3.1
Create User Profiles and Assign Privileges	System Setup and Software Installation Guide for Cisco ASR 9000 Series Routers	Release 7.1.1
Early Fast Discard	Early Fast discard	Release 5.4.0
Generic Routing Encapsulation (GRE) over IPv4	MPLS Layer 3 VPN Configuration Guide for Cisco ASR 9000 Series Routers Generic Routing Encapsulation Commands	Release 6.3.1

Feature	See the Following Documentation	Introduced in Release
• HSRP • VRRP	 IP Addresses and Services Configuration Guide for Cisco ASR 9000 Series Routers Cisco ASR 9000 Series Aggregation Services Router IP Addresses and Services Command Reference 	Release 6.2.1
Hierarchical Policers (including conform aware)	Cisco ASR 9000 Series Aggregation Services Router Modular Quality of Service Configuration Guide Cisco ASR 9000 Series Aggregation Services Router Modular Quality of Service Command Reference	Release 6.0.1
• IPv4 Routing • IPv6 Routing • OSPF • ISIS	Cisco ASR 9000 Series Aggregation Services Router Routing Configuration Guide Cisco ASR 9000 Series Aggregation Services Router Routing Command Reference	Release 5.4.0
IPSLA Platform Automated Monitoring	Implementing IP Service Level Agreements Cisco ASR 9000 Series Aggregation Services Router System Monitoring Command Reference	Release 6.0.0
• IPv4 and IPv6 ACL	Cisco ASR 9000 Series Aggregation Services Router IP Addresses and Services Configuration Guide Access List Commands	Release 5.4.0
• IPv4 L3VPN • 6PE, 6VPE	 Cisco ASR 9000 Series Aggregation Services Router MPLS Layer 3 VPN Configuration Guide Cisco ASR 9000 Series Aggregation Services Router VPN and Ethernet Services Command Reference 	Release 5.4.0
L2VPN VPWS	 L2VPN and Ethernet Services Configuration Guide for Cisco ASR 9000 Series Routers VPN and Ethernet Services Command Reference for Cisco ASR 9000 Series Routers 	Release 6.4.1
Link Aggregation Group (LAG)	Cisco ASR 9000 Series Aggregation Services Router Interface and Hardware Component Configuration Guide	Release 6.1.2

Feature	See the Following Documentation	Introduced in Release
Lawful Intercept	Implementing Lawful Intercept Cisco ASR 9000 Series Aggregation Services Router System Security Command Reference	Release 5.4.0
• LDP	Cisco ASR 9000 Series Aggregation Services Router MPLS Configuration Guide Cisco ASR 9000 Series Aggregation Services Router MPLS Command Reference	Release 5.4.0
• LPTS	Cisco ASR 9000 Series Aggregation Services Router IP Addresses and Services Configuration Guide LPTS Commands	Release 5.4.0
Multicast features: • IPv4/IPv6 L3 Native Multicast: IGMP, MLD, PIM SM/SSM in default VRF • IPv4 MVPN Rosen GRE with IGMP, PIM SM/SSM in Non-Default VRF • Profile 0: Rosen MVPN GRE • Profile 3: Rosen MVPN GRE with BGP-AD • Profile 11: Rosen MVPN GRE with BGP C-Multicast routing	Multicast Configuration Guide for Cisco ASR 9000 Series Routers Multicast Command Reference for Cisco ASR 9000 Series Routers	Release 6.4.1
• MPLS	Cisco ASR 9000 Series Aggregation Services Router MPLS Configuration Guide Cisco ASR 9000 Series Aggregation Services Router MPLS Command Reference	Release 5.4.0
• MP-BGP, EBGP PE-CE	Cisco ASR 9000 Series Aggregation Services Router Routing Configuration Guide Cisco ASR 9000 Series Aggregation Services Router Routing Command Reference	Release 5.4.0
Network Service Header (NSH)	Implementing NSH Based Service Chaining Cisco ASR 9000 Series Aggregation Services Router IP Addresses and Services Command Reference	Release 6.1.2

Feature	See the Following Documentation	Introduced in Release
NSH Proxy Mode	Cisco IOS XRv 9000 Router Specific Features	Release 6.2.1
RT Constriant	Cisco ASR 9000 Series Aggregation Services Router Routing Configuration Guide Cisco ASR 9000 Series Aggregation Services Pouter Routing Commend References	Release 6.2.1
Segment Routing over IPv6	Router Routing Command Reference Segment Routing Configuration Guide for Cisco ASR 9000 Series Routers Segment Routing Command Reference for Cisco	Release 6.6.1
• Telemetry	ASR 9000 Series Routers Telemetry Configuration Guide for Cisco ASR 9000 Series Routers	Release 6.0.0
The Two-Way Active Measurement Protocol (TWAMP)	System Monitoring Configuration Guide for Cisco ASR 9000 Series Routers Cisco ASR 9000 Series Aggregation Services Router System Monitoring Command Reference	Release 6.0.1
Virtualised Local Mobility Anchor (vLMA)	Configuring Proxy Mobile IPv6 Local Mobility Anchor Proxy Mobile IPv6 Local Mobility Anchor Commands	Release 6.3.1
VRF Support on Docker and LXC Containers	Cisco IOS XR Application Hosting Configuration Guide	Release 6.3.1
SRv6 Traffic Engineering	Segment Routing Configuration Guide for Cisco ASR 9000 Series Routers	Release 7.3.2
gNMI Bundling of Telemetry Updates	Cisco IOS XRv 9000 Router Installation and Configuration Guide	Release 7.8.1
Auto-Save and Copy Router Configuration Using Public Key Authentication	General Administration on Cisco ASR 9000 Series Routers	Release 7.10.1
Smart Licensing Using Policy	Cisco IOS XR Smart Licensing Using Policy	Release 24.1.1
Multi-Factor Authentication for SSH	System Security Configuration Guide for Cisco ASR 9000 Series Routers	Release 24.1.1

Caveats

Cisco XRv 9000 Series Router Specific Bugs

There are no caveats in this release.

Other Important Information

• For the XRv 9000 platform, minimum transmission period supported for the Link Aggregation Control Protocol (LACP) is 200 milliseconds.

Upgrading Cisco IOS XR Software

Cisco IOS XR Software is installed and activated from modular packages, allowing specific features or software patches to be installed, upgraded, or downgraded without affecting unrelated processes. Software packages can be upgraded or downgraded on all supported card types, or on a single card (node).



Note

The FPD related commands are not supported on IOS XRv 9000 Appliance. That includes **fpd auto-upgrade** command.

Cisco IOS XR Error messages

To view, search, compare, and download Cisco IOS XR Error Messages, refer to the Cisco IOS XR Error messages tool.

Cisco IOS XR MIBs

To determine the MIBs supported by platform and release, refer to the Cisco IOS XR MIBs tool.

Related Documentation

The most current Cisco XRv 9000 router documentation is located at the following URL:

https://www.cisco.com/c/en/us/td/docs/iosxr/ios-xrv-9000-router.html

Full Cisco Trademarks with Software License

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: https://www.cisco.com/c/en/us/about/legal/trademarks.html. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

 $^{\tiny{\textcircled{\scriptsize 0}}}$ 2023 Cisco Systems, Inc. All rights reserved.



Americas Headquarters Cisco Systems, Inc. San Jose, CA 95134-1706 USA **Asia Pacific Headquarters** CiscoSystems(USA)Pte.Ltd. Singapore **Europe Headquarters** CiscoSystemsInternationalBV Amsterdam,TheNetherlands